


## USER'S MANUAL

### SMOKE AND FIRE\* ALARM



P  
Printed in Mexico  
MOB-0466-160277-RevB L 01/18  
CONFORMS TO UL STD 217  
Model P1210

#### 10-YEAR SEALED BATTERY OPERATED PHOTOELECTRIC SMOKE ALARM WITH SILENCE FEATURE

#### IMPORTANT! PLEASE READ CAREFULLY AND SAVE.

The warnings/limitations card and manual contains important information about your smoke alarm's operation. If you are installing this alarm for use by others, you must leave this manual or a copy of it—with the end user. Reference product card for additional information.

#### INTRODUCTION

Thank you for choosing First Alert® for your smoke alarm needs. You have purchased a state-of-the-art smoke alarm designed to provide you with early warning of a fire. Please take the time to read this manual and make the smoke alarm an integral part of your family's safety plan.

#### KEY FEATURES OF THE P1210 SMOKE ALARM:

**Photoelectric Sensing Technology:** Photoelectric Sensors are generally more sensitive than ionization sensors in detecting smoldering fires which commonly occur in couches or bedding.

**OptiPath 360 Technology™:** Patented technology provides 360° of direct access to the smoke sensor.

**Single Test/Silence Button:** Allows you to test the alarm or silence nuisance alarms. Testing the alarm assures you that the unit is functioning correctly and ready to protect you and your family.

The alarm can be silenced for up to 9 minutes in the event of a nuisance alarm.

**10-Year End of Life Indicator and Low Battery Warning:** The alarm will chirp once per minute indicating a Low Battery Warning, meaning the unit will need to be replaced soon. The alarm will sound 3 pulses every 43 seconds to alert that the batteries are dead and the unit needs to be replaced immediately.

**Latching Feature - Alarm Memory:** The alarm sensed smoke or fire, went off and pulled itself out of alarm mode.

To notify you of this event, the alarm will give 3 quick flashes every 45 seconds for 24 hours. You can stop it by pressing the test/silence button. After 24 hours, it will pull itself out of the latch mode and no longer flash.

**Low Battery Silence:** The alarm can be silenced for 8 hours.

L © 2018 BRK Brands, Inc. All rights reserved. Distributed by BRK Brands, Inc., BRK Brands, Inc. is a subsidiary of Novelis Inc. (NYSE:NWL) - 3901 Liberty Street, Aurora, IL 60504-8122. Customer Service Team: (800) 323-8005 - www.firstalert.com - www.brkelectronics.com

#### FOLLOW THESE SIMPLE STEPS

1. Hold the mounting bracket against the ceiling (or wall) so the two clusters of universal mounting holes are aligned approximately at the 9:00 and 3:00 o'clock positions. See image. Choose one of the three sets of holes shown, A, B or C (see image) and trace around one of the sets. Be sure to choose a top and bottom slot on opposite sides so you can rotate the universal mounting bracket into position later. This will make it easier in the future to remove the mounting bracket without completely removing the screws.

**WARNING!** Do not install this alarm over an existing electrical box. Only AC powered units are intended for installation over electrical boxes.

2. Put the unit where it won't get covered with dust when you drill the mounting holes.

3. Using a 3/16" (5 mm) drill bit, drill a hole through the center of the oval outlines you traced.

4. Insert the small screw anchors (in the plastic bag with screws) into the holes. Tap the screw anchors gently with a hammer, if necessary, until they are flush with the ceiling or wall.

5. Install the screws but do not tighten completely. Attach the mounting bracket by aligning the screws in the open portion of the universal mounting slots and rotating the bracket into place. Tighten the screws until they are snug to secure the bracket. Do not over tighten.

6. Activating the battery. Mount alarm to mounting bracket to activate. Once unit is activated, it cannot be turned off. Make sure the alarm is locked into the mounting bracket.

**NOTE:** After you activate the battery, the power indicator light may flash. (If the unit alarms, the light will blink rapidly, and the horn will repeatedly sound 3 beeps, pause, 3 beeps.) Once the smoke alarm is on the bracket, you can rotate the alarm to adjust the alignment.

7. Test the alarm. See "Weekly Testing."




#### TO PERMANENTLY DEACTIVATE THE SMOKE ALARM

8. After 10 years of operation or Low Battery Warning, deactivate the alarm: Insert a tool below edge where shown and break tab. Then slide activation switch to deactivate mode.

**NOTE:** At end of life or low battery indication (chirp) unit must be put into deactivation mode to deactivate remaining stored energy in battery. Unit will no longer function once put into this mode. Unit will resist re-mounting.


Installed on Replace by

#### MOUNTING HOLE SETS



## USER'S MANUAL

### SMOKE AND FIRE\* ALARM



P  
Printed in Mexico  
MOB-0466-160277-RevB L 01/18  
CONFORMS TO UL STD 217  
Model P1210

#### 10-YEAR SEALED BATTERY OPERATED PHOTOELECTRIC SMOKE ALARM WITH SILENCE FEATURE

#### IMPORTANT! PLEASE READ CAREFULLY AND SAVE.

The warnings/limitations card and manual contains important information about your smoke alarm's operation. If you are installing this alarm for use by others, you must leave this manual or a copy of it—with the end user. Reference product card for additional information.

#### INTRODUCTION

Thank you for choosing First Alert® for your smoke alarm needs. You have purchased a state-of-the-art smoke alarm designed to provide you with early warning of a fire. Please take the time to read this manual and make the smoke alarm an integral part of your family's safety plan.

#### KEY FEATURES OF THE P1210 SMOKE ALARM:

**Photoelectric Sensing Technology:** Photoelectric Sensors are generally more sensitive than ionization sensors in detecting smoldering fires which commonly occur in couches or bedding.

**OptiPath 360 Technology™:** Patented technology provides 360° of direct access to the smoke sensor.

**Single Test/Silence Button:** Allows you to test the alarm or silence nuisance alarms. Testing the alarm assures you that the unit is functioning correctly and ready to protect you and your family.

The alarm can be silenced for up to 9 minutes in the event of a nuisance alarm.

**10-Year End of Life Indicator and Low Battery Warning:** The alarm will chirp once per minute indicating a Low Battery Warning, meaning the unit will need to be replaced soon. The alarm will sound 3 pulses every 43 seconds to alert that the batteries are dead and the unit needs to be replaced immediately.

**Latching Feature - Alarm Memory:** The alarm sensed smoke or fire, went off and pulled itself out of alarm mode.

To notify you of this event, the alarm will give 3 quick flashes every 45 seconds for 24 hours. You can stop it by pressing the test/silence button. After 24 hours, it will pull itself out of the latch mode and no longer flash.

**Low Battery Silence:** The alarm can be silenced for 8 hours.

L © 2018 BRK Brands, Inc. All rights reserved. Distributed by BRK Brands, Inc., BRK Brands, Inc. is a subsidiary of Novelis Inc. (NYSE:NWL) - 3901 Liberty Street, Aurora, IL 60504-8122. Customer Service Team: (800) 323-8005 - www.firstalert.com - www.brkelectronics.com

#### FOLLOW THESE SIMPLE STEPS

1. Hold the mounting bracket against the ceiling (or wall) so the two clusters of universal mounting holes are aligned approximately at the 9:00 and 3:00 o'clock positions. See image. Choose one of the three sets of holes shown, A, B or C (see image) and trace around one of the sets. Be sure to choose a top and bottom slot on opposite sides so you can rotate the universal mounting bracket into position later. This will make it easier in the future to remove the mounting bracket without completely removing the screws.

**WARNING!** Do not install this alarm over an existing electrical box. Only AC powered units are intended for installation over electrical boxes.

2. Put the unit where it won't get covered with dust when you drill the mounting holes.

3. Using a 3/16" (5 mm) drill bit, drill a hole through the center of the oval outlines you traced.

4. Insert the small screw anchors (in the plastic bag with screws) into the holes. Tap the screw anchors gently with a hammer, if necessary, until they are flush with the ceiling or wall.

5. Install the screws but do not tighten completely. Attach the mounting bracket by aligning the screws in the open portion of the universal mounting slots and rotating the bracket into place. Tighten the screws until they are snug to secure the bracket. Do not over tighten.

6. Activating the battery. Mount alarm to mounting bracket to activate. Once unit is activated, it cannot be turned off. Make sure the alarm is locked into the mounting bracket.

**NOTE:** After you activate the battery, the power indicator light may flash. (If the unit alarms, the light will blink rapidly, and the horn will repeatedly sound 3 beeps, pause, 3 beeps.) Once the smoke alarm is on the bracket, you can rotate the alarm to adjust the alignment.

7. Test the alarm. See "Weekly Testing."




#### TO PERMANENTLY DEACTIVATE THE SMOKE ALARM

8. After 10 years of operation or Low Battery Warning, deactivate the alarm: Insert a tool below edge where shown and break tab. Then slide activation switch to deactivate mode.

**NOTE:** At end of life or low battery indication (chirp) unit must be put into deactivation mode to deactivate remaining stored energy in battery. Unit will no longer function once put into this mode. Unit will resist re-mounting.

Installed on Replace by

#### MOUNTING HOLE SETS



#### INTRODUCTION (CONTINUED)...

**Red Blinking Power Indicator every 6 minutes:** Confirms that the smoke alarm is receiving power.

All First Alert® smoke alarms conform to regulatory requirements, including UL217 and are designed to detect particles of combustion. Smoke particles of varying number and size are produced in all fires.

**I** Ionization technology is generally more sensitive than photoelectric technology at detecting small particles, which tend to be produced in greater amounts by flaming fires, which consume combustible materials rapidly and spread quickly. Sources of these fires may include paper burning in a wastebasket, or a grease fire in the kitchen.

**P** Photoelectric technology is generally more sensitive than ionization technology at detecting large particles, which tend to be produced in greater amounts by smoldering fires, which may smolder for hours before bursting into flame. Sources of these fires may include cigarettes burning in couches or bedding.

For maximum protection, use both types of smoke alarms on each level and in every bedroom of your home.

#### BASIC SAFETY INFORMATION

##### WARNING!

- This unit will not alert hearing impaired residents. It is recommended that you install special units which use devices like flashing strobe lights to alert hearing impaired residents.
- Do not connect this unit to any other alarm or auxiliary device. It is a single-station unit that cannot be linked to other devices. Connecting anything else to this unit may prevent it from working properly.
- Unit will not operate without battery power. The smoke alarm cannot work until you activate the battery power pack.

##### CAUTION!

- Do not install this unit over an electrical junction box. Air currents around junction boxes can prevent smoke from reaching the sensing chamber and prevent the unit from alarming. Only AC powered units are intended for installation over junction boxes.
- Do not stand too close to the unit when the alarm is sounding. It is loud to wake you in an emergency. Exposure to the horn at close range may harm your hearing.
- Do not paint over the unit. Paint may clog the openings to the sensing chamber and prevent the unit from operating properly.

#### BEFORE YOU INSTALL THIS SMOKE ALARM

Important: Read "Recommended Locations for Smoke Alarms" and "Locations to Avoid for Smoke Alarms" before beginning. This unit monitors the air, and when smoke reaches its sensing chamber, it alarms. It can give you more time to escape before fire spreads. This unit can only give an early warning of developing fires if it is installed, maintained and located where smoke can reach it, and where all residents hear it as described in this manual. This unit will not sense gas, heat, or flame. It cannot prevent or extinguish fires.

Understand The Different Type of Smoke Alarms: Battery powered or electrical? Different smoke alarms provide different types of protection. See "About Smoke Alarms" for details.

Know Where To Install Your Smoke Alarms: Fire Safety Professionals recommend at least one smoke alarm on every level of your home, in every bedroom, and in every bedroom hallway or separate sleeping area. See "Recommended Locations for Smoke Alarms" and "Locations to Avoid for Smoke Alarms" for details.

Know What Smoke Alarms Can and Can't Do: A smoke alarm can help alert you to fire, giving you precious time to escape. It can only sound an alarm once smoke reaches the sensor. See "Limitations of Smoke Alarms" for details.

Check Your Local Building Codes: This smoke alarm is designed to be used in a typical single-family home. It alone will not meet requirements for boarding houses, apartment buildings, hotels or motels. See "Special Compliance Considerations" for details.

#### LOCATIONS TO AVOID FOR SMOKE ALARMS

FOR BEST PERFORMANCE, IT IS RECOMMENDED YOU INSTALL SMOKE ALARMS IN THESE AREAS:

- Where combustion particles are produced. Combustion particles form when something burns. Areas to avoid include poorly ventilated kitchens, garages, and furnace rooms. Keep units at least 20 feet (6 meters) from the sources of combustion particles (stove, furnace, water heater, space heater) if possible. In areas where a 20-foot (6-meter) distance is not possible – in modular, mobile, or smaller homes, for example – it is recommended the smoke alarm be placed as far from these fuel-burning sources as possible. The placement recommendations are intended to keep these alarms at a reasonable distance from a fuel-burning source, and thus reduce "unwanted" alarms. Unwanted alarms can occur if a smoke alarm is placed directly next to a fuel-burning source. Ventilate these areas as much as possible.
- In air streams near kitchens. Air currents can draw cooking smoke into the sensing chamber of a smoke alarm near the kitchen.
- In very damp, humid or steamy areas, or directly near bathrooms with showers. Keep units at least 10 feet (3 meters) away from showers, saunas, dishwashers, etc.
- Where temperatures are regularly below 40° F (4.4° C) or above 100° F (37.8° C), including unheated buildings, outdoor rooms, porches, or unfinished attics or basements.
- In very dusty, dirty, or greasy areas. Do not install a smoke alarm directly over the stove or range. Keep laundry room smoke alarms free of dust or lint.
- Near fresh averts, ceiling fans, or in very drafty areas. Drafts can blow smoke away from the unit, preventing it from reaching the sensing chamber.
- In insect infested areas. Insects can clog openings to the sensing chamber and cause unwanted alarms.
- Less than 12 inches (305mm) away from fluorescent lights. Electrical "noise" can interfere with the sensor.
- In "dead air" spaces. "Dead air" spaces may prevent smoke from reaching the smoke alarm.

#### LOCATIONS TO AVOID FOR SMOKE ALARMS (CONTINUED)...

##### AVOIDING DEAD AIR SPACES

"Dead air" spaces may prevent smoke from reaching the smoke alarm. To avoid dead air spaces, follow the installation recommendations below.

On ceilings, install smoke alarms as close to the center of the ceiling as possible. If this is not possible, install the smoke alarm at least 4 inches (102 mm) from the wall or corner.

For wall mounting (if allowed by building codes), the top edge of smoke alarms should be placed between 4 and 12 inches (102 and 305 mm) from the wall/ceiling line, below typical "dead air" spaces.

On a peaked, gabled, or cathedral ceiling, install the first smoke alarm within 3 feet (0.9 meters) of the peak of the ceiling, measured horizontally. Additional smoke alarms may be required depending on the length, angle, etc. of the ceiling's slope. Refer to NFPA 72 for details on requirements for sloped or peaked ceilings.

#### HOW TO INSTALL THIS SMOKE ALARM

This unit is designed to be mounted on the ceiling, or on the wall if necessary.

Tools you will need: pencil, drill with 3/16" (5 mm) drill bit, standard flathead screwdriver, hammer

##### THE PARTS OF THIS SMOKE ALARM

###### 1. Test/Silence button


2. Dual power indicator light and alarm indicator. Green LED provides visual indication of an alarm memory condition; Red LED provides visual indication of an alarm and hush modes

###### 1. Mounting bracket

###### 2. Mounting slots

###### 3. Turn this way to attach

###### 4. Turn this way to remove



#### OPTIONAL LOCKING FEATURE

The optional locking feature is designed to prevent unauthorized removal of the alarm. It is not necessary to activate the lock in single-family households where unauthorized alarm removal is not a concern.

</div

## IF THIS SMOKE ALARM SOUNDS

### RESPONDING TO AN ALARM

During an alarm, you will hear a loud, repeating horn pattern: 3 beeps, pause, 3 beeps, pause. The Red LED flashes rapidly.

### ⚠️ WARNING!

- If the unit alarms get everyone out of the house immediately.
- If the unit alarms and you are not testing the unit, it is warning you of a potentially dangerous situation that requires your immediate attention. NEVER ignore any alarm. Ignoring the alarm may result in injury or death.
- Never remove the batteries from a battery operated smoke alarm to stop an unwanted alarm (caused by cooking smoke, etc.). Removing batteries disables the alarm so it cannot sense smoke, and removes your protection. Instead open a window or fan the smoke away from the unit. The alarm will reset automatically.

### WHAT TO DO IN CASE OF FIRE

Don't panic; stay calm. Follow your family escape plan.

Get out of the house as quickly as possible. Don't stop to get dressed or collect anything.

Feel doors with the back of your hand before opening them. If a door is cool, open it slowly. Don't open a hot door. Keep doors and windows closed, unless you must escape through them.

Cover your nose and mouth with a cloth (preferably damp). Take short, shallow breaths.

Meet at your planned meeting place outside your home, and do a head count to make sure everybody got out safely.

Call the Fire Department as soon as possible from outside. Give your address, then your name.

Never go back inside a burning building for any reason.

Contact your Fire Department for ideas on making your home safer.

### ⚠️ WARNING!

Alarms have various limitations. See "Limitations of smoke alarms" for details.

### USING THE SILENCE FEATURE

The silence feature can temporarily quiet an unwanted alarm for up to 9 minutes. To use this feature, press the Test/Silence button on the cover. If the unit will not silence and no heavy smoke is present, or if it stays in silence mode continuously, it should be replaced immediately. The LED will flash every 10 seconds while in silence.

### ⚠️ WARNING!

The silence feature does not disable the unit—it makes it temporarily less sensitive to smoke. For your safety, if you move around the unit the dense enough to suggest a potentially dangerous situation, the unit will stay in alarm or may re-alarm quickly. If you do not know the source of the smoke, do not assume it is an unwanted alarm. Not responding to an alarm can result in property loss, injury, or death.

### SILENCING THE LOW BATTERY WARNING

This silence feature can temporarily quiet the Low Battery Warning "chirp". Press the Test/Silence button on the alarm. The Red light flashes normally, once every 6 minutes, during Low Battery Warning silence. After time, the low battery "chirp" will resume. Deactivate the smoke alarm and replace it immediately.

## IF YOU SUSPECT A PROBLEM

Smoke alarms may not operate properly because of a dead or weak battery, a build-up of dirt, dust or grease on the smoke alarm cover, or installation in an improper location. Clean the smoke alarm as described in "Regular Maintenance," and then test the smoke alarm again. If it fails to test properly when you use the test button, or if the problem persists, replace the smoke alarm immediately.

- If you hear a "chirp" about once a minute, replace the smoke alarm.
- If you experience frequent non-emergency alarms (like those caused by cooking smoke), try relocating the smoke alarm.
- If the alarm sounds when no smoke is visible, try cleaning or relocating the smoke alarm. The cover may be dirty.
- If the alarm does not sound during testing, make sure the power pack activating lever is pushed all the way securely.

### Do not try fixing the alarm yourself – this will void your warranty!

If the smoke alarm is still not operating properly, and it is still under warranty, please see "How to Obtain Warranty Service" in the Limited Warranty.

### RECOMMENDED LOCATIONS FOR SMOKE ALARMS

#### INSTALLING SMOKE ALARMS IN SINGLE-FAMILY RESIDENCES


The National Fire Protection Association (NFPA) recommends one smoke alarm on every level, in every sleeping area, and in every bedroom. In new construction, the smoke alarms must be AC powered and interconnected. See "Agency Placement Recommendations" for details. For additional coverage, it is recommended that you install a smoke alarm in all rooms, halls, storage areas, finished attics, and basements, where temperatures normally remain between 40° F (4.4° C) and 100° F (37.8° C). Make sure no door or other obstruction could keep smoke from reaching the smoke alarms.

#### MORE SPECIFICALLY, INSTALL SMOKE ALARMS:

- On every level of your home, including finished attics and basements.
- Inside every bedroom, especially if people sleep with doors closed.
- In the hall near every sleeping area. If your home has multiple sleeping areas, install a unit in each. If a hall is over 40 feet (12 meters) long, install an alarm at each end.
- At the top of the first-to-second level stairway, and at bottom of basement stairway.

## RECOMMENDED LOCATIONS FOR SMOKE ALARMS (CONTINUED)...

### RECOMMENDED PLACEMENT:



### IMPORTANT!

Specific requirements for smoke alarm installation vary from state to state and from region to region. Check with your local Fire Department for current requirements in your area. It is recommended AC or AC/DC units be interconnected for added protection.

#### MORE SPECIFICALLY, INSTALL SMOKE ALARMS:

- On every level of your home, including finished attics and basements.
- Inside every bedroom, especially if people sleep with doors closed.
- In the hall near every sleeping area. If your home has multiple sleeping areas, install a unit in each. If a hall is over 40 feet (12 meters) long, install an alarm at each end.
- At the top of the first-to-second level stairway, and at bottom of basement stairway.

### IMPORTANT!

Specific requirements for smoke alarm installation vary from state to state and from region to region. Check with your local Fire Department for current requirements in your area. It is recommended AC or AC/DC units be interconnected for added protection.

## AGENCY PLACEMENT RECOMMENDATIONS

NFPA 72 CHAPTER 29 "FOR YOUR INFORMATION, THE NATIONAL FIRE ALARM AND SIGNALING CODE, NFPA 72, READS AS FOLLOWS."

29.5.1 Required Detection. 29.5.1.1 Where required by other governing laws, codes, or standards for a specific type of occupancy, approved single and multi-station smoke alarms shall be installed as follows:

(1) In all sleeping rooms and guest room.

(2) Outside of each separate dwelling unit sleeping area, within 21 ft (6.4 m) of any door to a sleeping room, with the distance measured along a path of travel.

(3) On every level of a dwelling unit, including basements.

(4) On every level of a residential board and care occupancy (small facility), including basements and excluding crawl spaces and unfinished attics.

(5) In the living areas of a guest suite.

(6) In the living areas of a residential board and care occupancy (small facility).

(Reprinted with permission from NFPA 72®, National Fire Alarm and Signaling Code Copyright © 2010 National Fire Protection Association, Quincy, MA 02269. This reprinted material is not the complete and official position of the National Fire Protection Association, on the referenced subject which is represented only by the standard in its entirety. (National Fire Alarm and Signaling Code® and NFPA 72® are registered trademarks of the National Fire Protection Association, Inc., Quincy, MA 02269.)

### CALIFORNIA STATE FIRE MARSHAL (CSFM)

Early warning detection is best achieved by the installation of fire detection equipment in all rooms and areas of the household as follows: A smoke alarm installed in each separate sleeping area in the vicinity, but outside bedrooms, and Heat or smoke alarms in the living rooms, dining rooms, bedrooms, kitchens, hallways, finished attics, furnace rooms, closets, utility and storage rooms, basements, and attached garages.

### LIMITED WARRANTY

BRK Brands, Inc. ("BRK") the maker of First Alert® brand products warrants that for a period of ten years from the date of purchase, this product will be free from defects in material and workmanship. BRK, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. BRK dealers, service centers, or retail stores selling BRK products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on an improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than BRK or an authorized service center. Further, the warranty does not cover acts of God, such as fire, flood, hurricanes and tornadoes or any battery that is included with this unit.

BRK may provide an implied warranty of merchantability or fitness for a particular purpose. Some states or provinces do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

### HOW TO OBTAIN WARRANTY SERVICE

Service: If service is required, do not return the product to your retailer. In order to obtain warranty service, contact the Customer Service Team at 1-800-323-9005. To assist us in serving you, please have the model number and date of purchase available when calling.

### For Warranty Service return to: BRK Brands, Inc., 1301 Joe Battle, El Paso, TX 79936

Disposal: Waste electrical products should not be disposed of with regular household waste. Please recycle where facilities exist. Check local requirements for disposal of Li-ion electronic devices.

The alarm should be deactivated before disposal. See, "To Permanently Deactivate the Smoke Alarm".

You can also return your alarm to us for disposal. For return address see above. Please include a note confirming the product is being returned for disposal.

Visit [www.firstalert.com](http://www.firstalert.com) for more information.

### For your records, please record:

Date Purchased: \_\_\_\_\_

The alarm will also provide an audible End-of-Life Signal approximately 10 years after installation to remind you to replace the unit.

Where Purchased: \_\_\_\_\_

The End-of-Life Signal can be silenced for up to 2 days. Do not unplug or deactivate the alarm until you get replacement.

Date Installed: \_\_\_\_\_ / \_\_\_\_\_ Month/Year

Replace alarm 10 years after installation.

Please write the date in the space provided: \_\_\_\_\_ / \_\_\_\_\_ Month/Year

## IF THIS SMOKE ALARM SOUNDS

### RESPONDING TO AN ALARM

During an alarm, you will hear a loud, repeating horn pattern: 3 beeps, pause, 3 beeps, pause. The Red LED flashes rapidly.

### ⚠️ WARNING!

If the unit alarms get everyone out of the house immediately.

- If the unit alarms and you are not testing the unit, it is warning you of a potentially dangerous situation that requires your immediate attention. NEVER ignore any alarm. Ignoring the alarm may result in injury or death.
- Never remove the batteries from a battery operated smoke alarm to stop an unwanted alarm (caused by cooking smoke, etc.). Removing batteries disables the alarm so it cannot sense smoke, and removes your protection. Instead open a window or fan the smoke away from the unit. The alarm will reset automatically.

### WHAT TO DO IN CASE OF FIRE

Don't panic; stay calm. Follow your family escape plan.

Get out of the house as quickly as possible. Don't stop to get dressed or collect anything.

Feel doors with the back of your hand before opening them. If a door is cool, open it slowly. Don't open a hot door. Keep doors and windows closed, unless you must escape through them.

Cover your nose and mouth with a cloth (preferably damp). Take short, shallow breaths.

Meet at your planned meeting place outside your home, and do a head count to make sure everybody got out safely.

Call the Fire Department as soon as possible from outside. Give your address, then your name.

Never go back inside a burning building for any reason.

Contact your Fire Department for ideas on making your home safer.

### ⚠️ WARNING!

Alarms have various limitations. See "Limitations of smoke alarms" for details.

### USING THE SILENCE FEATURE

The silence feature can temporarily quiet an unwanted alarm for up to 9 minutes. To use this feature, press the Test/Silence button on the cover. If the unit will not silence and no heavy smoke is present, or if it stays in silence mode continuously, it should be replaced immediately. The LED will flash every 10 seconds while in silence.

### ⚠️ WARNING!

The silence feature does not disable the unit—it makes it temporarily less sensitive to smoke. For your safety, if you move around the unit the dense enough to suggest a potentially dangerous situation, the unit will stay in alarm or may re-alarm quickly. If you do not know the source of the smoke, do not assume it is an unwanted alarm. Not responding to an alarm can result in property loss, injury, or death.

### SILENCING THE LOW BATTERY WARNING

This silence feature can temporarily quiet the Low Battery Warning "chirp". Press the Test/Silence button on the alarm. The Red light flashes normally, once every 6 minutes, during Low Battery Warning silence. After time, the low battery "chirp" will resume. Deactivate the smoke alarm and replace it immediately.

## IF YOU SUSPECT A PROBLEM

Smoke alarms may not operate properly because of a dead or weak battery, a build-up of dirt, dust or grease on the smoke alarm cover, or installation in an improper location. Clean the smoke alarm as described in "Regular Maintenance," and then test the smoke alarm again. If it fails to test properly when you use the test button, or if the problem persists, replace the smoke alarm immediately.

- If you hear a "chirp" about once a minute, replace the smoke alarm.
- If you experience frequent non-emergency alarms (like those caused by cooking smoke), try relocating the smoke alarm.
- If the alarm sounds when no smoke is visible, try cleaning or relocating the smoke alarm. The cover may be dirty.
- If the alarm does not sound during testing, make sure the power pack activating lever is pushed all the way securely.

### Do not try fixing the alarm yourself – this will void your warranty!

If the smoke alarm is still not operating properly, and it is still under warranty, please see "How to Obtain Warranty Service" in the Limited Warranty.

### RECOMMENDED LOCATIONS FOR SMOKE ALARMS

#### INSTALLING SMOKE ALARMS IN SINGLE-FAMILY RESIDENCES


The National Fire Protection Association (NFPA) recommends one smoke alarm on every level, in every sleeping area, and in every bedroom. In new construction, the smoke alarms must be AC powered and interconnected. See "Agency Placement Recommendations" for details. For additional coverage, it is recommended that you install a smoke alarm in all rooms, halls, storage areas, finished attics, and basements, where temperatures normally remain between 40° F (4.4° C) and 100° F (37.8° C). Make sure no door or other obstruction could keep smoke from reaching the smoke alarms.

#### MORE SPECIFICALLY, INSTALL SMOKE ALARMS:

- On every level of your home, including finished attics and basements.
- Inside every bedroom, especially if people sleep with doors closed.
- In the hall near every sleeping area. If your home has multiple sleeping areas, install a unit in each. If a hall is over 40 feet (12 meters) long, install an alarm at each end.
- At the top of the first-to-second level stairway, and at bottom of basement stairway.

## RECOMMENDED LOCATIONS FOR SMOKE ALARMS (CONTINUED)...

### RECOMMENDED PLACEMENT:



### IMPORTANT!

Specific requirements for smoke alarm installation vary from state to state and from region to region. Check with your local Fire Department for current requirements in your area. It is recommended AC or AC/DC units be interconnected for added protection.

## SPECIAL COMPLIANCE CONSIDERATIONS

This smoke alarm is suitable for use in apartments, condominiums, townhouses, hospitals, day care facilities, health care facilities, boarding houses, group homes and dormitories provided a primary fire detection system already exists to meet fire detection requirements in common areas like lobbies, hallways, or porches. Using this smoke alarm in common areas may not provide sufficient warning to all residents or meet local fire protection ordinances/regulations.

This smoke alarm alone is not a suitable substitute for complete fire detection systems in places housing many people—like apartment buildings, condominiums, hotels, motels, dormitories, hospitals, health care facilities, nursing homes, day care facilities or group homes of any kind. It is not a suitable substitute for complete fire detection systems in warehouses, industrial facilities, commercial buildings, and special-purpose non-residential buildings which require special fire detection and alarm systems. Depending on the building codes in your area, this smoke alarm may be used to provide additional protection in these facilities.

In new construction, most building codes require the use of AC or AC/DC powered smoke