



General Monitors

by MSA

MODEL MC600

Multi-Channel Controller
for Hydrocarbon, H₂S and Toxic
Gas Monitoring Applications



The information and technical data disclosed in this document may be used and disseminated only for the purposes and to the extent specifically authorized in writing by General Monitors.

Instruction Manual

12-15

General Monitors reserves the right to change published specifications and designs without prior notice.

**Part No.
Revision**

**MANMC600
T/12-15**

Warranty

General Monitors warrants the Model MC600 to be free from defects in workmanship or material under normal use and service within two (2) years from the date of shipment.

General Monitors will repair or replace without charge any such defective equipment found to be deficient during the warranty period. General Monitors' personnel will make full determination of the nature of and responsibility for, defective equipment.

Defective or damaged equipment must be shipped prepaid to General Monitors' plant or representative from which shipment was made. In all cases, this warranty is limited to the cost of equipment supplied by General Monitors. The customer will assume all liability for the misuse of this equipment by its employees or other personnel.

NOTE: The Model MC600 Multi-Channel Controller System is easy to install; however, this manual should be read and understood before attempting to install or operate the device.

All warranties are contingent upon proper use in the application for which the product was intended and do not cover products which have been modified or repaired without General Monitors' approval, or which have been subjected to neglect, accident, improper installation or application, or on which the original identification marks have been removed or altered.

Except for the express warranty stated above, General Monitors disclaims all warranties with regard to the products sold, including all implied warranties of merchantability and fitness and the express warranty stated herein are in lieu of all obligations or liabilities on the part of General Monitors for damages including, but not limited to, consequential damages arising out of, or in connection with, the use or performance of the product.

Warnings

This instruction manual includes numerous cautions and warnings that are included to prevent injury to technicians who are handling the equipment and to prevent damage to your detection system.



WARNING: TOXIC, COMBUSTIBLE AND FLAMMABLE GASES AND VAPORS ARE VERY DANGEROUS. USE EXTREME CAUTION WHEN THESE HAZARDS ARE PRESENT.



WARNING: HYDROGEN SULFIDE (H₂S) IS AN EXTREMELY TOXIC GAS AND EXPOSURE MAY RESULT IN A LOSS OF CONSCIOUSNESS OR DEATH.

System Integrity Verification

General Monitors' mission is to benefit society by providing solutions through industry-leading safety products, services, and systems that save lives and protect capital resources from the dangers of hazardous flames, gases, and vapors.

The safety products you have purchased should be handled carefully and installed, calibrated, and maintained in accordance with their product instruction manuals. Remember, these products are for your safety.

To ensure operation at optimum performance, General Monitors recommends that certain preventive startup and maintenance tasks be performed.

Commissioning Safety Systems

Before power up, verify wiring, terminal connection, and stability of mounting for all integral safety equipment including, but not limited to:

- Power Supplies
- Control Modules
- Field detection devices
- Signaling/output devices
- Accessories connected to field and signaling devices

After the initial application of power (and any factor-specified warm-up period) to the safety system, verify that all signal outputs to and from devices and modules are within the manufacturer's specifications. Initial calibration, calibration checking and testing should be performed per the manufacturer's recommendations and instructions.

Proper system operation should be verified by performing a full, functional test of all component devices of the safety system, ensuring that the proper levels of alarming occur.

Fault/Malfunction circuit operation should be verified.

Periodic Testing/Calibration of Field Devices

Periodic testing/calibrating should be performed per the manufacturer's recommendations and instructions. Testing/Calibration procedures should include, but not be limited to:

- Verify zero reading
- Apply a known concentration of gas, or simulated test device provided by the manufacturer
- Verify integrity of all optical surfaces and devices

When testing produces results outside of the manufacturers' specifications, recalibration or repair/replacement of the suspect device(s) should be performed as necessary. Calibration intervals should be independently established through a documented procedure, including a calibration log maintained by plant personnel or third party testing services.

Periodic System Verification

The following system verifications should be performed at least annually:

Verify wiring, terminal connections and stability of mounting for all integral safety equipment, including, but not limited to:

- Power supplies
- Control modules
- Field detection devices
- Signaling/output devices
- Accessories connected to field and signaling devices

Proper system operation should be verified by performing a full, functional test of all component devices of the safety system, ensuring that the proper levels of alarming occur.

Fault/Malfunction circuit operation should be verified. In addition, calibration intervals should be independently established through a documented procedure, including a calibration log maintained by plant personnel or third party testing services.

About This Manual

This manual provides instructions for installing and operating the Model MC600 Multi-Channel Controller. Maintenance and specification information is also provided, as well as, programming information for the MODBUS registers. The intended audience includes field service technicians, MODBUS programmers and other technical staff involved in installing and using an MC600 system.

Format Conventions

Several format conventions are used throughout the book for notes and cautions, warnings, as well as, MODBUS notations.

Notes, Cautions and Warnings

NOTE: Notes provide supplementary details such as, exception conditions, alternate methods for a task, time saving tips and references to related information.



CAUTION: Cautions describe precautions to prevent damage to equipment.



WARNING: Warnings describe precautions to prevent serious injury to people working with equipment.

MC600 Menu Formats

- Menu keywords and LCD digital display messages are shown in bold, e.g. **Cal Fault**.
- MC600 navigation buttons are shown in text paragraphs formatted in bold, surrounded by square brackets, e.g. **[ACCEPT]** or **[MODE]**

MODBUS Register Formats

Hexadecimal numbers are indicated by a trailing lowercase “h”, such as, 000Eh.

Other Sources of Help

Extensive documentation, white papers and product literature for our complete line of safety products can be found at <http://www.MSAafety.com/detection>

Related Documentation

The detection instruments that you connect to the MC600 each have their own documentation and you will need to refer to the instruction manual for each instrument in order to calibrate and maintain the instrument. A list of the manuals for the MC600-compatible detection instruments follows:

- *Model TS400 Instruction Manual, part number MANTS400*
- *Model TS420 Instruction Manual, part number MANTS420*
- *Model TS4000 Instruction Manual; part number MANTS4000*
- *Model TS4000H Instruction Manual; part number MANTS4000H*
- *Model IR400 Instruction Manual, part number MANIR400*
- *Model IR700 Instruction Manual, part number MANIR700*
- *Model IR2100 Instruction Manual, part number MANIR2100*
- *Model IR5000 Instruction Manual, part number MANIR5000*
- *Model IR5500 Instruction Manual, part number MANIR5500*
- *Model IR7000 Instruction Manual, part number MANIR7000*
- *Model S4000C Instruction Manual, part number MANS4000C*
- *Model S4000CH Instruction Manual, part number MANS4000CH*
- *Model S4000T Instruction Manual, part number MANS4000T*
- *Model S4000TH Instruction Manual, part number MANS4000TH*
- *Model S4100C Instruction Manual, part number MANS4100C*
- *Model S4100T Instruction Manual, part number MANS4100T*
- *Model S214 Instruction Manual, part number MANS214*
- *Model S216A Instruction Manual, part number MANS216A*
- *Model S104 Instruction Manual, part number MANS104*
- *Model S106A Instruction Manual, part number MANS106A*
- *Observer Instruction Manual*
- *Observer-H Instruction Manual, part number MANOBSERVER-H*
- *Surveyor Instruction Manual, part number BB6019*

Contacting Customer Support

For additional product information not contained in this manual, please contact General Monitors Customer Support; refer to Section 6.0 for contact information.

1.0 Quick Start Installation Instructions

The main steps in a typical MC600 installation are listed below. There is some variation in the installation process at each site, depending on the exact site configuration.

Installation Step	Refer to Section
1. Unpack the equipment and prepare for the installation.	Section 1.1, 1.2
2. Mount the MC600 cabinet in place	Section 1.3
3. Mounting sensors and instruments	Section 1.4
4. Connecting sensors and instruments to the MC600	Section 1.5
5. Connecting MODBUS, HART, and relay devices from instruments to MC600	Section 1.6, 1.7, 1.8
6. Connect the MC600 cabinet to an external power supply if necessary, and then power on the MC600 system	Section 1.9

Table 1: MC600 Installation Overview

1.1 Unpacking the MC600 Equipment

Please keep the following precautions in mind when you unpack and install the MC600 cabinet and cabling.

- Installation and maintenance must be carried out by suitably, skilled and competent personnel only.
- Contact with the PCB components should be avoided in order to prevent damage from static electricity to equipment and personnel. Special care must be taken to wear grounding apparel and to ensure that only the connection points are touched whenever you are handling or installing the MC600.
- Each MOS H₂S sensor is shipped with a red plastic cap fitted over the sensor head. Inside the cap is a desiccant. **DO NOT** remove this cap until you are ready to power the system. **SAVE** the cap and **RE-CAP** the sensor anytime the system power is off for more than one hour.

All equipment shipped by General Monitors is packaged in shock absorbing containers, which provide considerable protection against physical damage. The contents should be carefully removed and checked against the packing list.

If any damage has occurred or there is any discrepancy in the order, please notify General Monitors as soon as possible. All subsequent correspondence with General Monitors must specify the equipment part number and the serial number.

NOTE: Each Model MC600 is thoroughly tested at the factory. However, a system checkout is required upon initial start-up to ensure system integrity.

1.2 Preparing for the Installation

To prepare installing the MC600 cabinet, you will need to choose a location and gather the required tools. Separate preparation guidelines for mounting sensors are provided in Section 1.5

1.2.1 Choosing a Location

The MC600 cabinet should be wall-mounted in a non-hazardous area. It can be placed indoors or outdoors. You will need to select a location for the MC600 that is near enough to the field-mounted devices to conform to the maximum cable lengths specified for the field-mounted device.

NOTE: If a Class I Division 2 power supply is used, the cabinet can be mounted in a hazardous Class I Division 2 area.

There must be adequate clearance beneath the MC600 cabinet to allow for cable installation. Weather-protected locations with minimal shock and vibration are preferred. Although the MC600 is largely immune to electromagnetic interference (EMI), it should not be mounted in close proximity to radio transmitters or similar equipment. The MC600 is provided with two ferrite clamps for use on the power supply cable in case any interference is observed. Before installation, carefully review the **Environmental Specifications** in Section 10.3 for allowable temperature ranges and the **Electrical Specifications** in Section 10.4 for power supply requirements.

1.2.2 Tools You Will Need

The following tools will be needed to install and cable the MC600:

- Flat-head screwdriver maximum 3/16" (5 mm) width for terminal block connections (included with unit)
- Adjustable wrench for conduit or cable gland connections (not included)
- #2 Phillips-head screwdriver (not included)

1.3 Mounting the MC600 Cabinet in Place




Figure 1: Mounting Dimensions for the MC600 Cabinet

Before bolting the cabinet in place, make sure it is level. Fasten four ¼-inch bolts into the four mounting holes on the corners of the enclosure. Use appropriate mounting screws/bolts in regard to the mounting surface i.e. concrete, wood, etc. Do not mount the MC600 onto drywall unless it is secured to the wooden studs behind the drywall.

1.4 Mounting the Sensors and Instruments

The catalytic HC sensors, MOS H₂S sensors and 4-20mA instruments, which will be connected to the MC600, must be mounted in locations where they are needed for gas detection. This can take place either before or after the MC600 cabinet is mounted in place. For detailed guidelines on selecting catalytic HC and MOS H₂S sensor locations, refer to Section 3.5.1.

1.4.1 Mounting Sensors with General Monitors' Accessories

Section 11.0 provides ordering information for several accessories for sensor mounting, such as explosion-proof junction boxes, duct mounting kits, splashguards, dust guards and remote calibration devices. Instructions for mounting each type of 4-20mA instrument are provided in the instruction manual for the instrument. For detailed guidelines on installing a sensor with a junction box or duct mounting kit, refer to the following sections:

- Mounting a Sensor with a GM Junction Box (Section 3.5.3)
- Mounting a Sensor with a Duct Mounting Kit (Section 3.5.4)

1.4.2 Applying Sealants to Conduit Entries

Please keep the following warning in mind when installing housings and cabling from catalytic HC and MOS H₂S sensors and 4-20mA instruments in hazardous areas. Make sure that the equipment maintains the appropriate seals for a Class I hazardous location.



WARNING: Each conduit run within a hazardous location (and from a hazardous to a non-hazardous location) must be sealed so that gases, vapors, and/or flames cannot pass beyond the seal. The purpose of seals in a Class I hazardous location is to prevent the passage of gases, vapors, or flames from one electrical installation to another through the conduit system. For information on Class I hazardous location seals, see NEC articles 501-5 and 500-3d.

NOTE: For additional warnings and cautions, refer to Section 3.6.1

1.5 Connecting Sensors and Instruments to the MC600

Once the MC600 cabinet is installed, you are ready to begin cabling from the signal conditioning cards in the MC600 cabinet slots to field-mounted catalytic HC sensors, MOS H₂S sensors and 4-20mA instruments. To install wiring from MOS H₂S and catalytic HC sensors or instruments to the MC600, the end of the wires that will be fastened to the MC600 signal card connector should be stripped to approximately 0.25 inches, as shown below.




Figure 2: Pre-stripping Wiring

1.5.1 Cabling Warnings and Cautions

Please review the following cautions before proceeding to install cabling. For information on non-hazardous location cabling to the MC600 cabinet, see NEC article 504. For information on Class I location seals for sensors mounted in hazardous areas, see NEC articles 501-5 and 500-3d



CAUTION: Under no circumstances should equipment be connected or disconnected when under power. This is contrary to hazardous area regulations and may also lead to serious damage to the equipment. Equipment damaged in this manner is not covered under warranty.



CAUTION: The MC600 Multi-Channel Controller System and field-mounted sensor devices contain components that can be damaged by static electricity. Special care must be taken when wiring the system to ensure that only the connection points are touched.

Removing or installing cards or field devices while power is applied may cause permanent damage.

1.5.2 Connecting a MOS H₂S Sensor to the MC600

NOTE: Only MOS H₂S sensors designed by General Monitors will work with the MC600. Any attempt to use a sensor that has not been designed by General Monitors will void the MC600 warranty.

Four-wire cabling is required to connect from the MOS H₂S signal-conditioning card to a field-mounted MOS H₂S sensor. The maximum cable lengths are indicated in Table 27; *MOS H₂S Sensor Cable Lengths*.

To connect to a MOS H₂S sensor:

1. Thread four-wire cabling from the MOS H₂S sensor into the MC600 cabinet through one of the conduit openings in the bottom of the cabinet.
2. Remove the connector from the MOS H₂S signal-conditioning card by loosening the two recessed screws that hold it in place and lift the connector forwards.
3. Loosen the five-wire receptacle screws on the bottom of the connector. Secure each wire from the field device into the connector receptacle and tighten the screw that holds it in place. Fasten the cabling shield in the far right receptacle.
4. Once the wires are secured in the connector, replace the connector on the card and tighten the connector mounting screws at each side.




Figure 3: MOS H₂S Connection

1.5.3 Connecting a Catalytic HC Sensor to the MC600

NOTE: Only catalytic HC sensors designed by General Monitors will work with the MC600. Any attempt to use a sensor that has not been designed by General Monitors will void the MC600 warranty.

Three-wire or four-wire cabling is used to connect from the catalytic HC signal-conditioning card to a field-mounted catalytic HC sensor. The maximum cable lengths are indicated in Table 26; *Catalytic HC Sensor Cable Lengths*.

To connect a catalytic HC sensor:

1. Thread cabling from the catalytic HC sensor into the MC600 cabinet through one of the conduit openings in the bottom of the cabinet.
2. Remove the connector from the catalytic HC signal-conditioning card by loosening the two recessed screws that hold it in place and lift the connector forwards
3. Loosen the wire receptacle screws. Then secure the red, black and white wires from the field device in the receptacles and tighten the screws to hold them in place. Fasten the cabling shield in the far right receptacle.
4. Once the wires are secured in the connector, replace the connector on the card and tighten the connector mounting screws at each side.




Figure 4: 4-20mA Instrument Connection

NOTE: If you have four-wire cabling, you can fasten the green wire into the empty second receptacle; however, no signal will be carried on this wire.

1.5.4 Connecting a 4-20mA Instrument to the MC600

Instruments with their own control circuitry, such as the, S4000 Series, S4100 Series, IR2100, Observer and Surveyor - are connected to the MC600 through a 4-20mA signal-conditioning card.

To connect a 4-20mA instrument:

1. Thread four-wire cabling from the instrument into the MC600 cabinet through one of the conduit openings in the bottom of the cabinet. The maximum cable lengths are indicated in the manuals for each device.
2. Remove the connector from the 4-20mA signal-conditioning card by loosening the two recessed screws that hold it in place and lift the connector forwards.
3. Loosen the five-wire receptacle screws, then secure each wire from the field device into the connector receptacle and tighten the screws that hold them in place. Fasten the cabling shield to the rightmost receptacle.
 - The *Analog Out* signal from the detection instrument must be routed to the *Analog In* receptacle on the signal-conditioning card connector.

NOTE: When the field instrument is an IR5000/IR5500, there are two Analog Out signals from the field instrument. Connect them to the Analog In receptacles of any two channels of the MC600 system.

- *COM (DC Ground)* must also be connected from the field device to the MC600 signal-conditioning card connector.
 - Connect the *+24VDC* signal wire from the detection instrument to the second connector receptacle, if the MC600 power supply is to be used to provide power to that instrument. If you choose to connect the instrument to a separate power supply other than the MC600, do not connect the *+24VDC* power signal wire.
 - The *Analog Out* receptacle on the signal-conditioning card connector is provided to forward the 4-20mA input from the field instrument on to another monitoring device, such as a PLC. Ground must also be connected to this device.
4. Once the wires are secured in the connector, replace the connector on the card and tighten the connector mounting screws at each side.




Figure 5: Cabling Shield

NOTE: For some 4-20mA instruments, the MC600 message **Fld Dev Fault** will appear while the instrument is in start-up mode. Refer to the instrument documentation for information on the start-up process.



CAUTION: The MC600 Multi-Channel Controller System cannot provide sufficient power for an IR5000/IR5500 field instrument. When an IR5000/IR5500 is being connected to the MC600, the user should provide their own 24V power supply for the IR5000/IR5500 source and receiver units, as outlined in the IR5000/IR5500 manual. **Do not use the +24V DC signal connection from the MC600 signal-conditioning card, or damage to the system may occur.**

1.6 Connecting a MODBUS Device

Connector J8 near the bottom left side of the main MC600 controller (Figure 8) is provided for connecting the two MC600 MODBUS channels to control room MODBUS devices. Refer to the manual for the field device to determine maximum cable lengths.

1.7 Connecting a HART Field Device

A HART field device like the IR400, S4000CH, S4000TH, IR5500 and TS4000H can only operate with the MC600 through analog current communication. In order to make the full range of analog signal available to the MC600, the field devices must have HART disabled. Please consult the instruction manual of the field device on disabling the bi-directional communication.



WARNING: Field devices equipped with HART must have the HART function disabled to work properly with the MC600. If the devices are not disabled, the multi-point controller will not recognize fault conditions from HART.

1.8 Connecting Alarm Relay Devices

Connectors J10 and J11 at the bottom of the MC600 main PCB (Figure 8) connect Relays 1 to 6 to alarm devices, such as, sirens and bells. The functioning of the Alarm and Warning relay connections varies depending on whether the relays are configured as energized or de-energized, latching, non-latching or Timed.




Figure 6: MC600 MODBUS & Alarm Relay Connectors

There are nine inputs in connectors J10 and J11 to connect to a relay, for total of 18 connections. Each input label indicates what it is used for.

- The first digit in the receptacle label represents the channel number, from 1 to 6
- The last digit in the receptacle label indicates the function of the receptacle.
- If the last digit is C, then the receptacle is for Relay Common.

- If the relays are set up as de-energized (the default), the last digit 1 is for normally closed and the last digit 2 is for normally open.
- If the relays are set up as energized, the last digit 1 is normally open and the last digit 2 is normally closed.

NOTE: Connector J12 (Figure 9) is connected to Fault relays. The Fault relay is normally energized. It will change state after power-up.

The default MC600 configuration setting for the Warning and Alarm relays is de-energized. Use Table 2 as a guide for determining the normally open (**NO**) and the normally closed (**NC**) contacts for the energized vs. de-energized setting.

NORMALLY ENERGIZED		NORMALLY DE-ENERGIZED	
J10	POS 1 – NO	J10	POS 1 – NC
	POS 2 – C		POS 2 – C
	POS 3 – NC		POS 3 – NO
	POS 4 – NO		POS 4 – NC
	POS 5 – C		POS 5 – C
	POS 6 – NC		POS 6 – NO
	POS 7 – NO		POS 7 – NC
	POS 8 – C		POS 8 – C
	POS 9 – NC		POS 9 – NO
J11	POS 1 – NO	J11	POS 1 – NC
	POS 2 – C		POS 2 – C
	POS 3 – NC		POS 3 – NO
	POS 4 – NO		POS 4 – NC
	POS 5 – C		POS 5 – C
	POS 6 – NC		POS 6 – NO
○	POS 7 – NO		POS 7 – NC
	POS 8 – C		POS 8 – C
	POS 9 – NC		POS 9 – NO

Table 2: Normally Open and Closed Relays



WARNING: Relay contacts must be protected against transient and over-voltage conditions (Figure 27).

1.9 Connecting Power and Starting Operation

Once the mounting, cabling, and alarm relay installation is complete, the MC600 Multi-Channel Controller System is ready to begin the power-on sequence. Please review this section carefully before powering on the system.

1.9.1 Start-up Readiness Checklist

Prior to applying power to the system for the first time, check the following items:

- Verify that all signal wiring (except for +24V) is installed correctly.
- Verify that the MC600 cabinet is properly mounted. Make sure that the conduit/cable entries are securely installed.
- Make sure to inhibit any external devices, such as, Trip Amplifiers, PLC devices or DCS systems until after the start-up sequence has completed.

NOTE: The +24V wire(s) to the power supply (supplies) should be connected after the readiness checklist is verified to protect the system from shorting.

NOTE: The SHIELD terminal of J9 should be connected to an earth ground.

1.9.2 Connecting the MC600 to a Power Supply



WARNING: The MC600 power supply or connected external power supply should be left **OFF** and unconnected to its power source until after you have completed cabling connections.

If you have ordered a power supply pre-installed for the MC600, the unit will be shipped with cabling from the power supply to the control board pre-installed. You will only need to connect the onboard power supply to a 115/230 VAC power source. Two ferrite beads are supplied. They should be installed on the AC cord.




Figure 7: MC600 Connections to an Onboard Power Supply

To connect the MC600 onboard power supply to a power source:

Refer to Figure 9 as you follow these steps.

1. Verify the voltage switch on the power supply is set appropriately for you site's AC power connection, either 115VAC or 230VAC.
2. Connect cabling from the connector beneath the power supply to the power supply's external power source. Three wires will be needed to carry AC line, AC neutral and frame ground to the power source. Make sure the two ferrite beads are installed on the AC cord.




Figure 8: Onboard Class I Division 2 Power Supply

To connect the MC600 onboard Class I Division 2 power supply to a power source:

Refer to Figure 10 when following these steps

3. Connect cabling from the connector beneath the power supply to the power supply's external power source. Three wires will be needed to carry the AC line AC neutral, and frame ground to the power source. . Make sure the two ferrite beads are installed on the AC cord.

NOTE: This is 100VAC – 240VAC/50Hz-60Hz auto-switching power supply, you do not need to select the input voltage.

To connect the MC600 to an external power source:

If the MC600 does not have an onboard power supply, you will need to install cabling form the MC600 J9 connector to an external primary DC power supply (Figure 11). See Table 26 for cable length specifications.

Refer to your power supply manual for the location of the ground and +24VDC terminals and connections from the external power supply to a power source.




Figure 9: MC600 Connections to an External Power Supply

Refer to Figure 11 when following these steps

1. Connect a wire from the MC600 J9 connector COM receptacle to the power supply DC Ground connector.
2. Connect the MC600 J9 connector +24VDC receptacle to the power supply +24VDC terminal
3. The Model MC600 operates on nominal power of +24VDC. When you are ready to power on the MC600, connect the external power supply to a power source. Refer to your power supply manual for instructions on connecting it to a power supply.

1.9.3 Startup Process for an MC600 System

Upon power-up, the MC600 only requires a few minutes to stabilize while the unit attains proper operation. The six MC600 channel LCDs will go through the following process during this period:

1. The LCD segments for all six channels remain lit for two seconds. The four LEDs for READY, ALARM, FAULT and WARN also remain lit during this period.
2. Next, Channel 1 will display the part number and firmware revision for the MC600 control card and Channel 2 will display the part number and firmware revision for the LCD panel.
3. Each channel that has a signal-conditioning card installed and a sensor or instrument connected should go into Operation Mode, with gas measurement data shown.

The Operation Mode display is different for different sensors and instruments, as follows:

- **Catalytic HC Sensor:** The LCD display for each channel with a catalytic HC sensor will go through a 50-second long startup cycle countdown, followed by an Operation Mode display similar to the following (“Comb” stands for combustible)

0% LEL
Comb

- **MOS H₂S Sensor:** The Operation Mode display appears in the following format, assuming that no gas is currently detected:

0 ppm
H₂S

- **4-20mA Instrument:** The Operation Mode display may appear in one of several formats, depending on the instrument that is connected to it. Example the Observer display:

<58 dB
Obser

NOTE: Powering ON and OFF of the MC600 is controlled from the power supply and/or power source. If there are any problems in the start-up or testing of the MC600 system, please refer to Section 8.0 or contact General Monitors Technical Support (Section 6.0).

1.9.3.1 MC600 Startup Operation and Configuration Tasks

Once the MC600 is powered ON and in Operation Mode, the following tasks will need to be completed using the MC600 onboard menus:

1. Configure the display setup, as described in Section 3.10
2. Calibrate all connected catalytic HC and MOS H₂S sensors (Section 4.5).
 - For each catalytic HC sensor connected to the MC600, General Monitors recommends that you calibrate the sensor one hour after a first time system start-up.

- For each MOS H₂S sensor connected to the MC600, General Monitors recommends that you calibrate the sensor one hour after start-up and again 24 hours later.
3. Recalibrate the LCD channel display for 4-20mA signal-conditioning cards (Section 4.6).
 4. Configure the Alarm and Warning relay set points, as needed (Section 4.9.1).
 5. Configure the relays, as needed, for energized versus de-energized, latching versus non-latching or timed (Section 4.9.3).

NOTE: For general instructions on navigating the MC600 menu system, see Section 4.1.

Table of Contents

WARRANTY	II
WARNINGS	II
SYSTEM INTEGRITY VERIFICATION.....	III
Commissioning Safety Systems	iii
Periodic Testing/Calibration of Field Devices	iii
Periodic System Verification	iv
ABOUT THIS MANUAL	V
Format Conventions	v
Notes, Cautions and Warnings	v
MC600 Menu Formats	v
MODBUS Register Formats.....	v
Other Sources of Help.....	v
Related Documentation	vi
Contacting Customer Support.....	vi
1.0 QUICK START INSTALLATION INSTRUCTIONS.....	VII
1.1 Unpacking the MC600 Equipment	vii
1.2 Preparing for the Installation	viii
1.2.1 Choosing a Location	viii
1.2.2 Tools You Will Need	viii
Mounting the MC600 Cabinet in Place	ix
1.3	ix
1.4 Mounting the Sensors and Instruments	ix
1.4.1 Mounting Sensors with General Monitors' Accessories.....	x
1.4.2 Applying Sealants to Conduit Entries	x
1.5 Connecting Sensors and Instruments to the MC600	x
1.5.1 Cabling Warnings and Cautions	x
1.5.2 Connecting a MOS H ₂ S Sensor to the MC600	xi
1.5.3 Connecting a Catalytic HC Sensor to the MC600.....	xi
1.5.4 Connecting a 4-20mA Instrument to the MC600	xii
1.6 Connecting a MODBUS Device	xiv
1.7 Connecting a HART Field Device	xiv
1.8 Connecting Alarm Relay Devices	xiv
1.9 Connecting Power and Starting Operation	xv
1.9.1 Start-up Readiness Checklist.....	xv
1.9.2 Connecting the MC600 to a Power Supply	xvi
1.9.3 Startup Process for an MC600 System	xix
2.0 INTRODUCTION	1
2.1 Features and Benefits	3
2.2 Applications.....	3
3.0 INSTALLATION	4
3.1 Unpacking the MC600 Equipment	4

3.2	Preparing for the Installation	5
3.2.1	Choosing a Location	5
3.2.2	Tools You Will Need	5
3.3	Mounting the MC600 Cabinet in Place	6
3.4	Mounting the Sensors and Instruments	7
3.4.1	Sensor Location Considerations	7
3.4.2	Sensor Poisons	7
3.4.3	Mounting a Sensor with a GM Junction Box	8
3.4.4	Mounting a Sensor with a Duct Mounting Kit	9
3.4.5	Applying Sealants to Conduit Entries	9
3.5	Connecting Sensors and Instruments to the MC600	10
3.5.1	Warnings, Cautions and Standards	11
3.5.2	Connecting a MOS H ₂ S Sensor to the MC600	12
3.5.3	Connecting a Catalytic HC Sensor to the MC600	13
3.5.4	Connecting a 4-20mA Instrument to the MC600	14
3.6	Connecting a MODBUS Device	16
3.7	Connecting a HART Field Device	16
3.8	Connecting Alarm Relay Devices	16
3.9	Connecting Power and Starting Operation	18
3.9.1	Start-up Readiness Checklist	18
3.9.2	Connecting the MC600 to a Power Supply	19
3.9.3	Startup Process for an MC600 System	21
3.10	Configuring the Front Panel Setup	24
3.11	Maintaining the X/P Integrity	25
4.0	BASIC OPERATION AND CONFIGURATION	26
4.1	Entering and Exiting from the MC600 Menus	26
4.2	Using the Front Panel Navigation Buttons	27
4.3	Menu Flowchart Legend	27
4.4	MC600 Menu Overview	28
4.5	Calibrating Catalytic HC and MOS H ₂ S Sensors	29
4.5.1	Calibration Schedule	30
4.5.2	Preparing for Calibration	30
4.5.3	Sensor Calibration Equipment	30
4.5.4	Calibration Procedure for Catalytic HC and MOS H ₂ S Sensors	32
4.5.5	Stopping Sensor Calibration	33
4.6	Calibrating the LCD Display for 4-20mA Instruments	34
4.7	Checking Calibration for Sensors	35
4.8	Inhibiting Alarms for Selected Channels	37
4.9	Using the Basic Setup Menu Options	38
4.9.1	Configuring Alarm and Warning Set points	40
4.9.2	Configuring alarm delay time (ultrasonic products only)	45
4.9.3	Configuring a Calibration Point for Catalytic HC Sensors	46
4.9.4	Configuring the MC600 Relays	46
5.0	ADVANCED CONFIGURATION	49
5.1	Using the Advanced Setup Menu Options	50
5.1.1	Selecting a Model Option	50
5.1.2	Selecting the Channel Mode for the Alarm and Warning Indicators	53
5.1.3	Configuring Zoning (for Relay Allocation)	54
5.1.4	Configuring Horn Relay	59

5.1.5	Configuring Card Tests	59
5.1.6	Configuring Setup and Inhibit Passwords	60
5.1.7	Configuring the Fault Relays.....	62
5.1.8	Configuring MODBUS Parameters	63
5.1.9	Loading Default Settings	64
5.2	Using the Setup Check Menu	65
5.3	Using the Self Test Menu.....	67
6.0 CUSTOMER SUPPORT.....		68
7.0 MAINTENANCE.....		69
7.1	Developing a Maintenance Schedule	69
7.2	Calibration and Calibration Checks.....	69
7.2.1	Alternate Calibration Equipment	69
7.3	Cleaning the MC600	72
7.4	Lubrication.....	72
7.5	Storage.....	72
8.0 TROUBLESHOOTING.....		73
8.1	MC600 Controller Error Codes and Remedies	73
8.1.1	CON FAIL/COMM	73
8.1.2	CON FAIL / EEPROM.....	73
8.1.3	CON FAIL / LOW LINE	73
8.1.4	CON FAIL / PROGRAM.....	73
8.1.5	CON FAIL / RAM.....	73
8.1.6	CON FAIL / DATA RAM.....	73
8.2	Channel Error Codes and Remedies.....	74
8.2.1	Setup Channel (Sensors and Instruments).....	74
8.2.2	Cal Channel (Sensors and Instruments).....	74
8.2.3	Cal Fault (Sensors and Instruments)	74
8.2.4	Card Removed (Sensors and Instruments)	74
8.2.5	Fld Dev Fault (Instruments Only)	74
8.2.6	Invalid Card (Sensors and Instruments)	75
8.2.7	Sensor Fault (Sensors Only).....	75
8.2.8	Field Device Offline:	75
9.0 MC600 MODBUS INTERFACE.....		76
9.1	General MODBUS Information	76
9.1.1	Serial Communication Settings.....	76
9.1.2	Function Codes Supported	76
9.1.3	MODBUS Read Protocol (Query/Response).....	77
9.1.4	MODBUS Write Command Protocol (Query/Response)	78
9.1.5	Exception Response Messages and Codes	79
9.2	MC600 MODBUS Registers Summary	80
9.3	MC600 MODBUS Register Details	85
9.3.1	MC600 Mode (0001h, Read-Only).....	85
9.3.2	Unit Error Status (0002h, Read-Only).....	85
9.3.3	Calibration and Calibration Check Mode Status (0003h, Read/Write)	85
9.3.4	Model Type (0004h, Read-Only).....	87
9.3.5	Control Card Firmware Revision (0005h, Read-Only)	87
9.3.6	LCD Card Firmware Revision (0006h, Read-Only)	87

9.3.7	Temperature (0007h, Read-Only).....	87
9.3.8	Maximum Temperature (0008h, Read-Only)	87
9.3.9	Minimum Temperature (0009h, Read-Only)	87
9.3.10	Accept/Reset (000Ah, Write-Only).....	87
9.3.11	MODBUS Channel 1 Address (000Fh, Read/Write).....	87
9.3.12	MODBUS Channel 1 Baud Rate (0010h, Read/Write)	88
9.3.13	MODBUS Channel 1 Data Format (0011h, Read/Write)	88
9.3.14	MODBUS Channel 2 Address (0012h, Read/Write)	88
9.3.15	MODBUS Channel 2 Data Format (0014h, Read/Write)	89
9.3.16	MODBUS Channel 1 Total Receive Errors (0020h, Read-Only)	89
9.3.17	MODBUS Channel 1 Address Errors (0021h, Read-Only)	89
9.3.18	MODBUS Channel 1 Function Code Errors (0022h, Read-Only).....	89
9.3.19	MODBUS Channel 1 Starting Address Errors (0023h, Read-Only)	89
9.3.20	MODBUS Channel 1 No. of Register Errors (0024h, Read-Only)	90
9.3.21	MODBUS Channel 1 RXD CRC Errors (0025h, Read-Only).....	90
9.3.22	MODBUS Channel 1 Byte Timing Errors (0026h, Read-Only)	90
9.3.23	MODBUS Channel 1 Framing Errors (0027h, Read-Only)	90
9.3.24	MODBUS Channel 1 Parity Errors (0028h, Read-Only)	90
9.3.25	MODBUS Channel 1 Noise Errors (0029h, Read-Only)	90
9.3.26	MODBUS Channel 1 SCI Interrupt Errors (002Ah, Read-Only)	90
9.3.27	MODBUS Channel 1 Clear MODBUS Errors (002Bh, Write-Only)	90
9.3.28	MODBUS Channel 2 Total Receive Errors (0030h, Read-Only)	90
9.3.29	MODBUS Channel 2 Address Errors (0031h, Read-Only)	91
9.3.30	MODBUS Channel 2 Function Code Errors (0032h, Read-Only).....	91
9.3.31	MODBUS Channel 2 Starting Address Errors (0033h, Read-Only)	91
9.3.32	MODBUS Channel 2 Number of Register Errors (0034h, Read-Only).....	91
9.3.33	MODBUS Channel 2 RXD CRC Errors (0035h, Read-Only).....	91
9.3.34	MODBUS Channel 2 Byte Timing Errors (0036h, Read-Only)	91
9.3.35	MODBUS Channel 2 Framing Errors (0037h, Read-Only)	91
9.3.36	MODBUS Channel 2 Parity Errors (0038h, Read-Only)	92
9.3.37	MODBUS Channel 2 Noise Errors (0039h, Read-Only)	92
9.3.38	MODBUS Channel 2 SCI Interrupt Errors (003Ah, Read-Only)	92
9.3.39	MODBUS Channel 2 Clear MODBUS Errors (003Bh, Write-Only)	92
9.3.40	Channel Mode (0040h for Channel 1, 0050h for Channel 2, etc.).....	92
9.3.41	Device Type (0041h for Channel 1, 0051h for Channel 2, etc.)	94
9.3.42	Sensor Full-scale (Read-Only, 0042h for Chan 1, 0052h for Chan 2, etc.).....	96
9.3.43	Sensor Value (Read-Only, 0043h for Chan 1, 0053h for Chan 2, etc.)	96
9.3.44	Alarm High Set point (Read/Write, 0044h for Chan 1, 0054h for Chan 2, etc.).....	97
9.3.45	Alarm Low Set point (Read/Write, 0045h for Chan 1, 0055h for Chan 2, etc.)	97
9.3.46	Warning Set point (Read/Write, 0046h for Chan. 1, 0056h for Chan. 2, etc.)	98
9.3.47	Alarm State (0047h for Chan 1, 0057h for Chan 2, etc.)	99
9.3.48	Sensor Life (0048h for Chan 1, 0058h for Chan 2, etc.).....	100
9.3.49	Calibration Point (0049h for Chan 1, 0059h for Chan 2, etc.)	100
9.3.50	Alarm Mode (004Ah for Chan 1, 005Ah for Chan 2, etc.).....	100
9.3.51	Alarm Delay Time (004Bh for Chan 1, 005Bh for Chan 2, etc.)	100
10.0	MC600 SPECIFICATIONS	101
10.1	System Specifications	101
10.1.1	MC600 System Unit	101
10.1.2	MC600 System Unit Continued.....	102
10.1.3	4-20mA GM Instrument Specifications	102
10.2	Mechanical Specifications.....	102

10.3	Environmental Specifications	105
10.4	Electrical Specifications	105
	10.4.1 Relay Ratings	106
	10.4.2 RS-485 Output	106
10.5	Approvals	106
11.0	SENSORS AND ACCESSORIES.....	107
11.1	Catalytic Bead Hydrocarbon (HC) Sensors	107
11.2	Catalytic HC Sensor Spare Parts and Accessories	108
	11.2.1 Catalytic HC Sensor Part Numbers	108
	11.2.2 Sensor Housing (Junction Box)	108
	11.2.3 Sensor Accessories	109
	11.2.4 Calibration Equipment.....	109
11.3	Metal Oxide Semiconductor (MOS H ₂ S) Sensors.....	110
11.4	MOS H ₂ S Sensor Spare Parts and Accessories.....	111
	11.4.1 Sensors	111
	11.4.2 Sensor Housing (Junction Box)	111
	11.4.3 Sensor Accessories	111
	11.4.4 Calibration Equipment.....	112
11.5	MC600 System Upgrades and Accessories	113
	11.5.1 MC600 Upgrade Modules	113
	11.5.2 MC600 Accessories	113
12.0	INSTALLING UPGRADES	114
12.1	Adding a Signal-Conditioning Card.....	114
12.2	Adding a Power Supply to the MC600 Chassis	115
12.3	Adding a Class 1 Division 2 Power Supply to MC600 Chassis	116
12.4	Adding a Sounder	117

Table of Figures

Figure 1: Mounting Dimensions for the MC600 Cabinet	ix
Figure 2: Pre-stripping Wiring	x
Figure 3: MOS H ₂ S Connection	xi
Figure 4: 4-20mA Instrument Connection	xii
Figure 5: Cabling Shield	xiii
Figure 6: MC600 MODBUS & Alarm Relay Connectors	xiv
Figure 7: MC600 Connections to an Onboard Power Supply	xvi
Figure 8: Onboard Class I Division 2 Power Supply	xvii
Figure 9: MC600 Connections to an External Power Supply	xviii
Figure 10: MC600 Multi Channel Controller System	1
Figure 11: MC600 Cabinet Front Panel and Interior	2
Figure 12: Mounting Dimensions for the MC600 Cabinet	6
Figure 13: Sensor Housing and Junction Box	8
Figure 14: Duct Mounting Kit Assembly	9
Figure 15: Pre-stripping Wiring	10
Figure 16: MOS H ₂ S Sensor	12
Figure 17: Connector Receptacle	12
Figure 18: Catalytic HC Sensor	13
Figure 19: Cabling Shield for HC Sensor	13
Figure 20: 4-20mA Instrument Card	14
Figure 21: Connector Receptacle	15
Figure 22: MC600 MODBUS & Alarm Relay Connectors	17
Figure 23: Relay Protection for DC and AC Loads	18
Figure 24: MC600 Connections to an Onboard Power Supply	19
Figure 25: Onboard Class I Division 2 Power Supply	20
Figure 26: MC600 Connections to an External Power Supply	21
Figure 27: Sample Operation Mode Display	23
Figure 29: Front Panel Menu Display and Navigation Buttons	26
Figure 30: MC600 Menu Overview	28
Figure 31: Portable Purge Calibration Equipment	31
Figure 32: Field Calibrator (Breaker Bottle) with H ₂ S Gas Ampoule	32
Figure 33: Setup Channels Submenu	39
Figure 34: Alarm Delay Setup	40
Figure 35: Setup Relays Submenu	47
Figure 36: MC600 Advanced Menu Options	49
Figure 37: Setup Channels, Options Model Submenu	51
Figure 38: Model Options for a 4-20mA Signal Conditioning Card	52
Figure 39: Option Mode Submenu	55
Figure 40: Zoning Submenu	57
Figure 41: Relay Assignment Options with No Zoning	58
Figure 42: Setup Card Test Submenu	59
Figure 43: Setup Password Submenu	60
Figure 44: Setup Fault Relays Submenu	62
Figure 45: Setup MODBUS Submenu	63
Figure 46: Setup Load Defaults Submenu	64
Figure 47: Setup Check Menu	66
Figure 48: Self-Test Menu	67
Figure 49: Remote Test Gas Applicator (TGA-1)	70
Figure 50: Three-Liter Chamber for Liquid and Solvent Vapors	70

Figure 51: H ₂ S Portable Purge Calibrator	71
Figure 52: Outline and Dimensional Drawing	103
Figure 53: Outline and Dimension Drawing, Cabinet Door and Bottom	104
Figure 54: Catalytic Bead, Combustible Gas Sensor	107
Figure 55: MOS H ₂ S Gas Sensor	110
Figure 56: Movement of Electrons on MOS H ₂ S Film	111
Figure 57: Power Supply	115
Figure 58: Power Supply Connector.....	116
Figure 59: MC600 Class I Division 2 Power Supply.....	117
Figure 60: Sounder Unit	118
Figure 61: LCD Board.....	118

Table of Tables

Table 1: MC600 Installation Overview.....	vii
Table 2: Normally Open and Closed Relays	xv
Table 3: MC600 Installation Overview.....	4
Table 4: Normally Open and Closed Relay Contacts.....	17
Table 5: MC600 Device Measurement Ranges, Minimum and Maximum Set Points and Increments	44
Table 6: Default Allocation of Relays to Channels and Alarms	47
Table 7: Zoning Options and Relay Assignments	56
Table 8: Locations	68
Table 9: Serial Data Formats.....	76
Table 10: MODBUS Read Query Message.....	77
Table 11: MODBUS Read Response Message	77
Table 12: MODBUS Write Query Message.....	78
Table 13: MODBUS Write Response Message	78
Table 14: MODBUS Exception Response Message	79
Table 15: MODBUS Exception Codes.....	80
Table 16: MC600 MODBUS Register Summary	84
Table 17: Bitmap for Unit Error Status (Lower Byte Only)	85
Table 18: Calibration and Calibration Check Modes	86
Table 19: Baud Rates for MODBUS Channel 1	88
Table 20: Data Formats for MODBUS Channel 1	88
Table 21: Baud Rates for MODBUS Channel 2	89
Table 22: Data Formats for MODBUS Channel 2	89
Table 23: Channel Mode Descriptions	94
Table 24: Sensor Types (Catalytic HC and MOS H ₂ S)	94
Table 25: Instrument Types (4-20mA Instruments).....	95
Table 26: Alarm States (Bit Map)	99
Table 27: VDC Cable Lengths.....	106
Table 28: Catalytic HC Sensor Cable Lengths.....	106
Table 29: MOS H ₂ S Sensor Cable Lengths	106

2.0 Introduction

This manual provides instructions for installing and operating the Model MC600 Multi-Channel Controller System for gas detection. Task procedures for installation, menu-based configuration, and operation are provided, along with, maintenance instructions, specifications, and MODBUS programming information.

The MC600 is a microprocessor-based controller that provides six channels of continuous gas detection. It is directly compatible with General Monitors' catalytic bead hydrocarbon sensors (referred to in this manual as catalytic HC sensors) and with General Monitors' Metal Oxide Semiconductor hydrogen sulfide sensors (referred to as MOS H₂S sensors). The MC600 also interfaces with numerous General Monitors' instruments based on infrared, catalytic HC, MOS H₂S and electrochemical sensors. The compatible instruments include Models S4000C and T, S4000CH and TH, S4100C and T, S104, S106A, S214, S216A, TS400, TS420, TS4000/H, IR2100, IR400, IR700, IR5000/IR5500, IR7000, Observer, Observer-H and Surveyor.

The MC600 is housed in a glass-filled polyester, NEMA Type 4X cabinet enclosure that must be mounted in a safe (non-hazardous) area with an optional onboard power supply. For mounting in hazardous areas, the MC600 Class I Division 2 must be used. Signal-conditioning input cards for catalytic HC sensors, MOS H₂S sensors and 4-20mA interface input can easily be installed and removed from slots in the controller cabinet for maximum flexibility. The MC600 includes card slots and front panel displays for up to six connected devices.



Figure 10: MC600 Multi Channel Controller System

Once sensors and instruments are connected to the MC600 signal cards via cabling, you can set up and monitor the devices using the MC600 front panel LCD displays and menu controls (or using the MODBUS communications interface). The six backlit LCD modules have two lines each, with eight characters per line. READY, ALARM, WARNING and FAULT indicators supplement the LCD digital displays and keyboard controls are provided for setup, calibration and gas reading functions.

Figure 13 shows the front panel and the inside of the MC600 cabinet. The front panel includes six LCD displays for up to six connected field devices; the inside of the cabinet has an optional power supply installed and slots for six signal-conditioning cards.




Figure 11: MC600 Cabinet Front Panel and Interior

The MC600 provides six auxiliary 8-amp relays that are user-configurable to activate external devices such as a horn and/or beacon on any of the six channels' alarm or warning set points. These relays have several independent, user-configurable options:

- Warning
- Low alarm and High alarm activation set points
- Discrete activation set points for different channels
- Settings for energized vs. de-energized, latching, non-latching or timed in the range from 1-120 minutes

The MC600 has one common Fault relay that activates upon any system or individual channel malfunction. The Fault relay has two user-selectable options: activated or de-activated, during setup or calibration mode operation.

2.1 Features and Benefits

The following is a partial list of features and benefits for the MC600 Multi-Channel Controller System:

- Gas detection and calibration control
- Stored detector and gas table information for the General Monitors' catalytic HC and MOS H₂S sensors.
- Interfacing and monitoring via 4-20mA input with numerous General Monitors fixed point detection instruments for combustible and toxic gases.
- One to six channels for continuous monitoring for all connected gas detection equipment, with reporting via LCD display and MODBUS commands in % by volume, % LEL, ppm or dB.
- System expandability and modularity based on plug-in signal-conditioning cards.
- Dual redundant MODBUS communications
- Removable terminal block plugs
- Six user-configurable 8-Amp relays.
- Up to three zones with independent voting and relay configuration.
- Application flexibility, ease of setup and ease of installation and wiring.
- Class I Division 2 power supply option for hazardous location mounting

2.2 Applications

There are many applications suitable for the Model MC600 Multi-Channel Controller and its connected gas detection sensors. The following list of applications is available for the MC600 when combined with catalytic HC sensors, MOS H₂S sensors and a variety of gas detection instruments:

- Wastewater & Utilities
- Petrochemical and Chemical Plants
- Pulp & Paper Mills
- Steel Industry
- Compressor Stations
- Refineries, drilling platforms and rigs
- Gas and oil production platforms
- Gas collection facilities
- Mud-logging operations
- Sulfur recovery plants
- De-sulfurization facilities
- Sewage disposal/treatment plants

3.0 Installation

The main steps in a typical MC600 installation are listed below. There is some variation in the installation process at each site, depending on the exact site configuration.

Installation Step	Refer to Section
1. Unpack the equipment and prepare for the installation.	Section 3.1 and Section 3.2
2. Prepare the MC600 cabinet for mounting in place.	Section 3.3
3. Mount sensors and instruments to be connected to the MC600	Section 3.4
4. Connect the sensors and instruments to the MC600	Section 3.5
5. Connecting MODBUS, HART, and alarm relays to the MC600	Section 3.6, 3.7, 3.8
6. Connect the MC600 cabinet to an external power supply if necessary, and then power on the MC600 system	Section 3.9
7. Configuring the front panel	Section 3.10

Table 3: MC600 Installation Overview

3.1 Unpacking the MC600 Equipment

Please keep the following warnings and cautions in mind when you unpack and install the MC600 cabinet and cabling.



CAUTION: Installation and maintenance must be carried out by suitably, skilled and competent personnel only.

Removing or installing cards or field devices while power is applied may cause permanent damage.



CAUTION: Contact with the PCB components should be avoided in order to prevent damage from static electricity to equipment and personnel. Special care must be taken to wear grounding apparel and to ensure that only the connection points are touched whenever you are handling or installing the MC600.



CAUTION: Each MOS H₂S sensor is shipped with a red plastic cap fitted over the sensor head. Inside the cap is a desiccant. **DO NOT** remove this cap until you are ready to power the system. **SAVE** the cap and **RE-CAP** the sensor anytime the system power is off for more than one hour.

All equipment shipped by General Monitors is packaged in shock absorbing containers, which provide considerable protection against physical damage. The contents should be carefully removed and checked against the packing list.

If any damage has occurred or there is any discrepancy in the order, please notify General Monitors as soon as possible. All subsequent correspondence with General Monitors must specify the equipment part number and the serial number.

NOTE: Each Model MC600 is thoroughly tested at the factory. However, a system checkout is required upon initial start-up to ensure system integrity.

3.2 Preparing for the Installation

To prepare installing the MC600 cabinet, you will need to choose a location and gather the required tools. Separate preparation guidelines for mounting sensors are provided in Section 3.5.

3.2.1 Choosing a Location

The MC600 cabinet should be wall-mounted in a non-hazardous area. It can be placed indoors or outdoors. You will need to select a location for the MC600 that is near enough to the field-mounted devices to conform to the maximum cable lengths specified for the field-mounted device.

NOTE: If a Class I Division 2 power supply is used, the cabinet can be mounted in a hazardous Class I Division 2 area.

There must be adequate clearance beneath the MC600 cabinet to allow for cable installation. Weather-protected locations with minimal shock and vibration are preferred. Although the MC600 is largely immune to electromagnetic interference (EMI), it should not be mounted in close proximity to radio transmitters or similar equipment. The MC600 is provided with two ferrite clamps for use on the power supply cable in case any interference is observed. Before installation, carefully review the environmental specifications for allowable temperature ranges and the electrical specifications for power supply requirements.

3.2.2 Tools You Will Need

The following tools will be needed to install and cable the MC600:

- Flat-head screwdriver maximum 3/16" (5 mm) width for terminal block connections (included with unit)
- Adjustable wrench for conduit or cable gland connections (not included)
- #2 Phillips-head screwdriver (not included)

3.3 Mounting the MC600 Cabinet in Place

Once the MC600 cabinet is prepared for installation, it should be mounted in place.




Figure 12: Mounting Dimensions for the MC600 Cabinet

Before bolting the cabinet in place, make sure it is level. Fasten four ¼-inch bolts into the four mounting holes on the corners of the enclosure. Use appropriate mounting screws/bolts in regard to the mounting surface i.e. concrete, wood, etc. Do not mount the MC600 onto drywall unless it is secured to the wooden studs behind the drywall.

3.4 Mounting the Sensors and Instruments

The gas detection devices that will be connected to the MC600 must be mounted in locations where they are needed for gas detection. This can take place either before or after the MC600 cabinet is mounted in place.

- This section provides some guidelines for selecting sensor locations for catalytic HC and MOS H₂S sensors; later sections describe how to mount a sensor using a General Monitors' explosion-proof sensor housing and duct mounting kit.
- Instructions for mounting each type of 4-20mA instrument are provided in the instruction manual for that instrument.

Section 11.0 provides ordering information for several accessories that can be installed during sensor mounting, splash guards, dust guards and remote calibration devices.

3.4.1 Sensor Location Considerations

Given that the optimum sensor location is different for each application, there are no standard rules for sensor placement. The customer must evaluate conditions at the sensor site in order to make this determination. The following are some general guidelines:

- The sensor should be easily accessible for calibration checks. Ensure that there is sufficient clearance to use field calibration devices, such as, the breaker bottle and gas ampoules or a Portable Purge Calibrator (Section 4.5.3).
- The sensor head should always point downward to prevent water buildup on the sensing element. Remember that some combustible gases are heavier than air; however, do not rely on this fact when selecting a sensor position.
- The sensor should be located in areas where leaks are suspected (i.e. near valves & pipe connections, etc.). It should not be placed where contaminating substances may coat it.

3.4.2 Sensor Poisons

Sensors may be adversely affected by prolonged exposure to certain atmospheres. The more important poisons are:

- For catalytic HC sensors only, prolonged exposure to Hydrogen Sulfide (H₂S) Gas
- Halides (compounds containing Fluorine, Chlorine, Bromine and Iodine)
- Glycol
- Heavy Metals (e.g. Tetraethyl lead)
- Silicones contained in greases or aerosols are the most common "coating" agents. These are not true sensor poisons, but they do reduce sensor response.

Other damaging materials that can harm the sensor include mineral acids and caustic vapors. The presence of such poisons and vapors does not exclude the use of MOS H₂S and catalytic HC sensors; however, a careful analysis of ambient conditions should be undertaken and the customer should be aware that sensor calibration might need to occur at more frequent intervals.

3.4.3 Mounting a Sensor with a GM Junction Box

Figure 17 shows a GM explosion-proof housing for catalytic HC and MOS H₂S sensors that is rated for use in Class I, Division I, Groups B, C & D hazardous locations. Both housing entries are tapped for 3/4" NPT threads. The sensor connects to one of these entries, while the other entry is for conduit runs. The lid of the housing is also threaded to allow the user to gain entry to the sensor connections in the field.

When a sensor is attached to the housing, it must be screwed into the housing using five to seven turns to ensure that the explosion-proof integrity of the housing is maintained.

Once the sensor is installed/operating in the field, no attempt should be made to disconnect the sensor, the conduit or the housing lid without removing power from the unit. This would compromise the explosion-proof integrity of the field device. There is a four-position terminal block inside the junction box housing to route the wires from the sensor to the MC600.




Figure 13: Sensor Housing and Junction Box

3.4.4 Mounting a Sensor with a Duct Mounting Kit

General Monitors produces a Duct Mounting Kit (P/N 10041) for applications that require the sensor to be mounted in an air-conditioning system or heating duct.




Figure 14: Duct Mounting Kit Assembly

To install a sensor using the Duct Mounting Kit Assembly:

1. Select a location on the duct and cut out a hole large enough for the sensor to be inserted into the duct.
2. Place the O-Ring over the sensor threads, against the 1 ¼-inch hexagon on the wiring side of the sensor.
3. Insert the wiring side of the sensor through the gasket and cover.
4. Screw the lock-nut onto the wiring side of the sensor
5. Use the four screws to attach the mounted sensor to the duct. The sensor should be oriented so that when the plate is attached to the duct, the sensing element is inside the duct.

NOTE: For an explosion-proof installation, the Duct Mounting Kit is combined with a junction box, such as, the one shown in Figure 13. The junction box would be attached to the sensor housing on the other side of the duct mounting cover plate.

3.4.5 Applying Sealants to Conduit Entries

Please keep the following warnings and cautions in mind when you install housings and cabling from catalytic HC and MOS H₂S sensors, as well as, instruments mounted in hazardous areas, to make sure that the equipment maintains the appropriate seals for a Class I hazardous location.



WARNING: Each conduit run within a hazardous location (and from a hazardous to a non-hazardous location) must be sealed so that gases, vapors and/or flames cannot pass beyond the seal. For information on Class I location seals, see NEC Articles 501-5 and 500-3d



WARNING: Unused cable entry holes in each sensor housing must be sealed with approved explosion-proof stopping plugs. Red caps supplied by

General Monitors are for dust protection only and must not be left on the unit when installed.



CAUTION: Acetic acid will cause damage to metal components, metal hardware, ceramic IC's, etc. If damage results from the use of a sealant that contains acetic acid (RTV silicone), the warranty will be void.



CAUTION: To prevent corrosion due to moisture or condensation, it is recommended that the conduit connected to the sensor housings be sealed or contain a drain loop.

3.5 Connecting Sensors and Instruments to the MC600

Once the MC600 cabinet is installed, you are ready to begin cabling from the signal-conditioning cards in the MC600 cabinet slots to field-mounted catalytic HC sensors, MOS H₂S sensors and 4-20mA instruments. You can connect one sensor or instrument to each signal-conditioning card in the cabinet by routing standard cabling from the device to the wiring connector on the card. Separate procedures are provided for installing cabling to MOS H₂S, catalytic HC and 4-20mA cards.

The signal-conditioning cards are preinstalled in the cabinet; the white label in the cabinet above the card connection slots indicates what type of card is in each channel. Channel numbers 1 to 6 are silk-screened on the PCB adjacent to each slot.

To install wiring from MOS H₂S and catalytic HC sensors or instruments to the MC600, the end of the wires that will be fastened to the MC600 signal card connector should be stripped to approximately 0.25 inches (Figure 19).




Figure 15: Pre-stripping Wiring

3.5.1 Warnings, Cautions and Standards

Please review the following warning and caution statements before proceeding to install cabling. For information on non-hazardous location cabling to the MC600 cabinet, see NEC article 504. For information on Class I location seals for sensors mounted in hazardous areas, see NEC articles 501-5 and 500-3d



WARNING: Under no circumstances should equipment be connected or disconnected when under power. This is contrary to hazardous area regulations and may also lead to serious damage to the equipment. Equipment damaged in this manner is not covered under warranty.



CAUTION: The MC600 Multi-Channel Controller System and field-mounted sensor devices contain components that can be damaged by static electricity. Special care must be taken when wiring the system to ensure that only the connection points are touched.



CAUTION: Use wire with insulation rated to at least 105°C

3.5.1.1 European Union (EU) Approved Cable Armor and Screens

Interconnecting cables must have an overall screen or screen and armor. Cables BS5308 Part 2, Type 2 or equivalent are suitable. The cable armor must be terminated in a suitable cable gland at the detector to ensure a positive electrical connection.

NOTE: The terms 'screen' and 'shield' are equivalent for the purpose of this manual.

3.5.1.2 Cable Termination in Non-Hazardous Areas

- The cable **armor** must be connected to **safety earth** in the safe area.
- The cable screen (drain wire) must be connected to an instrument earth in the safe area.
- The power supply OV return must be connected to an instrument earth in the safe area.
- The interconnecting cables should be segregated from power and other noisy cables. Avoid proximity to cables associated with radio transmitters, welders, switch mode power supplies, inverters, battery chargers, ignition systems, generators, switch gear, arc lights and other high frequency or high power switching process equipment.
- In general, maintain separation of at least 1 meter between instrument and other cables. Greater separations are required where long parallel cable runs are unavoidable. Avoid running instrument cable trenches close to lightning conductor earthing pits.
- Complete all cable insulation testing before connecting the cable at either end.

3.5.2 Connecting a MOS H₂S Sensor to the MC600



CAUTION: Only MOS H₂S sensors designed by General Monitors will work with the MC600. Any attempt to use a sensor that has not been designed by General Monitors will void the MC600 warranty.

Four-wire cabling is required to connect from the MOS H₂S signal-conditioning card to a field-mounted MOS H₂S sensor. The maximum cable lengths are indicated in Table 28.

To connect to a MOS H₂S sensor:

1. Thread four-wire cabling from the MOS H₂S sensor into the MC600 cabinet through one of the conduit openings in the bottom of the cabinet.
2. Remove the connector from the signal-conditioning card by loosening the two recessed screws that hold it in place and lift the connector forwards.




Figure 16: MOS H₂S Sensor

3. Loosen the five-wire receptacle screws on the bottom of the connector. Secure each wire from the field device into the connector receptacle and tighten the screw that holds it in place. Fasten the cabling shield in the far right receptacle.




Figure 17: Connector Receptacle

4. Once the wires are secured in the connector, replace the connector on the card and tighten the connector mounting screws at each side.
5. The fuse on the signal conditioning card may need to be replaced if a sensor fault error appears during power-on (Section 8.2.7)

3.5.3 Connecting a Catalytic HC Sensor to the MC600



CAUTION: Only catalytic HC sensors designed by General Monitors will work with the MC600. Any attempt to use a sensor that has not been designed by General Monitors will void the MC600 warranty.

Three-wire cabling is used to connect from the catalytic HC signal-conditioning card to a field-mounted catalytic HC sensor. The maximum cable lengths are indicated in Table 27.

To connect a catalytic HC sensor:

1. Thread cabling from the catalytic HC sensor into the MC600 cabinet through one of the conduit openings in the bottom of the cabinet.
2. Remove the connector from the catalytic HC signal-conditioning card by loosening the two recessed screws that hold it in place and lift the connector forwards




Figure 18: Catalytic HC Sensor

3. Loosen the wire receptacle screws. Then secure the red, black and white wires from the field device in the receptacles and tighten the screws to hold them in place. Fasten the cabling shield in the far right receptacle.




Figure 19: Cabling Shield for HC Sensor

4. Once the wires are secured in the connector, replace the connector on the card and tighten the connector mounting screws at each side.

NOTE: If you have four-wire cabling, you can fasten the green wire into the empty second receptacle; however, no signal will be carried on this wire.

3.5.4 Connecting a 4-20mA Instrument to the MC600

Instruments with their own control circuitry, such as, S4000 Series, S4100 Series, IR2100, Observer and Surveyor - are connected to the MC600 through a 4-20mA signal-conditioning card.

To connect a 4-20mA instrument:

1. Thread four-wire cabling from the instrument into the MC600 cabinet through one of the conduit openings in the bottom of the cabinet. The maximum cable lengths are indicated in the manuals for each device.
2. Remove the connector from the 4-20mA signal-conditioning card by loosening the two recessed screws that hold it in place and lift the connector forwards.




Figure 20: 4-20mA Instrument Card

3. Loosen the five-wire receptacle screws, then secure each wire from the field device into the connector receptacle and tighten the screws that hold them in place. Fasten the cabling shield to the rightmost receptacle.




Figure 21: Connector Receptacle

The *Analog Out* signal from the detection instrument must be routed to the *Analog In* receptacle on the signal conditioning card connector.

NOTE: When the field instrument is an IR5000/IR5500, there are two *Analog Out* signals from the field instrument. Connect them to the *Analog In* receptacles of any two channels of the MC600 system.

COM (DC Ground) must also be connected from the device to the signal card connector.

- The +24VDC signal wire from the detection instrument should be connected to the second connector receptacle *if* the MC600 power supply will be used to provide power to the instrument. If you plan to connect the instrument to a separate power supply other than the MC600, *do not* connect the +24VDC power signal wire.
- 4. The Analog Out receptacle on the signal-conditioning card connector is provided to forward the 4-20mA input from the field instrument on to another monitoring device, such as a PLC. When the analog signal is passed through to a PLC or DCS device, the W1 jumper on the analog input card must be cut. Ground must also be connected to this device.
- 5. Once the wires are secured in the connector, replace the connector on the card and tighten the connector mounting screws at each side.

NOTE: For some 4-20mA instruments, the MC600 message **Fld Dev Fault** will appear while the instrument is in start-up mode. Refer to the instrument documentation for information on the start-up process



CAUTION: The MC600 Multi-Channel Controller System cannot provide sufficient power for an IR5000/IR5500 field instrument. When an IR5000/IR5500 is being connected to the MC600, the user should provide their own 24V power supply for the IR5000/IR5500 source

and receiver units as outlined in the IR5000/IR5500 manual. **Do not use the +24V DC signal connection from the MC600 signal-conditioning card, or damage to the system may occur.**

3.6 Connecting a MODBUS Device

Connector J8 near the bottom left side of the MC600 main circuit board is provided for connecting the two MC600 MODBUS channels to control room MODBUS devices. Refer to the manual for the field device to determine maximum cable lengths.

To Connect a MODBUS Device to the J8 Connector

1. Remove the connector from the MC600 controller board; loosen the two recessed screws that hold it in place on each side and then lift the connector forwards.
2. For the first MODBUS device that you plan to attach, loosen the two Mod1 signal wire receptacle screws and the shield wire receptacle on the bottom of the connector.
3. Secure the two wires from the field MODBUS device in the connector receptacles and tighten the screws to hold them in place. Fasten the cabling shield to the nearest shield receptacle.
4. Repeat for the second MODBUS device, with the Mod2 receptacles, and then re-attach the J8 connector on the controller board.

3.7 Connecting a HART Field Device

A HART field device like the IR400, S4000CH, S4000TH, IR5500 and TS4000H can only operate with the MC600 through analog current communication. In order to make the full range of analog signal available to the MC600, the field devices must have HART disabled. Please consult the instruction manual of the field device on disabling the bi-directional communication.



WARNING: Field devices equipped with HART must have the HART function disabled to work properly with the MC600. If the devices are not disabled, the multi-point controller will not recognize fault conditions from HART.

3.8 Connecting Alarm Relay Devices

Connectors J10 and J11 at the bottom of the MC600 main PCB connect relays 1 to 6 to alarm devices such as sirens and bells. The functioning of the alarm and warning relay connections varies depending on whether the relays are configured as energized or de-energized, latched or non-latched, or timed.




Figure 22: MC600 MODBUS & Alarm Relay Connectors

There are three receptacles in connectors J10 and J11 to connect each of six relays, for a total of 18 receptacles. Each receptacle label indicates what it is used for.

The first digit in the receptacle label represents the channel number, from 1 to 6.

The last digit in the receptacle label indicates the function of the receptacle. If the last digit is C, the receptacle is for relay common.

If the relays are set up as de-energized (the default), the last digit 1 is for normally closed, and the last digit 2 is for normally open.

If the relays are set up as energized, the last digit 1 is for normally open, and the last digit 2 is for normally closed.

NOTE: Connector J12 is connected to fault relays. The fault relay is normally energized. It will change state after power-up.

The default MC600 configuration setting for the warning and alarm relays is de-energized. Use the following table as a guide for determining the normally open (**NO**) and the normally closed (**NC**) contacts for the energized versus de-energized setting.

	NORMALLY ENERGIZED	NORMALLY DE-ENERGIZED
	J10 POS 1 – NO	J10 POS 1 – NC
	POS 2 – C	POS 2 – C
	POS 3 – NC	POS 3 – NO
	POS 4 – NO	POS 4 – NC
	POS 5 – C	POS 5 – C
	POS 6 – NC	POS 6 – NO
	POS 7 – NO	POS 7 – NC
	POS 8 – C	POS 8 – C
	POS 9 – NC	POS 9 – NO
	J11 POS 1 – NO	J11 POS 1 – NC
	POS 2 – C	POS 2 – C
	POS 3 – NC	POS 3 – NO
	POS 4 – NO	POS 4 – NC
	POS 5 – C	POS 5 – C
	POS 6 – NC	POS 6 – NO
○	POS 7 – NO	POS 7 – NC
	POS 8 – C	POS 8 – C
	POS 9 – NC	POS 9 – NO

Table 4: Normally Open and Closed Relay Contacts



WARNING: Relay contacts must be protected against transient and over-voltage conditions (Figure 27).




Figure 23: Relay Protection for DC and AC Loads

European Union (EU) Approved Applications: The ALARM relay contact ratings are 8A, 30 V RMS/42.4 V peak or 8A @ 30 VDC resistive max.

North American Approved Applications: The ALARM relay contact ratings are 8A @ 250 VAC and 8A @ 30 VDC resistive max.

3.9 Connecting Power and Starting Operation

Once the mounting, cabling and alarm relay installation is complete, your MC600 controller system is ready to begin the power-on sequence. Please review this section carefully before powering on the system.

3.9.1 Start-up Readiness Checklist

Prior to applying power to the system for the first time, check the following items:

NOTE: The +24V wire(s) to the power supply (supplies) should be connected after the readiness checklist is verified, to protect the system from shorting.

NOTE: The SHIELD terminal of J9 should be connected to an earth ground.

- Verify that all the signal wiring (except for +24V) is installed correctly.
- Verify that the MC600 cabinet is properly mounted. Make sure that the conduit/cable entries are securely installed.
- Make sure to inhibit any external devices, such as Trip Amplifiers, PLC devices or DCS systems until after the start-up sequence has completed.

Once you are ready to begin the start-up, verify that the power supply is connected properly.

3.9.2 Connecting the MC600 to a Power Supply



WARNING: The MC600 power supply or connected external power supply should be left OFF and unconnected to its power source until after you have completed cabling connections.

- If you have ordered a power supply pre-installed for the MC600, then the unit is shipped with cabling from the power supply to the control board pre-installed. You will only need to connect the onboard power supply to a 115/230 VAC power source. Two ferrite beads are supplied. They should be installed on the AC cord.




Figure 24: MC600 Connections to an Onboard Power Supply

To connect the MC600 onboard power supply to a power source

Refer to Figure 24 as you follow these steps.

- Verify that the voltage switch on the power supply is set to the appropriate setting for your site, either 115VAC or 230VAC.
- Connect cabling from the connector beneath the power supply to the power supply's external power source. Three wires will be needed to carry AC Line, AC Neutral and Frame Ground to the power source. Make sure the two ferrite beads are installed on the AC cord.




Figure 25: Onboard Class I Division 2 Power Supply

To connect the MC600 Class I Division 2 onboard power supply to an power source:

Refer to Figure 25 when following these steps

3. Connect cabling from the connector beneath the power supply to the power supply's external power source. Three wires will be needed to carry the AC line AC neutral, and frame ground to the power source. Make sure the two ferrite beads are installed on the AC cord.

NOTE: This is 100VAC – 240VAC/50Hz-60Hz auto-switching power supply, you do not need to select the input voltage.

To connect the MC600 to an external power supply

If the MC600 does *not* have an onboard power supply, then you will need to install cabling from the MC600 J9 connector to an external Primary DC power supply. See Table 26 for cable length specifications.




Figure 26: MC600 Connections to an External Power Supply

You will need to refer to your power supply manual for the location of the ground and +24VDC terminals, and connections from the external power supply to a power source.

Refer to Figure 26 as you follow these steps.

1. Connect a wire from the MC600 J9 connector COM receptacle to the power supply DC Ground connector.
2. Connect the MC600 J9 connector +24VDC receptacle to the power supply +24VDC terminal.
3. The Model MC600 operates on nominal power of +24 VDC. When you are ready to power on the MC600, connect the external power supply to a power source. Refer to your power supply manual for instructions on connecting it to a power source.

3.9.3 Startup Process for an MC600 System

NOTE: Powering on and off of the MC600 is controlled from the power supply and/or power source. If you have any problems in the start-up or testing of the detector system, please refer to Section 8.0 or contact General Monitors Technical Support (see Section 6.0).

Upon first power-up, the MC600 requires a few minutes to stabilize while the unit attains its proper operating temperature. The six MC600 Channel LEDs will go through the following process during this period:

1. The LCD segments for all six channels remain lit for several seconds. The four LEDs for READY, ALARM, FAULT and WARN also remain lit during this period.
2. Next, Channel 1 will display the part number and firmware revision for the MC600 control card, Channel 2 will display the part number and firmware revision for the LCD panel, and Channels 3 through 6 remain blank, as shown below (Rev. A is shown for reference, the actual program revision may vary):

CHANNEL 1 65023-1 ----- Rev. A	CHANNEL 4 ----- -----
CHANNEL 2 65024-1 ----- Rev. A	CHANNEL 5 ----- -----
CHANNEL 3 ----- -----	CHANNEL 6 ----- -----

3. Next, each channel that has a signal-conditioning card installed and a sensor or instrument connected to it will go into Operation Mode, in which gas measurement data is shown. The Operation Mode display varies for different sensors and instruments, as follows:
 - **Catalytic HC Sensor:** The LCD display for a channel with a catalytic HC sensor will go through a 50-second startup cycle countdown, followed by an Operation Mode display similar to the following (“Comb” stands for combustible):
 - 0% LEL Comb
 - **MOS H₂S Sensor:** The Operation Mode display appears in the following format, assuming that no gas is currently detected:
 - 0 ppm H₂S
 - **4-20mA instrument:** The Operation Mode display may appear in one of several formats, depending on the instrument that is connected to it. An example set of displays is shown in Figure 31




Figure 27: Sample Operation Mode Display

Once the MC600 is powered on and in Operation Mode, you will need to complete several tasks using the MC600 onboard menus. A list of these tasks follows:

NOTE: For general instructions on navigating the MC600 menu system, see Section 4.1.

1. **Configure the Display Setup**, as described in the following section.
2. **Calibrate all connected catalytic and MOS H₂S sensors** (Section 4.5).
 - For each catalytic HC sensor connected to the MC600, General Monitors recommends that you calibrate the sensor one hour after a first time system start-up.
 - For each MOS H₂S sensor connected to the MC600, General Monitors recommends that you calibrate the sensor one hour after start-up and again 24 hours later.
3. **Recalibrate the LCD channel display for 4-20mA signal conditioning cards** (Section 4.6).
4. **Configure the Alarm and Warning relay set points, as needed** (Section 4.9.1).
5. **Configure the relay states as needed**, for energized versus de-energized, latching versus non-latching and timed (Section 4.9.3).

3.10 Configuring the Front Panel Setup

Use the [DISPLAY SETUP] button to adjust the front panel LCD displays, LEDs and sounder (if installed). The following flowchart shows the front panel setup options that appear in the Channel 1 display. The changes you select using this menu will affect all six LCD displays, all four LEDs, etc.

Press the [MODE] button to move from one setup option to the next, and use the [▲] and [▼] buttons to change the option settings. To exit from this menu at any time press the [DISPLAY SETUP] button. Any changes made are saved automatically when this menu is exited.




Figure 28: Display Setup Menu Sequence

LCD Brightness Adjustment. Press [▲] or [▼] to choose a value from 0 (darkest) to 9 (lightest) for the six LCD channel displays. The default value is 6.

LED Brightness Adjustment. Press [▲] or [▼] to choose a value from 0 (dimkest) to 9 (brightest) for the four LEDs: READY, ALARM, FAULT and WARN. The default is 0.

Sounder Volume. Press [▲] or [▼] to choose a value from 0 (quietest) to 9 (loudest). The default is 0.

Key Click Toggle. Press [▲] or [▼] to toggle the key click between On and Off. The default is audible or On.

Key Test. Press [ENTER] to enter the key test, and then press any front panel button to test it ([ACCEPT], [MODE], [ENTER], [RESET], [▲] or [▼]). To exit from the Key Test, you will have to exit from the display menu by pressing [DISPLAY SETUP], or wait five seconds and the unit will automatically exit from the button test.

Display Test. Press [ENTER] to start the Display Test. The sounder, the six LCD displays and the four LEDs will go through a diagnostic sequence, flashing the LEDs and sounder and counting from 0 to 9 on the LCD displays. The MC600 will return to Operation mode after completion of the test.

3.11 Maintaining the X/P Integrity

The catalytic HC and MOS H₂S sensor junction box housings are rated explosion-proof for use in the following hazardous locations:

CSA/FM: Class I, Division 1, Groups B, C, D and Class I, Zone 1.

ATEX: Ex e d IIC, II 2 G

Anytime the cover of a sensor housing is removed, or the cover bolts are loosened and power is to be left on, it will be necessary to declassify the area. When replacing the cover, the gap between the lid and the housing should be less than .0015 inch (.038 mm).

Make sure that the flame-path is clear of dirt and debris before replacing the cover. You can verify this by tightening the cover bolts to a torque setting of 50 inch-pounds or by using a feeler gauge to ensure that the gap between the cover and the housing is less than .0015 inch (.038 mm).

There are two entry holes in each sensor housing; these holes are used to attach the sensor, as well as wiring conduits to other devices. Each hole is tapped for 3/4" NPT threads. The factory installs plugs in the unused entry holes, except one. A plastic cap is placed into the remaining hole and must be removed before conduit can be attached to the housing.

When a sensor is attached to the housing, it must be screwed into the housing using five to seven turns to ensure that the explosion-proof integrity of the housing is maintained.

4.0 Basic Operation and Configuration

The MC600 LCD displays and navigation buttons form the user interface for a set of menu options that provide you with the most flexible gas detection system possible. This chapter describes how to use the MC600 menus for operation and configuration of the MC600 system unit and connected sensors and instruments. Basic tasks you can accomplish using the menus include:

- Calibrating and checking calibration for catalytic HC and MOS H₂S sensors
- Inhibiting alarms for selected channels
- Configuring set points for the Alarm High, Alarm Low and Warning states
- Configuring the relays as Energized/De-Energized, Latching/Non-Latching or Timed

This chapter provides instructions for these basic tasks. Section 5.0 describes several advanced configuration tasks you can accomplish using the MC600 menus

NOTE: An alternate method to accomplish many of the menu functions is to send commands to the MC600 MODBUS registers from a connected MODBUS device. Section 9.0 describes these registers in detail.

4.1 Entering and Exiting from the MC600 Menus

Pressing the [MODE] button displays **Menu Cal** in the Channel 1 LCD window; this is the first main menu option. Once the MC600 has exited from Operation mode, the other five LCD windows remain blank during most menu operations.




Figure 29: Front Panel Menu Display and Navigation Buttons

Pressing the **[MODE]** button a second time returns all six channels to Operation mode, exiting from the menus. If you have made changes to the configuration settings using the menus, the prompt **Save ? Yes** appears when you press the **[MODE]** button a second time; you must either confirm or cancel your changes before returning to Operation mode.

4.2 Using the Front Panel Navigation Buttons

The MC600 front panel includes several buttons for navigating through the menu. The menu overview flowchart shown in Section 4.4 indicates how these buttons are used to navigate through the different main menu and submenu options:

[MODE] – Toggles between entry into the menus and exit from the menus from anywhere in the menu structure.

NOTE: If you have made configuration changes using the MC600 menus, a prompt to save your changes in permanent memory will appear when you press **[MODE]** to exit from the menus.

[▲] (Up Arrow) – Advances through the options within a menu level.

[▼] (Down Arrow) – Moves back through the options within a menu level.


[ENTER] – Movement down one menu level, or initiation (start) of the currently displayed operational task (calibration, calibration check, etc.).


[RESET] (also shown as **RS**) – Progression up one menu level (either back to the first option at the previous menu level or back to the most recently selected option at the previous level). **[RESET]** can also be used for backwards navigation through the Setup Check submenu options and to reset latched or timed alarms.


[ACCEPT] (also shown as **AC**) – Used for moving forward through the Setup Check menu options, to accept alarms and disable alarm devices, and to cancel fault conditions.

4.3 Menu Flowchart Legend

Figure 30 shows a flowchart of the upper level of the menu structure, to help you navigate between menu options. The menu flowchart provides a roadmap for using the configuration menus and digital displays in the MC600. Several shapes indicate different characteristics of flowchart items, as follows:

 Diamond shapes in the flowchart indicate decision points in the menu where you can move in several directions or choose from several parameter values.

 Dotted lines in the flowchart indicate Password and other prompts that only appear under particular conditions (if a password is set, if you have made configuration changes, etc.).

 Rectangular boxes indicate processes that take place due to a menu selection, such as zeroing or recalibrating a sensor unit. They also surround cross-references to sections in this book that describe menu functions in more detail.

 Display boxes indicate a status or measurement display message.

4.4 MC600 Menu Overview

The following illustration shows an overview of the upper branches of the MC600 menus. Figure 30 shows a navigational flowchart for the two-line LCD menu options as they appear on the Channel 1 LCD display. Variables you must select are shown in italics, such as Chan # 1-6, etc. Connecting arrows indicate the path(s) you can travel between menu options, using the front panel navigation buttons.

NOTE: The basic menu areas described in this chapter are shown shaded.




Figure 30: MC600 Menu Overview

NOTE: Once a password is enabled, you must enter it before you can access the Setup and Inhibit submenus (Section 5.1.6).

Following are descriptions of the six main menu options; each option has one or more submenus branching from it.

1. *Calibration Menu (Menu Cal)*. Use this option to select an MC600 channel and place it in Calibration Mode.

Section 4.5 describes how to use this option to calibrate catalytic HC and MOS H₂S sensors connected to an MC600 channel, to improve their gas detection accuracy.

Section 4.6 describes how to use this option to calibrate the LCD display for connected 4-20mA instruments.

2. *Calibration Check Menu (Menu Cal Chck)*. This option allows you to select one of the six MC600 channels and place it in Calibration Check Mode.

Section 4.7 describes how to use this menu option to test the gas detection accuracy of a catalytic HC or MOS H₂S sensor device connected to an MC600 channel.

3. *Inhibit Menu (Menu Inhibit)*. This option is used to disable and re-enable alarms and warnings for selected MC600 channel(s). Section 4.8 describes how to use the Inhibit submenu.

4. *Setup Menu (Menu Setup)*. This option has eight submenus branching from it. Each submenu allows you to configure different MC600 features for the connected sensor devices. Most of the Setup submenus are described in Section 5.0, but the following basic tasks are described in this chapter.

Section 4.9.1 describes how to configure Alarm and Warning set points and channel display mode.

Section 4.9.2 describes how to configure a Calibration point for catalytic HC sensors.

Section 4.9.3 describes how to configure the six Alarm and Warning Relays onboard the MC600.

5. *Setup Check Menu (Menu StupChck)*. This option has seven submenus branching from it that allow you to check on the current MC600 configuration settings.

Section 5.0 describes these submenus.

6. *Self-Test Menu (Menu Self's)*. This option has two submenus branching from it, which run a set of diagnostic tests for the MC600 processors and memory.

Section 5.0 describes how to use this submenu.

4.5 Calibrating Catalytic HC and MOS H₂S Sensors

Calibration is the process of applying a known level of gas to a sensor and the sensor adjusting to match the output signal to the level of applied gas. You can select the MC600 **Menu Cal** main menu option to place a connected catalytic HC or MOS H₂S sensor in Calibration Mode.

Entering Calibration Mode automatically disables the alarm circuits for the selected sensor.

NOTE: 4-20mA instruments must be calibrated with their own control devices rather than using the MC600 menus. However, you can use the **Menu Cal** option to calibrate the LCD display for these instruments (see Section 4.6).

4.5.1 Calibration Schedule

For catalytic HC sensors connected to the MC600, General Monitors recommends that you calibrate the sensor one hour after a first time system start-up. For MOS H₂S sensors only, General Monitors recommends that you calibrate the sensor one hour after system start-up and again 24 hours later.

After the first 24 hours of operation, you only need to recalibrate the sensor(s) if a calibration check indicates that calibration is needed. You should check calibration for catalytic HC and MOS H₂S sensors at least every ninety (90) days to ensure system integrity.

4.5.2 Preparing for Calibration

For a catalytic HC sensor, if you suspect that background hydrocarbon gases are present, purge the sensor environment with Zero Air before beginning calibration. Zero Air is air that is hydrocarbon-free. If Zero Air is not available, cover the sensor for about thirty seconds before starting sensor calibration.

For a MOS H₂S sensor, if you suspect that Hydrogen Sulfide gas is present, purge the sensor environment with clean air before you start sensor calibration.

For both catalytic and MOS H₂S sensors, make sure that the equipment you will use to apply gas matches the calibration concentration configured for the sensor. The default calibration point for all catalytic HC and MOS H₂S sensors is 50% of the full-scale concentration (full-scale is the maximum displayed value).

NOTE: You can use the **Cal Pnt** menu option to change the calibration point for catalytic HC sensors only, in the range from 25% to 95% (Section 4.9.2).

4.5.3 Sensor Calibration Equipment

The more commonly used calibration devices are the portable purge calibrators for catalytic HC sensors, and breaker bottles (field calibrators) with glass ampoules for MOS H₂S sensors.

4.5.3.1 Equipment for Catalytic HC Sensors

The recommended calibration equipment for GM catalytic HC sensors is a GM portable purge calibrator (Figure 34).




Figure 31: Portable Purge Calibration Equipment

Before beginning sensor calibration, you should place the calibration cup over the sensor; the cylinder valve and the ON/OFF valve are used to control the flow of gas.

NOTE: Section 7.2.1 describes the TGA-1 (Test Gas Applicator) remote calibration device and the 3-liter chamber for calibrating with solvent or volatile liquids. Section 11.0 provides ordering information for all GM calibration equipment.

4.5.3.2 Equipment for MOS H₂S Sensors

The most common method of reliably introducing toxic calibration gas to the MOS H₂S sensors is to use a General Monitors' field calibrator (breaker bottle) with glass ampoules of H₂S gas (Figure 35)




Figure 32: Field Calibrator (Breaker Bottle) with H₂S Gas Ampoule

The glass ampoules contain an H₂S gas concentration that is 50% of full-scale for the sensor that will be calibrated; ampoules containing several different concentrations of H₂S gas are available for different sensor models.

To apply the gas, place the ampoule inside the breaker bottle in the breaker slot, and place the breaker bottle over the sensor. Once you are prompted to apply gas to the sensor, you turn the breaker thumbscrew to break the ampoule and release the gas.

NOTE: Section 7.2.1.3 describes the H₂S Portable Purge Calibrator, an alternate method for introducing calibration or test gas to MOS H₂S sensors that may be advisable for high humidity environments. Section 11.0 provides ordering information for all GM calibration equipment.

4.5.4 Calibration Procedure for Catalytic HC and MOS H₂S Sensors

The following step-by-step procedure describes how to use the MC600 menus to start calibration for a connected catalytic HC or MOS H₂S sensor. You can also send MODBUS commands to begin calibration. The LCD status messages that appear during calibration (beginning with step 2) would be similar.

To Calibrate a Catalytic HC or MOS H₂S Sensor:

1. Press the **[MODE]** button to exit from Operation Mode and enter the MC600 menus. The **Menu Cal** main menu option appears on Channel 1.
2. Press **[ENTER]** to move to the **Cal Chan # 1** prompt. Press the **[▲]** and **[▼]** arrow buttons to select which channel you will be calibrating, from 1 to 6.
3. Press **[ENTER]** to start calibration. The LCD display for the selected channel then displays the message **Sensor Life nnn %**, indicating that the sensor is zeroing. The sensor should be exposed to clean air during this interval.

This message indicates the approximate percent of expected usage left for the sensor. A new sensor device should read 100%.

If you have just installed a new sensor, and the sensor life is less than 100%, press **[RESET]** to reset the number back to 100%.

4. When the message **Apply Gas** appears on the LCD display, you should apply gas to the sensor. You have six minutes to apply gas and complete the calibration process.

First make sure that the device supplying gas for calibration is fastened in place over the sensor; this can be the cup from a portable purge calibrator, a field calibrator with a glass ampoule in it, etc.

Apply gas to the sensor. For the portable purge calibrator, this means opening the valve on the calibration cylinder and the ON/OFF valve. For the field calibrator, this means twisting the knob clockwise to break the ampoule and release the gas.

5. Once the sensor has begun detecting gas, the message **Cal in Progress** appears on the LCD display for a few minutes.

The time required for calibration may be longer if the TGA-1 remote calibration device, a Dust Guard, Splash Guard or other sensor accessories are present.

6. Once calibration is complete, the LCD will show the message **Remove Gas**. You should then disconnect whichever calibration device you have decided to use with the sensor.

7. Once you remove the gas from the sensor, the display may indicate a few percent full-scale, soon dropping to a "0" value.

The unit is now calibrated, and the new SPAN value is stored in non-volatile memory.

NOTE: If the unit cannot store the new calibration values in EEPROM, the sensor will display a **Cal Fault** message, and the unit will use the stored calibration values. You should attempt to recalibrate the sensor.

4.5.5 Stopping Sensor Calibration

You can exit from Calibration Mode before gas is applied and before a **Cal Fault** error message appears, (such as when the **Apply Gas** prompt is shown) by pressing the **[RESET]** button. The message **Cal Aborted** will appear briefly, and the unit will then return to normal operation with the previous calibration values unchanged.

However, once gas is applied to a sensor, it is not possible to stop calibration. Also, if the MC600 is placed in Calibration Mode and no gas is applied for several minutes after the **Apply Gas** prompt appears, the unit will revert to a **Cal Fault** condition. You must calibrate the unit to clear the **Cal Fault** error message.

4.6 Calibrating the LCD Display for 4-20mA Instruments

NOTE: You cannot calibrate a 4-20mA instrument using the MC600 menus or MODBUS commands; you must calibrate and apply gas using the instrument's onboard controller, following the directions in the *Instruction Manual* for the instrument.

The MC600 displays a value that is proportional to the current value that it receives from connected 4-20mA instruments. The function of the **Options Adjust** option for a 4-20mA instrument channel is to calibrate the LCD display to make sure that it shows 0% LEL (or 0% v/v or 0 ppm) when it receives 4mA input, and 50% when it receives 12mA input.

You should select the **Options Adjust** option for a 4-20mA instrument when you first power on your MC600 system, to calibrate the display. You would only select this option again if you suspect the LCD display for the instrument is not accurate, such as when the MC600 measurement display does *not* match the instrument's own measurement display.

NOTE: Calibrating a TS420 instrument that measures oxygen adjusts the LCD display for 17.38mA (20.9% v/v) and 3.50mA (fault). Calibrating a TS4000/H instrument configured to measure oxygen adjusts the LCD display for 17.38mA (20.9% v/v) only.

To Calibrate the Channel Display for a 4-20mA Instrument

1. Press the **[MODE]** button to exit from Operation Mode and enter the MC600 menus. The first main menu option **Menu Cal** appears.
2. Press the **[▲]** or **[▼]** arrow buttons to **Menu Setup** and press **[Enter]** to select. Press **[Enter]** at the **Setup Channels** menu, and using the **[▲]** or **[▼]** arrow buttons, select a channel and press **[Enter]**. **Options Model** appears on the display. Press **[▲]** or **[▼]** arrow buttons to **Option Adjust**.
3. Press **[ENTER]** to start Calibration. The LCD messages for the selected channel will vary depending on what type of instrument is connected.
4. The messages for all instruments (*except* oxygen detection) appear as follows:

4-20 Crd Zeroing: A 4mA current input is calibrated to display as 0% of full-scale.

4-20 Crd Span ?: Pressing **[ENTER]** will allow the LCD channel calibration to proceed; pressing **[RESET]** will stop the calibration process.

Apply 12mA: It is up to the customer to apply 12mA current to the MC600.

4-20 Crd Spanning: A 12mA current input is calibrated to display as 50% of full-scale.

Remove Span: It is up to the customer to remove the 12mA current, to return to normal operation.

5. The messages for oxygen detection instruments such as the TS420 are different, since an oxygen sensor outputs 17.38mA by default. They appear as follows:
 - 4-20 Crd Spanning:** A 17.38mA current input is calibrated to display as 20.9%.
 - Remove Cell:** You will need to remove the sensor cell from the TS420 instrument to cause the current to go to 3.50mA.
 - 4-20 Crd Zeroing:** Once the cell is removed, a 3.50mA current input is used to adjust the display zero.
 - Replace Cell:** You will need to replace the cell that was removed, to return to normal operation.
6. The messages for a TS4000/H instrument configured to measure oxygen are as follows:
 - 4-20 Crd Spanning:** A 17.38mA current input is calibrated to display as 20.9%.
 - 4-20 Crd Zeroing:** A value corresponding to a 4mA current input is adjusted to display as 0%.

4.7 Checking Calibration for Sensors

NOTE: There is no reason to select this menu option for a 4-20mA instrument, since you cannot check calibration for a 4-20mA instrument using the MC600 menus or MODBUS commands. You must use the instrument's onboard controller to check calibration, following the directions in the instrument's *Instruction Manual*.

A Calibration Check tests whether a catalytic HC or MOS H₂S sensor is detecting a known concentration of gas (such as 50% of full-scale) applied to the sensor from calibration equipment. If the detection is not accurate, then the sensor must be recalibrated. After initial system startup and calibration, you should check calibration for the catalytic and MOS H₂S sensors at least every ninety (90) days to ensure system integrity.

You can check catalytic HC and MOS H₂S sensor response without activating external alarms by placing the MC600 in Calibration Check Mode. Entering Calibration Check Mode automatically disables the alarm circuits. For information on General Monitors' calibration equipment used to apply gas during a calibration check, see **Sensor Calibration Equipment** in Section 4.5.3.

A step-by-step procedure follows for completing a Calibration Check, and recalibrating if necessary, using the MC600 *Menu Cal Check* main menu option. You can also send MODBUS commands to begin a calibration check; the LCD status messages that appear during calibration (described starting with **Sensor Life nnn %** in Step 3) are the same for both methods.

To Run a Calibration Check for a Catalytic HC or MOS H₂S Sensor:

1. Press the **[MODE]** button to exit from Operation Mode and enter the MC600 menus. The main menu option **Menu Cal** appears.
2. Press **[▲]** to move to the **Menu Cal Chck** option. Press **[ENTER]** to move to the **Calchck Chan # 1** prompt. Press the **[▲]** and **[▼]** arrow buttons to select which channel device you will be checking, from 1 to 6.
3. Press **[ENTER]** to enter Calibration Check mode. The LCD display for the selected channel then displays the message **Sensor Life *nnn* %**, indicating the sensor is zeroing. The sensor should be exposed to clean air during this interval.

This message indicates the approximate percent of expected usage left for the sensor. A new sensor device should read 100%.

If you have just installed a new sensor, and the sensor life is less than 100%, press **[RESET]** to reset the number back to 100%.

4. Once the message **cc** flashes at the right of the LCD display along with the message ***nn* % LEL** (or ***nn* % v/v** or ***n.n* ppm**), this indicates that it is time to apply gas to the sensor.

Make sure that the device supplying the test gas is fastened in place over the sensor; this can be the cup from a portable purge calibrator, a Field Calibrator with a glass H₂S ampoule in it, a remote TGA-1 calibration unit, etc.

Apply the gas to the sensor. For the portable purge calibrator, this means opening the valve on the calibration cylinder and the ON/OFF valve. For the H₂S Field Calibrator, this means turning the knob clockwise on the ampoule holder until the ampoule breaks, releasing the gas.

5. Once you have applied gas to the sensor, monitor the LCD display.
If the sensor does *not* see gas and the reading remains at **0% LEL**, **0% v/v** or **0.0 ppm**, the unit will return to normal operating mode after a few minutes.
If the sensor *does* see the gas, the gas reading will begin to go up. The LCD reading will continue to flash while the unit remains in Calibration Check mode.

NOTE: The test gas concentration must be at least 10% full-scale before the unit will complete the calibration check sequence. If the channel is placed in the Cal Check Mode and no gas is applied for six minutes, the unit will revert to normal operation.

6. Compare the Calibration Check reading shown on the LCD display with the gas concentration applied, and determine if it is necessary to calibrate the sensor. Then take one of the following actions:

If the reading is within an acceptable accuracy range, remove the gas and allow the sensor to see clean air, then press **[RESET]** to exit. *The procedure is finished.*

If the reading is not acceptable, but the current gas concentration can be used for calibration, press **[ENTER]** to begin calibration and *go to Step 8.*

If the reading is not acceptable and the current gas concentration cannot be used for calibration, remove the gas and allow the sensor to see clean air, and then press **[RESET]** to exit. Go to Section 4.5 for calibration instructions.

NOTE: The default gas concentration level for calibrating all GM sensors is 50% of full-scale. You can change this default *for catalytic HC sensors only* via the **Cal Pnt** menu option.

7. Once you have pressed **[ENTER]** to begin calibration, the message **Cal in Progress** flashes on the LCD display. Make sure that gas is still applied to the sensor.
8. When the message **Remove Gas** appears, stop applying gas and remove the calibration cup from the sensor. The reading will return to normal Operation Mode.

4.8 Inhibiting Alarms for Selected Channels

The **Inhibit** main menu option allows you to inhibit alarm relays from being triggered for the selected channel(s); the inhibition can be reset once the need for it is finished. This option is provided to inhibit the alarms for a channel connected to a 4-20mA instrument, before gas is applied to the instrument during a calibration or calibration check.

You can also use this menu option to complete a manual calibration check for connected catalytic HC and MOS H₂S sensors, without entering Calibration Check Mode.

To Inhibit an Alarm for a Selected Channel:

1. Press the **[MODE]** button to exit from Operation Mode and enter the MC600 menus. The main menu option **Menu Cal** appears.
2. Press **[▲]** to move to the **Menu Inhibit** option. Press **[ENTER]** to move to the **Inhibit Chan #1** prompt.

NOTE: If a password is currently enabled, you will be prompted to enter it before you can access the **Inhibit** menu. Press the **[▲]** and **[▼]** arrow buttons to scroll through the alphanumeric characters for each digit in the password, and press the **[ACCEPT]** and **[RESET]** buttons to move between password digits.

3. Press the **[▲]** and **[▼]** arrow buttons to select which channel device you will be inhibiting, from 1 to 6.
4. Once you have selected a channel, press **[ENTER]** to move to the **Chn1 Inh Set** prompt.
5. To finish inhibiting the alarm, press **[ENTER]** again. The **Inhibit Chan #1** prompt will reappear.
6. Press the **[MODE]** button to return to Operation mode. The inhibited channel will display a flashing "I" in the lower right corner.

To Restore an Inhibited Alarm:

1. Press the **[MODE]** button to exit from Operation Mode and enter the MC600 menus. The first main menu option **Menu Cal** appears.
2. Press **[▲]** to move to the option **Menu Inhibit**. Press **[ENTER]** to move to the **Inhibit Chan #1** prompt.
3. Press the **[▲]** and **[▼]** arrow buttons to select which channel device you will be restoring, from 1 to 6.
4. Once you have selected a channel, press **[ENTER]** to move to the **Chnn Inh Set** prompt.
5. Press the **[▲]** button once to move to **Chnn Inh Reset**, and then press **[ENTER]** again. The **Inhibit Chan #n** prompt will reappear.
6. Press the **[MODE]** button to return to Operation mode. The flashing "I" in the lower right corner will not appear any longer.

4.9 Using the Basic Setup Menu Options

The **Menu Setup** main menu option is the gateway to eight Setup submenus for configuring different portions of your MC600 system. You will need to use only two of these submenus directly after you start up your MC600 system:

Setup Channels. Step-by-step instructions are provided in this chapter for configuring Alarm and Warning set points, and a calibration point for catalytic HC sensors only.

Setup Relays. Step-by-step instructions are provided in this chapter for configuring Alarm and Warning relay options, such as Energized vs. De-Energized, Latching vs. Non-Latching or Timed from 1-120 minutes.

The remaining six Setup submenus are used more rarely, and are considered advanced options; they are **Setup Zoning**, **Setup Card Test**, **Setup Password**, **Setup Fault Relay**, **Setup MODBUS**, and **Setup Load Defaults**. They are described in detail in Section 5.0.

NOTE: The **Options Model** portion of this submenu is needed only if you are upgrading your system with additional signal conditioning cards; it is described in Section 5.0.

Upon enter the Menu Setup, the Fault LED indicator will be flashing




Figure 33: Setup Channels Submenu

Note: For ultrasonic products, the default setting for Alarm Hi, Alarm Lo and Warning is 79dB




Figure 34: Alarm Delay Setup

4.9.1 Configuring Alarm and Warning Set points

The following rules must also be followed, regarding the boundaries between the Alarm High, Alarm Low, and Warning set points.

The Alarm High set point must be greater than or equal to the Alarm Low set point. Table 5 lists the Alarm High set point maximum for each General Monitors MC600-compatible sensor and instrument. The maximum set point value for catalytic HC sensors and HC instruments can not exceed 60% LEL (or v/v). The maximum set point varies for MOS H₂S sensors and non-HC instruments.

The default setting for the Alarm High set point is always 60% of the full-scale (maximum display) value, as calculated in %LEL, %v/v or ppm units.

The Alarm Low set point for all sensors and instruments must be less than or equal to the Alarm High set point, and greater than or equal to the Warning set point.

The default setting for the Alarm Low set point is always 45% of the full-scale (maximum display) value, as calculated in %LEL, %v/v or ppm units.

The Warning set point for all sensors and instruments must be less than or equal to the Alarm Low set point. The minimum Warning set point for catalytic HC sensors and HC instruments must be at least 5% of full-scale. The minimum set point varies for different MOS H₂S sensors and non-HC instruments, as listed in Table 5.

The default setting for the Warning set point is always 30% of the full-scale (maximum display) value, as calculated in %LEL, %v/v or ppm units.

Ultrasonic products, the Warning set point, Alarm Low and Alarm high are always the same level and the default set point is 79dB. If user changes any above set point, MC600 will automatically update the rest of the set points to the new set point.

Table 5 lists alarm and warning set point information for each sensor and instrument that is compatible with the MC600.

Sensor / Instrument Model	Display Value Full Range	Display Increment	Warning Min. Set point	Alarm High Max. Set point	Set point Increment
Catalytic HC sensors (all)	0-100% LEL	1% LEL	5% LEL	60% LEL	5% LEL
MOS H ₂ S sensors, 20 ppm	0-20 ppm	1 ppm	1 ppm	19 ppm	1 ppm
MOS H ₂ S sensors, 50 ppm	0-50 ppm	1 ppm	5 ppm	45 ppm	1 ppm
MOS H ₂ S sensors, 100 ppm	0-100 ppm	1 ppm	5 ppm	95 ppm	5 ppm
TS400, CLO ₂ (Chlorine Dioxide)	0-3 ppm	.1 ppm	.2 ppm	2.9 ppm	.1 ppm
TS400, CL ₂ (Chlorine)	0-10 ppm	.1 ppm	.5 ppm	9.5 ppm	.1 ppm
TS400, CO, 100 (Carbon Monoxide)	0-100 ppm	1 ppm	5 ppm	95 ppm	1 ppm
TS400, CO, 500 (Carbon Monoxide)	0-500 ppm	1 ppm	25 ppm	475 ppm	5 ppm
TS400, HCL (Hydrogen Chloride)	0-20 ppm	.1 ppm	1 ppm	19 ppm	.1 ppm
TS400, NO (Nitric Oxide)	0-100 ppm	1 ppm	5 ppm	95 ppm	1 ppm
TS400, NO ₂ (Nitrogen Dioxide)	0-20 ppm	.1 ppm	1 ppm	19 ppm	.1 ppm
TS400, SO ₂ (Sulfur Dioxide)	0-20 ppm	.1 ppm	1 ppm	19 ppm	.1 ppm

Sensor / Instrument Model	Display Value Full Range	Display Increment	Warning Min. Set point	Alarm High Max. Set point	Set point Increment
TS400, H ₂ S, 20	0-20 ppm	0.1 ppm	1 ppm	19 ppm	0.1 ppm
TS400, H ₂ S, 50	0-50 ppm	0.5 ppm	10 ppm	45 ppm	0.5 ppm
TS400, H ₂ S, 100	0-100 ppm	1 ppm	5 ppm	95 ppm	1 ppm
TS420 (Oxygen)	0-25% v/v	+ .1% v/v	1.3% v/v	20% v/v	0.1% v/v
TS4000/H, CLO ₂ (Chlorine Dioxide)	0-3 ppm	.01 ppm	0.15 ppm	2.85 ppm	.03 ppm
TS4000/H, CL ₂ , 10 (Chlorine)	0-10 ppm	0.1 ppm	0.5 ppm	9.5 ppm	0.1 ppm
TS4000/H, CL ₂ , 20 (Chlorine)	0-20 ppm	0.1 ppm	1 ppm	19 ppm	0.2 ppm
TS4000/H, CO, 100 (Carbon Monoxide)	0-100 ppm	1 ppm	5 ppm	95 ppm	1 ppm
TS4000/H, CO, 500 (Carbon Monoxide)	0-500 ppm	1 ppm	25 ppm	475 ppm	5 ppm
TS4000/H, HCL (Hydrogen Chloride)	0-20 ppm	0.1 ppm	1 ppm	19 ppm	0.2 ppm
TS4000/H, NO (Nitric Oxide)	0-100 ppm	1 ppm	5 ppm	95 ppm	1 ppm
TS4000/H, NO ₂ (Nitrogen Dioxide)	0-20 ppm	0.1 ppm	1 ppm	19 ppm	0.2 ppm
TS4000/H, SO ₂ , 20 (Sulfur Dioxide)	0-20 ppm	0.1 ppm	1 ppm	19 ppm	0.2 ppm
TS4000/H, SO ₂ , 100	0-100 ppm	1 ppm	5 ppm	95 ppm	1 ppm
TS4000/H, O ₃ (Ozone)	0-1 ppm	.01 ppm	.05 ppm	.95 ppm	.01 ppm
TS4000/H, O ₂ (Oxygen)	0-25% v/v	+ .1% v/v	1.5% v/v	20% v/v	.25% v/v
TS4000/H, H ₂ S, 20	0-20 ppm	0.1 ppm	1 ppm	19 ppm	0.2 ppm
TS4000/H, H ₂ S, 50	0-50 ppm	0.1 ppm	2.5 ppm	47.5 ppm	0.5 ppm
TS4000/H, H ₂ S, 100	0-100 ppm	1 ppm	5 ppm	95 ppm	1 ppm
IR2100 (Infrared HC)	0-100% LEL	1% LEL	5% LEL	60% LEL	5% LEL
IR400 (Infrared HC)	0-100% LEL	1% LEL	5% LEL	60% LEL	5% LEL
IR2100 (Infrared HC)	0-100% v/v	1% v/v	5% v/v	60% v/v	5% v/v
IR400 (Infrared HC)	0-100% v/v	1% v/v	5% v/v	60% v/v	5% v/v
IR5000 (Infrared HC) Methane	0-5000 ppm	100 ppm	1500 ppm	4500 ppm	100 ppm
IR5000 (Infrared HC) Methane	0-5% LEL	0.1% LEL	0.5% LEL	4.5% LEL	0.1% LEL

Sensor / Instrument Model	Display Value Full Range	Display Increment	Warning Min. Set point	Alarm High Max. Set point	Set point Increment
IR5000 (Infrared HC) Propane	0-2000 ppm	100 ppm	600 ppm	1800 ppm	100 ppm
IR5000 (Infrared HC) Propane	0-1% LEL	0.1 %LEL	0.1% LEL	0.8% LEL	0.1% LEL
IR7000 (CO ₂)	0-5000 ppm	50 ppm	250 ppm	4750 ppm	250 ppm
IR700 (CO ₂)	0-2000 ppm	20 ppm	100 ppm	1900 ppm	100 ppm
IR700 (CO ₂)	0-5000 ppm	50 ppm	250 ppm	4750 ppm	250 ppm
IR700 (CO ₂)	0-10000 ppm	100 ppm	500 ppm	9500 ppm	500 ppm
IR700 (CO ₂)	0-30000 ppm	300 ppm	1500 ppm	28500 ppm	1500 ppm
IR700 (CO ₂)	0-50000 ppm	500 ppm	2500 ppm	47500 ppm	2500 ppm
S4000C/H (Catalytic HC)	0-100% LEL	1% LEL	5% LEL	60% LEL	5% LEL
S4000T/H -20 (MOS H ₂ S)	0-20 ppm	1 ppm	1 ppm	19 ppm	1 ppm
S4000T/H -50 (MOS H ₂ S)	0-50 ppm	1 ppm	5 ppm	45 ppm	1 ppm
S4000T/H -100 (MOS H ₂ S)	0-100 ppm	1 ppm	5 ppm	95 ppm	5 ppm
S4100C (Catalytic HC)	0-100% LEL	1% LEL	5% LEL	60% LEL	5% LEL
S4100T-20 (MOS H ₂ S)	0-20 ppm	1 ppm	1 ppm	19 ppm	1 ppm
S4100T-50 (MOS H ₂ S)	0-50 ppm	1 ppm	5 ppm	45 ppm	1 ppm
S4100T-100 (MOS H ₂ S)	0-100 ppm	1 ppm	5 ppm	95 ppm	5 ppm
S104 (Catalytic HC)	0-100% LEL	1% LEL	5% LEL	60% LEL	5% LEL
S106A (Catalytic HC)	0-100% LEL	1% LEL	5% LEL	60% LEL	5% LEL
S214-20 (MOS H ₂ S)	0-20 ppm	1 ppm	1 ppm	19 ppm	1 ppm
S214-50 (MOS H ₂ S)	0-50 ppm	1 ppm	5 ppm	45 ppm	1 ppm
S214-100 (MOS H ₂ S)	0-100 ppm	1 ppm	5 ppm	95 ppm	5 ppm
S216A-20 (MOS H ₂ S)	0-20 ppm	1 ppm	1 ppm	19 ppm	1 ppm
S216A-50 (H ₂ S)	0-50 ppm	1 ppm	5 ppm	45 ppm	1 ppm
S216A-100 (H ₂ S)	0-100 ppm	1 ppm	5 ppm	95 ppm	5 ppm
OBSERVER, OBSERVER-H	58- 104 dB	1 dB	64dB	99 dB	5 dB
SURVEYOR	44- 104 dB	1 dB	54 dB	99 dB	5 dB
TS4000H, H ₂ , 500 (Hydrogen)	0-500 ppm	1 ppm	25 ppm	475 ppm	5 ppm
IR5500 (Infrared HC) Methane	0-5000 ppm	100 ppm	1500 ppm	4500 ppm	100 ppm

Sensor / Instrument Model	Display Value Full Range	Display Increment	Warning Min. Set point	Alarm High Max. Set point	Set point Increment
IR5500 (Infrared HC) Methane	0-5% LEL	0.1% LEL	0.5% LEL	4.5% LEL	0.1% LEL
IR5500 (Infrared HC) Propane	0-2000 ppm	100 ppm	600 ppm	1800 ppm	100 ppm
IR5500 (Infrared HC) Propane	0-1% LEL	0.1 %LEL	0.1% LEL	0.8% LEL	0.1% LEL

Table 5: MC600 Device Measurement Ranges, Minimum and Maximum Set Points and Increments

To Set the Alarm and Warning Set points for Each Channel:

1. Press the **[MODE]** button to exit from Operation Mode and enter the MC600 menus. The main menu option **Menu Cal** appears first.
2. Press **[▲]** to move to the **Menu Setup** option. Press **[ENTER]** to move to the **Setup Channels** prompt.

NOTE: If a password is currently enabled, you will be prompted to enter it before you can access the **Setup** menu. Press the **[▲]** and **[▼]** arrow buttons to scroll through the alphanumeric characters for each digit in the password, and press the **[ACCEPT]** and **[RESET]** buttons to move between password digits.

3. Once the Setup Channels prompt appear, press **[ENTER]** to display **Channel #1**. Press the **[▲]** and **[▼]** arrow buttons to select a channel, from 1 to 6.
4. Once you have selected a channel, press **[ENTER]** to move to the **Options Model** prompt, then press **[▲]** once to move to the **Options Alarms** prompt.
5. Press **[ENTER]** again to move to the **Alarm Hi** prompt, then press **[ENTER]** to view the current (default) set point value.
6. To change the set point value, press the **[▲]** and **[▼]** arrow buttons to cycle through the allowable values. Once the set point value you wish to select appears, press **[ENTER]** to select it and return to the **Alarm Hi** prompt.

Table 5 lists the maximum and minimum allowable alarm and warning set points for each sensor device and instrument that is compatible with the MC600.

If the full range listed in Table 5 does not appear when you are scrolling through the set point values, this is because the other two set points restrict your selection (the Alarm Hi, Alarm Lo and Warning set points may not overlap).

7. Once the **Alarm Hi** prompt reappears, you can press the **[▲]** and **[▼]** arrow buttons to select Alarm Lo or Warning, then press **[ENTER]** to view the current set point value, and modify it as described in Step 6.
8. To exit from the menus and save your changes, press **[MODE]**. The prompt **Save? Yes** will appear before you can return to Operation Mode.

Press **[ENTER]** to save your changes in permanent memory and return to Operation Mode.

To cancel your changes and return to Operation Mode, press **[▲]** to display **Save? No**, then press **[ENTER]**.

4.9.2 Configuring alarm delay time (ultrasonic products only)

When sound level is equal or above the Warn/Alarm set point, the MC600 will flash the WARN LED. When the time delay is expired, the MC600 will then flash **W A A**

the ALARM LED, activate the relays and flash **Ⓜ ℓ Ⓜ** on the channel LCD. There are four choices of selecting the time delay: 10, 15, 20 and 25 seconds. See figure 37b for setting up the alarm delay time

4.9.3 Configuring a Calibration Point for Catalytic HC Sensors

The default setting for MC600 calibration is 50% LEL for catalytic HC sensors. Many hydrocarbon gases are calibrated at 50% LEL. However, in case the catalytic HC sensor will be used to detect a gas that requires a different calibration point, the **Cal Pnt** menu option allows you to adjust the calibration point between 25% LEL and 95% LEL.

To Configure a Calibration Point for Catalytic HC Sensors:

1. Press the **[MODE]** button to exit from Operation Mode and enter the MC600 menu; the main menu option **Menu Cal** appears first.
2. Press **[▲]** to move to the **Menu Setup** option. Press **[ENTER]** to move to the **Setup Channels** prompt.

NOTE: If a password is currently enabled, you will be prompted to enter it before you can access the **Setup** menu. Press the **[▲]** and **[▼]** arrow buttons to scroll through the alphanumeric characters for each digit in the password, and press the **[ACCEPT]** and **[RESET]** buttons to move between password digits.

3. Once the Setup Channels prompt appears, press **[ENTER]** again to display **Channel #1**. Press the **[▲]** and **[▼]** arrow buttons to select a channel, from 1 to 6.
4. Once you have selected a channel, press **[ENTER]** then press **[▲]** to move to the **Options Cal Pnt** prompt.
5. Press **[ENTER]** again to move to the default setting, **Cal Pnt 50 %LEL**.
6. Press the **[▲]** and **[▼]** arrow buttons to select a different calibration point, and then press **[ENTER]** to select that value.
7. To exit from the menus and save your changes, press **[MODE]**. The prompt **Save? Yes** will appear before you can return to Operation Mode.

Press **[ENTER]** to save your changes in permanent memory and return to Operation Mode.

To cancel your changes and return to Operation Mode, press **[▲]** to display **Save? No**, then press **[ENTER]**.

4.9.4 Configuring the MC600 Relays

The MC600 **Setup Relays** submenu provides options to configure several settings for the six MC600 Alarm and Warning relays: Latching or Non-Latching, as well as Timed, Energized or De-Energized. In addition, you can configure the minimum time duration for an activated relay (in minutes). The default setting for all of the relays is Non-Latching, De-Energized. The minimum time interval to leave a timed relay activated is one minute.

The allocation of relays to channels is determined by the zoning configuration for the MC600. We assume, in this section, that you are using the default factory configuration for zoning, which is shown in Table 6. See Section 5.0 for instructions on changing the zoning configuration for the MC600.

Number of Zones	Alarm State	Channels	Relays
1	Alarm High	1-6	1 and 2
	Alarm Low	1-6	3 and 4
	Warning	1-6	5 and 6

Table 6: Default Allocation of Relays to Channels and Alarms




Figure 35: Setup Relays Submenu

To Configure the Relays:

1. Press the **[MODE]** button to exit from Operation Mode and enter the MC600 menus; the main menu option **Menu Cal** appears first.
2. Press **[▲]** to move to the **Menu Setup** option, then press **[ENTER]** to move to the **Setup Channels** prompt.

NOTE: If a password is currently enabled, you will be prompted to enter it before you can access the **Setup** menu. Press the **[▲]** and **[▼]** arrow buttons to scroll through the alphanumeric characters for each digit in the password, and press the **[ACCEPT]** and **[RESET]** buttons to move between password digits.

3. Press **[▲]** to move to the **Setup Relays** submenu prompt. Press **[ENTER]** to move to the relay selection options. **Relay #1** appears first.
4. Press **[ENTER]** to select **Relay #1** or press **[▲]** to choose a relay from 2 to 6, then press **[ENTER]**.
5. The **Options State** prompt will then appear. Press **[ENTER]** to view the first relay state option, which is **De-Energized**.
6. Press **[ENTER]** to select **De-Energized** or press an arrow button to move to **Energized**. Press **[ENTER]** to select it. Once you select a state setting, the **Options State** prompt will reappear.
7. Press **[▲]** to move to the **Options Mode** prompt, then press **[ENTER]** to view the first Mode setting, which is **Mode Nlatched**.
8. Press **[ENTER]** to select **Mode Nlatched** or press an arrow button to move to **Mode Latched** or **Mode Timed** and then press **[ENTER]**.

If you select **Mode Nlatched** or **Mode Latched** and then press **[ENTER]**, the **Options State** prompt will reappear.

If you select **Mode Timed** and press **[ENTER]**, you will be prompted to specify a minimum time for the relay to remain activated. The default is one minute, but you can press the arrow buttons to view values from 1-120 minutes. Press **[ENTER]** to select a value.

9. To exit from the menus and save your changes, press **[MODE]**. The prompt **Save? Yes** will appear before you can return to Operation Mode.

Press **[ENTER]** to save your changes in permanent memory and return to Operation Mode.

To cancel your changes and return to Operation Mode, press **[▲]** to display **Save? No**, then press **[ENTER]**.

5.0 Advanced Configuration

This chapter describes the MC600 configuration options for secondary tasks that are needed less often than the basic tasks, such as:

- Selecting the Model for a channel after you have added a new card and/or device.
- Selecting the channel mode for the alarm and warning indicators.
- Setting up zoning groups for the connected sensors and instruments, in order to allocate and configure the MC600 alarm relays.

Changing the default MODBUS communication parameters and setting passwords.




Figure 36: MC600 Advanced Menu Options

NOTE: The Advanced menu areas described in Figure 39 are shown shaded.

5.1 Using the Advanced Setup Menu Options

The **Menu Setup** main menu option is the gateway to eight submenus for configuring different portions of your MC600 system. Most of these submenus are used relatively rarely and they are described in this section.

NOTE: If a password is enabled, you must enter it before you can access the **Inhibit** or **Setup** submenus. Press the [▲] and [▼] arrow buttons to scroll through the alphanumeric characters for each digit in the password, and press the [ACCEPT] and [RESET] buttons to move between password digits. The default setting is password disabled.

Setup Channels, Options Model: Step-by-step instructions are provided in this section for selecting a device model for each channel, after you upgrade the MC600 system. (Information on the basic portions of the **Setup Channels** submenu is provided in Section 4.0.)

Setup Channels, Options Mode: Includes options for configuring the channel Warning and Alarm indicators as Latching or Non-Latching.

Setup Zoning: Includes options for configuring zoning and voting for multiple channel-based alarms.

Setup Card Test: Includes options for signal-conditioning card diagnostics.

Setup Password: Includes options for configuring passwords to restrict access to the Setup and Inhibit submenus.

Setup Fault Relay: Includes options for configuring the Fault Relays.

Setup MODBUS: Includes options for configuring communications settings for MC600 MODBUS communications, such as the data format and baud rate.

Setup Load Defaults: Reloads a default MC600 configuration.

5.1.1 Selecting a Model Option

Your MC600 system is already set up at the factory for you by General Monitors, based on the Models of catalytic HC sensors, MOS H₂S sensors and 4-20mA instruments that you have ordered. A label directly above the signal conditioning cards indicates which device is installed in each channel.

However, if you install a field upgrade, such as installing additional signal conditioning cards or connecting different devices to your existing 4-20mA signal conditioning cards, you will need to use the **Options Model** submenu to reconfigure the channel(s).

Once you select a channel within the **Setup Channels** submenu, the **Options Model** submenu will display only the model options for the installed signal-conditioning card.

Figure 41 shows the large number of Model options you may select for channels with 4-20mA signal-conditioning cards installed.




Figure 37: Setup Channels, Options Model Submenu




Figure 38: Model Options for a 4-20mA Signal Conditioning Card

To Select a Model Option:

1. Press the **[MODE]** button to exit from Operation Mode and enter the MC600 menus. The first main menu option **Menu Cal** appears.
2. Press **[▲]** to move to the option **Menu Setup**. Press **[ENTER]** to move to the **Setup Channels** prompt.
3. At the **Setup Channels** prompt, press **[ENTER]** to display **Channel #1**. Press the **[▲]** and **[▼]** arrow buttons to select a channel, from 1 to 6.
4. Once you have selected a channel, press **[ENTER]** to move to the **Options Model** prompt. Press **[ENTER]** again to view the beginning of the list of Models.
5. Navigate through the Model options using the **[▲]** and **[▼]** buttons, then press **[ENTER]** to select a Model. Press **[ENTER]** again to complete your selection and redisplay the **Options Model** prompt.
6. To exit from the menus and save your changes, press **[MODE]**. The prompt **Save? Yes** will appear before you can return to Operation Mode.

Press **[ENTER]** to save your changes in permanent memory and return to Operation Mode.

To cancel your changes and return to Operation Mode, press **[▲]** to display **Save? No**, then press **[ENTER]**.

NOTE: When an IR5000/IR5500 Instrument is selected, it should have the following settings for analog output values:

Fault - 0mA

Beam Block – 2mA

Analog output 1 during test gas – 1.5mA

Analog output 2 during test gas – 1.5mA

This will allow the MC600 to detect fault, beam block, and off-line conditions.

5.1.2 Selecting the Channel Mode for the Alarm and Warning Indicators

The MC600 features individual indicators for the Warning, Alarm Low and Alarm High on each of the six channel's displays.

The MC600 allows the user to select the operating mode of the channel display. Similar to the Latching/Non-Latching option available for the Relays, this option allows the user to set the channel Warning and Alarm indicators to latch after the gas being monitored has exceeded the Warning and Alarm set points. In order to clear a latched Warning or Alarm from a channel's display, it must first be accepted and then reset. After an alarm has been accepted, the corresponding indicator will stop flashing. A Warning or Alarm indicator can only be cleared if the gas level has moved below the corresponding set point for the channel.

Figure 39 shows the Option Mode submenu of the Setup Channels menu.

5.1.3 Configuring Zoning (for Relay Allocation)

The **Setup Zoning** submenu provides several options for creating zones and assigning relays to MC600 channels. The default configuration is for one zone. If you select a configuration of “0 Zones” a set of menu options lets you assign each of the six MC600 relays to the Alarm High, Alarm Low or Warning state of a particular MC600 channel. With zero zoning selected, all relays default to unassigned.

You may also create two or three zones in order to share the six relays among several channels. This changes the allocation of relays to channels according to a set arrangement shown in the following table. With zoning implemented, you can configure single or dual voting for each zone; voting determines how many channels must be in an alarm or warning state to activate the relay. The default number of votes is single.




Figure 39: Option Mode Submenu

Number of Zones	Zone	Alarm State	Channels	Relays
0	N/A	User-defined	User-defined	User-defined
1 (default)	1	High	1-6	1 and 2
	1	Low	1-6	3 and 4
	1	Warning	1-6	5 and 6
1 Horn	1	High	1-6	1 and 2
	1	Low	1-6	3 and 4
	1	Warning	1-6	5
	1	Horn	1-6	6
2	1	High	1-3	1
	1	Low	1-3	2
	1	Warning	1-3	3
	2	High	4-6	4
	2	Low	4-6	5
	2	Warning	4-6	6
3	1	High	1-2	1
	1	Low	1-2	N/C
	1	Warning	1-2	2
	2	High	3-4	3
	2	Low	3-4	N/C
	2	Warning	3-4	4
	3	High	5-6	5
	3	Low	5-6	N/C
	3	Warning	5-6	6

Table 7: Zoning Options and Relay Assignments




Figure 40: Zoning Submenu




Figure 41: Relay Assignment Options with No Zoning

5.1.4 Configuring Horn Relay

If “1 zone” option is selected, the horn relay can be configured and is assigned to relay 6. If any of the channels generate a warning or low or high alarm, the horn will activate. Pressing the ACCEPT button will silence the horn.

To select the horn option, enter “1 zone” submenu of setup zoning menu and select “1 zone sgl horn” for single vote or “1 zone dl horn” for dual vote. Figure 42 shows zoning submenu options.

5.1.5 Configuring Card Tests

The **Setup Card Test** submenu allows you to configure the relays as Active or Not Active during a Card Test. In addition, you can configure the Ramp Time, which determines how quickly the signals increase from zero to full-scale during the Card Test.

If you make changes to the Relays or Ramp Time parameters, you will be prompted to save your changes once you press [MODE] to exit from the menu system.




Figure 42: Setup Card Test Submenu

5.1.6 Configuring Setup and Inhibit Passwords

By default, the MC600 password is disabled. The **Setup Password** submenu includes options for leaving the system password disabled (the default), enabling a default password ("FACT") or defining a new password string.

Once a password is enabled, you will be prompted to enter a password when you attempt to gain access to the Setup and Inhibit menus.

If you make changes to the password settings, you will be prompted to save your changes once you press [MODE] to exit from the menu system.




Figure 43: Setup Password Submenu

To Define a Password:

1. Press the **[MODE]** button to exit from Operation Mode and enter the MC600 menus. The first main menu option **Menu Cal** appears.
2. Press **[▲]** to move to the **Menu Setup** main menu option. Press **[ENTER]** to move to the **Setup Channels** prompt.

NOTE: If a password is currently enabled, you will be prompted to enter it before you can access the **Setup** menu. Press the **[▲]** and **[▼]** arrow buttons to scroll through the alphanumeric characters for each digit in the password, and press the **[ACCEPT]** and **[RESET]** buttons to move between password digits.

3. Once the **Setup Channels** prompt appears, press the **[▲]** and **[▼]** arrow buttons to move to the **Setup Password** submenu.
4. Press **[ENTER]** to view the first option, **Password Disable**. Either press **[ENTER]** to disable use of passwords, or press the **[▲]** button move to the **Password Set** option, then press **[ENTER]**.
5. The default system password is "FACT". Either press **[ENTER]** to use the default, or define a new 4-digit password string.
Press the **[▲]** and **[▼]** arrow buttons to scroll through the alphanumeric characters for each digit in the password,
Press the **[ACCEPT]** and **[RESET]** buttons to move between password digits.
6. Press **[ENTER]** to complete your password definition. To exit from the menus and save your changes to the password, press **[MODE]**. The prompt **Save? Yes** will appear before you can return to Operation Mode.
Press **[ENTER]** to save your changes in permanent memory and return to Operation Mode.
To cancel your changes and return to Operation Mode, press **[▲]** to display **Save? No**, then press **[ENTER]**.

NOTE: Password information is retained in nonvolatile memory. Care must be exercised in setting and enabling a password. If the password is lost or forgotten, it cannot be reset by cycling power.

5.1.7 Configuring the Fault Relays

This **Setup Flt Relay** submenu includes options for configuring the Fault Relays so that a Fault LED will light and the Fault Relay will change state when the MC600 is in Calibration or Calibration Check Mode, or upon entering the Setup menus.

The default setting for the Fault Relay is **ON** during Calibration and Setup. If you make changes to the Fault Relay settings, you will be prompted to save your changes once you press [MODE] to exit from the menu system.




Figure 44: Setup Fault Relays Submenu

5.1.8 Configuring MODBUS Parameters

The **Setup MODBUS** submenu includes options for configuring communications parameters for the two MC600 MODBUS channels, such as the Address, Data Format and Baud Rate. The default settings are:

- The default Address setting is 1 for MODBUS Channel 1, and the default address setting is 2 for MODBUS Channel 2. The range of allowable addresses is 1-247 (decimal).
- The selectable Baud Rates are 19,200, 9600, 4800, or 2400 bits per second. The default setting for both channels is 19,200.
- The default Data Format setting for both channels is 8 data bits, no parity, and 1 stop bit. The data formats you can select are shown in Figure 45.

If you make changes to the default settings, you will be prompted to save your changes once you press **[MODE]** to exit from the menu system.




Figure 45: Setup MODBUS Submenu

5.1.9 Loading Default Settings

The **Setup Load Defaults** submenu includes options to reload a simplified set of defaults for the MC600, consisting of the following settings:

All channels are set to empty. If there are signal-conditioning cards installed in the six channel slots, they will all be flashing the message **Set-Up Channel**.

Relays are set for a single zone with one vote, Non-Latching and De-Energized.

MODBUS channel settings are as follows:


- Addresses set to 1 for Channel 1, and 2 for Channel 2
- Baud Rate set to 19200 bps
- Data Format set to 8 data bits, no parity, and 1 stop bit

Fault Relay is ON during calibration and setup

Card Test settings are for Relays Active and Ramp Time = 10 seconds

Setup and Inhibit menu password disabled, and set to "FACT" by default

- Maximum and minimum temperatures cleared.



NOTE: Loading defaults will delete all six-channel definitions, and you will have to reconfigure them

Figure 46: Setup Load Defaults Submenu

5.2 Using the Setup Check Menu

The Menu StupChck submenu provides a read-only summary of the current configuration settings for the MC600 channels. Data is shown in the LCD windows for each channel populated with a signal card, rather than just in Channel 1. The following flowchart shows how to navigate among the different groups of settings.




Figure 47: Setup Check Menu

5.3 Using the Self Test Menu

The **Menu Self Tst** submenu provides two types of tests:

Card Test. The Card Test ramps the signal from zero to full-scale for all channels that have card test set in this menu. Once you select channels to test, you can press **[MODE]** to start the test. For example, if Channels One, Two and Three all have card test set, then the signals for those channels will all ramp up once you press **[MODE]**. You will need to select the channels again in order to rerun the test

The **Card Test Setup** menu (see *Configuring Card Tests*) in Section 5.1.5) determines how fast the signal will be ramped during the test (Ramp Time), and whether the Alarm and Warning relays will be active during the test. If the relays are Active during the test, then the Warning and Alarm signals will be triggered as the signal to the channel exceeds the relay set points.

- **Display Test.** The Display Test darkens all segments of the six LCD channel displays. If they are not all darkened, this indicates an LCD malfunction. In addition, this test turns the READY, FAULT, ALARM and WARN LEDs on.




Figure 48: Self-Test Menu

6.0 Customer Support

Area	Phone / Email
UNITED STATES 26776 Simpatica Circle Lake Forest, CA 92630	Phone: +1-949-581-4464. 800-446-4872 Email: info.gm@MSAsafety.com
9776 Whithorn Drive Houston, TX 77095	Phone: +1-281-855-6000
UNITED KINGDOM Heather Close Lyme Green Business Park Macclesfield, Cheshire, United Kingdom, SK11 0LR	Phone: +44-1625-619-583
IRELAND Ballybrit Business Park Galway Republic of Ireland, H91 H6P2	Phone: +353-91-751175
SINGAPORE Block 5, Amk Tech II, #05-20/22/23 Ang Mo Kio Industrial Park 2A Singapore 567760	Phone: +65-6748-3488
MIDDLE EAST PO Box 54910 Dubai Airport Free Zone United Arab Emirates	Phone: +971-4294 3640

Table 8: Locations

Additional locations can be found on our web site, www.MSAsafety.com

7.0 Maintenance

Maintenance activities for the MC600 include periodic calibration and calibration checks for connected catalytic HC and MOS H₂S sensors, cleaning and lubrication, as needed. Maintenance for connected 4-20mA instruments is described in the instruction manuals for those instruments

NOTE: The system's full two-year warranty will be voided if customer personnel or third parties damage the system during repair attempts or maintenance activities.



WARNING: Disconnect or inhibit external devices, such as, Trip Amplifiers, PLC or DCS systems before performing any maintenance.



CAUTION: Each MOS H₂S Sensor is shipped with a red plastic cap fitted over the sensor head. Inside the cap is a desiccant. DO NOT remove this cap until you have applied power to the sensors. SAVE the cap and RE-CAP the sensor anytime the system power is off for more than one hour.

7.1 Developing a Maintenance Schedule

Maintenance requirements will vary with each installation; General Monitors recommends that a schedule for periodic maintenance be established and followed and that a maintenance logbook be kept for each MC600 unit and sensor in operation. Specific recommendations for scheduling calibration and calibration checks are provided in the following section.

7.2 Calibration and Calibration Checks

General Monitors recommends that you calibrate each catalytic HC sensor one hour after the MC600 system start-up. MOS H₂S sensors should be calibrated an hour after start-up, then again after 24 hours of operation. During ongoing operation, the calibration for both catalytic and MOS H₂S sensors should be checked at least every ninety (90) days to ensure system integrity. Frequent calibration checks ensure the integrity of the life-protecting equipment.

More frequent cleaning and calibration checks are recommended if the equipment is impacted by unusual environmental conditions such as mud collecting on the sensor head, sensors accidentally being painted over, etc.

7.2.1 Alternate Calibration Equipment

Section 4.5.3, **Sensor Calibration Equipment**, describes how to calibrate sensors using the most common equipment, the portable purge calibrator for catalytic HC sensors and breaker bottles (Field Calibrators) with gas ampoules for H₂S sensors. There are several alternate types of calibration equipment you can use, which are briefly described here. Ordering information for all of the calibration equipment is provided in Section 11.0.

7.2.1.1 Remote TGA-1 for Hydrocarbon Calibration

The General Monitors remote test gas applicator, TGA-1, is designed to be permanently installed on a combustible gas sensor. The TGA-1 provides

protection from outside elements and it allows the user to apply a test gas to the sensor from a remote source.




Figure 49: Remote Test Gas Applicator (TGA-1)

7.2.1.2 Three-Liter Chamber for Hydrocarbon Calibration

The 3-Liter Portable Calibration Chamber is used as an alternate to the more typical portable purge calibrator when the sensor is calibrated with solvent vapors. It is a practical and safe instrument for the field calibration of combustible gas monitoring systems. Sensors can be calibrated in place with a known liquid/air mixture, reducing the possibility of calibration error.

The Portable Calibration Chamber is a 3-liter sample chamber with an intrinsically safe battery-powered mixing fan. For catalytic bead sensors, a porthole allows the chamber to be placed on the sensor for calibration.



Figure 50: Three-Liter Chamber for Liquid and Solvent Vapors

Before using the 3-Liter Chamber, make sure the following is present:

3-Liter Chamber

Dish

250 micro liter syringe

Correct volume of solvent/liquid for calibration and calibration checks.

7.2.1.3 H₂S Portable Purge Calibrator

General Monitors recommends using breaker bottles and glass ampoules for calibrating H₂S gas detection instruments. However, the H₂S Portable Purge Calibrator is available for applications where a calibration method of flowing H₂S gas to the sensor might provide a better calibration source (e.g. high humidity environments).

The H₂S Portable Purge Calibrator is a compact, practical, accurate and safe system for field calibration of H₂S sensors. The cylinder is filled with an H₂S in air mixture in one of seven separate parts per million (ppm) levels of concentration (10, 20, 25, 35, 50, 70 or 100). Using a known air/gas mixture reduces the possibility of error in field calibration.

NOTE: Do not store the cylinder with the regulator fully engaged in the cylinder valve.



Figure 51: H₂S Portable Purge Calibrator

The Portable Purge Calibrators are lightweight assemblies that are easy to carry. However, an optional carrying case is available for those desiring to carry more than one assembly at a time. The case can hold up to two complete assemblies and facilitates transporting them in the field.

7.3 Cleaning the MC600

You can remove particulate matter from the MC600 and sensor accessories using an appropriate halogen-free solvent, such as water or ethanol. Accessories should be thoroughly dried with compressed air, if necessary, before refitting them to the detector. When cleaning with conductive liquids, all power should be removed from the equipment.

7.4 Lubrication

European Union (EU) Approved Applications: The following grease compound is recommended for use: PBC Polybutylcuprysil, (or equivalent), which has BASEEFA Health & Safety Executive component approval No. 1051U for use as a jointing compound on flameproof electrical enclosures. This is available from General Monitors.

The neoprene rubber gasket, if it is found dry, should also be lubricated with Type P80 lubricant, available from General Monitors (P/N 610-010).

7.5 Storage

The Model MC600 cabinet should be stored in a clean, dry area, that is within the temperature and humidity ranges quoted in ***Environmental Specifications*** in Section 10.3 You should insert dust caps into any vacant cable entry holes during storage.

8.0 Troubleshooting



CAUTION: Component level repair must be undertaken either by General Monitors' personnel, or by an authorized service facility. SMT PCB repair shall be performed only at a General Monitors facility. Failure to comply with this requirement will invalidate the warranty.

NOTE: The system's full two-year warranty will be voided if customer personnel or third parties damage the system during repair attempts or maintenance activities.

Be sure to inhibit or disconnect external alarm wiring before making any check that might send the unit into alarm, if an alarm condition will cause a problem.

8.1 MC600 Controller Error Codes and Remedies

The MC600 controller has self-diagnostics incorporated into the microprocessor's program. If a Fault is detected, the Fault relay will de-energize, the Fault LED will light and a fault message will appear on the MC600 LCD display for Channel 1.

8.1.1 CON FAIL/COMM

Indicates failure in communication between the microprocessor and LCD display.

ACTION – Check cable #65011 for damage or loose connection. Then cycle power. If fault message reappears, the unit must be returned to the factory for repair

8.1.2 CON FAIL / EEPROM

Indicates failure to recall nonvolatile user configuration.

ACTION – The unit must be returned to the factory for repair.

8.1.3 CON FAIL / LOW LINE

Indicates inadequate input power.

ACTION – Check power supply and verify 20VDC minimum.

8.1.4 CON FAIL / PROGRAM

Indicates failure of program checksum.

ACTION – The unit must be returned to the factory for repair.

8.1.5 CON FAIL / RAM

Indicates failure of microprocessor RAM.

ACTION – The unit must be returned to the factory for repair.

8.1.6 CON FAIL / DATA RAM

Indicates failure of microprocessor RAM.

ACTION – The unit must be returned to the factory for repair.

8.2 Channel Error Codes and Remedies

The individual MC600 channels may show several different error codes that are related to the functioning of the signal conditioning card and/or sensor or instrument that is connected to each channel. Some of the following codes apply only to particular card types.

8.2.1 Setup Channel (Sensors and Instruments)

Appears routinely after a new signal-conditioning card has been inserted, to indicate that the channel needs to be configured for model options, etc., using the MC600 menus or MODBUS commands.

ACTION – See Section 5.1.

8.2.2 Cal Channel (Sensors and Instruments)

Indicates that calibration is required. Appears routinely after a new signal-conditioning card has been inserted and the channel has been configured.

ACTION – Calibrate channel per instructions in the section on *Calibrating Catalytic HC and MOS H₂S Sensors* in Section 4.5, or *Calibrating the LCD Display for 4-20mA Instruments* in Section 4.6.

8.2.3 Cal Fault (Sensors and Instruments)

Indicates that channel calibration failed due to conditions, such as, gas not being applied to the sensor, current not being applied to a 4-20mA card for LCD calibration, etc.

ACTION – Calibrate channel per instructions in the section on *Calibrating Catalytic HC and MOS H₂S Sensors* in Section 4.5, or *Calibrating the LCD Display for 4-20mA Instruments* in Section 4.6.

8.2.4 Card Removed (Sensors and Instruments)

Indicates that a signal-conditioning card has just been removed from a channel slot.

ACTION – Press [ACCEPT] to acknowledge removal of the card and leave the channel display blank or replace the card in the MC600 slot and reconfigure the channel (it will have to be set up once it is reinserted).

8.2.5 Fld Dev Fault (Instruments Only)

This may indicate a problem with the wiring from the signal-conditioning card to the field device, with the signal-conditioning card fuses or with the field instrument.

NOTE: For some 4-20mA instruments, the MC600 message **Fld Dev Fault** will appear while the instrument is in start-up mode. Refer to the instrument documentation for information on the start-up process.

ACTION – Check and verify that the signal wiring to the sensor is correct. Also, one or both of the fuses on the signal-conditioning card may need to be replaced.

If it is not a fuse or cabling problem, this error is signal-level related and depends on instrument type. For example, the TS400 shows a fault when current is less than 3.5mA, the S4000 shows a fault when current is less than 1.5mA, etc. Refer

to the instruction manual for the respective instrument; for a list of instrument documentation, see the list of **Related Documents** on page vi.

8.2.6 Invalid Card (Sensors and Instruments)

Indicates that an unrecognizable signal card is in the slot.

ACTION – Remove signal card and return to the factory for service.

8.2.7 Sensor Fault (Sensors Only)

For catalytic HC and MOS H₂S sensors only, this message indicates that the sensor is not functioning properly. The fuse on the signal conditioning card may need to be replaced if a **Sensor Fault** error appears during power-on.

ACTION – Check and verify that the signal wiring to the sensor is correct. If it is a MOS H₂S sensor, try replacing the fuse on the MOS H₂S signal-conditioning card.

If adjusting the cabling and replacing the fuse does not remedy the problem, you should then attempt to calibrate the sensor per instructions in the section *Calibrating Catalytic HC and MOS H₂S Sensors* in Section 4.5. If all of these actions are unsuccessful, return the sensor to the factory for service.

8.2.8 Field Device Offline:

Whenever the channel indicates Field Device Offline that means the unit is in calibration mode, set up mode or self test mode. Please refer to device instruction manual for more detail

9.0 MC600 MODBUS Interface

MODBUS is a widely used serial communication protocol for the RS-485 IEEE standard. A MODBUS program on a remote PC or other host can be used to control MC600 operation remotely. You can send MODBUS Read and Write commands to the MC600 registers to perform functions such as initiating gas check tests, zeroing and calibration of connected detectors, configuring communication channels between the controller and connected units, and monitoring status information for connected devices.

Section 9.1 provides general background information regarding the MODBUS interface, which applies for the MC600 devices. Later sections describe the MC600 MODBUS registers in detail.

9.1 General MODBUS Information

9.1.1 Serial Communication Settings

The unit can be configured for different communication speeds and data formats

9.1.1.1 Baud Rate

The baud rate is selectable via the MODBUS communications interface. The selectable baud rates are 19,200, 9600, 4800, or 2400 bits per second; the default setting is 19,200 for the MC600. .

9.1.1.2 Data Format

The data format is selectable via the MODBUS communications interface. The default setting is 8 data bits, no parity, and 1 stop bit. The selectable data formats are as follows:

Data Bits	Parity	Stop Bit	Format	Register Code
8	None	1	8-N-1	0
8	None	2	8-N-2	1
8	Even	1	8-E-1	2
8	Odd	1	8-O-1	3

Table 9: Serial Data Formats

9.1.2 Function Codes Supported

Function Code 03 (Read Holding Registers) is used to read status from the slave unit.

Function Code 06 (Preset Single Register) is used to write to the slave unit.

9.1.3 MODBUS Read Protocol (Query/Response)

The MODBUS Read command query and response message formats are shown in the following two tables.

<u>Byte</u>	<u>MODBUS</u>	<u>Range</u>
1 st	Slave Address	1-247* (Decimal)
2 nd	Function Code	03
3 rd	Register Address High**	00
4 th	Register Address Low**	00-FFh
5 th	Number of Registers High	00
6 th	Number of Registers Low	01
7 th	CRC*** Low	00-FFh
8 th	CRC*** High	00-FFh

NOTES: *Address 0 is reserved for broadcast mode and is not supported.
 **Register Address can be a maximum of 160 Locations (0000-009Fh).
 ***CRC = Cyclic Redundancy Check

Table 10: MODBUS Read Query Message

<u>Byte</u>	<u>MODBUS</u>	<u>Range</u>
1 st	Slave Address	1-247* (Decimal)
2 nd	Function Code	03
3 rd	Byte Count	02-FFh
4 th	Data High	00-FFh
5 th	Data Low	00-FFh
6 th	CRC** Low	00-FFh
7 th	CRC** High	00-FFh

NOTES: *Address 0 is reserved for broadcast mode and is not supported.
 **CRC = Cyclic Redundancy Check

Table 11: MODBUS Read Response Message

9.1.4 MODBUS Write Command Protocol (Query/Response)

The MODBUS Write command Query and Response message formats are shown in the following two tables.

<u>Byte</u>	<u>MODBUS</u>	<u>Range</u>
1 st	Slave Address	1-247* (Decimal)
2 nd	Function Code	06
3 rd	Register Address High**	00
4 th	Register Address Low**	00-FFh
5 th	Preset Data High	00-FFh
6 th	Preset Data Low	00-FFh
7 th	CRC*** Low	00-FFh
8 th	CRC*** High	00-FFh

NOTES: *Address 0 is reserved for broadcast mode and is not supported.
 **Register Address can be a maximum of 160 Locations (0000-009Fh).
 ***CRC = Cyclic Redundancy Check

Table 12: MODBUS Write Query Message

<u>Byte</u>	<u>MODBUS</u>	<u>Range</u>
1 st	Slave Address	1-247* (Decimal)
2 nd	Function Code	06
3 rd	Register Address High**	00
4 th	Register Address Low**	00-FFh
5 th	Preset Data High	00-FFh
6 th	Preset Data Low	00-FFh
7 th	CRC Low Byte***	00-FFh
8 th	CRC High Byte***	00-FFh

NOTES: *Address 0 is reserved for broadcast mode and is not supported.
 **Register Address can be a maximum of 160 Locations (0000-009Fh).
 ***CRC = Cyclic Redundancy Check

Table 13: MODBUS Write Response Message

9.1.5 Exception Response Messages and Codes

In a normal communications query and response, the master device sends a query to the MC600 and the MC600 receives the query without a communications error. The MC600 then handles the query normally within the master device’s allowable timeout and returns a normal response to the master. An abnormal communications query produces one of several possible events:

1. If the MC600 does not receive the query due to a communications error, then no response is returned from the MC600 and the master device will eventually process a timeout condition for the query.
2. If the MC600 receives the query, but detects a communication error (CRC, etc.), then no response is returned from the MC600 and the master device will eventually process a timeout condition for the query.
3. If the MC600 receives the query without a communications error, but cannot process the response to the master within the master’s timeout setting, then no response is returned from the MC600. The master device will eventually process a timeout condition for the query. To prevent this condition from occurring, the master’s timeout setting should be set to 200 milliseconds or greater, since 200 milliseconds is the maximum response time for the MC600.
4. If the MC600 receives the query without a communications error but cannot process it due to an error in the query, then the MC600 will return an exception response message informing the master of the error. The following table shows the structure of the exception response message. A different Exception Code indicates each type of query error.

<u>Byte</u>	<u>MODBUS</u>	<u>Range</u>
1 st	Slave Address	1-247* (Decimal)
2 nd	Function Code	83h or 86h
3 rd	Exception Code (See Error!)	01 – 06
4 th	Reference source not found.	00-FFh
5 th	CRC Low**	00-FFh
	CRC High**	

Table 14: MODBUS Exception Response Message

NOTES: *Address 0 is reserved for broadcast mode and is not supported.
 **CRC = Cyclic Redundancy Check

9.1.5.1 Exception Code Field

In a normal response, the MC600 returns data and status in the data field, which was requested in the query from the master. In an exception response, the MC600 returns an exception code in the data field, which describes the MC600 condition that caused the exception. The following table lists the exception codes that are supported by the MC600:

Code	Name	Description
01	Illegal Function	The function code received in the query is not an allowable action for the MC600.
02	Illegal Data Address	The data (register) address received in the query is not an allowable address for the MC600.
03	Illegal Data Value	A data value contained in the query data field is not an allowable value for the MC600.
04	Slave Device Failure	An unrecoverable error occurred while the MC600 was attempting to perform the requested action.
05	Acknowledge	The MC600 has accepted the request and is processing it, but a long duration of time will be required to do so. This response is returned to prevent a timeout error from occurring in the master.
06	Device Busy	The MC600 is engaged in processing a long-duration program command. The master should retransmit the message later when the slave is free.

Table 15: MODBUS Exception Codes

9.2 MC600 MODBUS Registers Summary

The following table summarizes the contents of the MC600 MODBUS registers. More detailed descriptions for the registers are provided following the table. Each register is allocated 16 bits (two bytes) of memory; however, many of the registers use only the lower byte (bits 1-8).

Master I/O Address (Dec)	Register Address (Hex)	Function	Data Type	Data Range	Access
40001	0000h	Not Used	N/A	N/A	N/A
40002	0001h	Unit Mode	Numeric Value	00-01h	Read
40003	0002h	Unit Status	Bit Map	8-bit	Read
40004	0003h	Calibration Status	Numeric Value	00-0Ch	Read/Write
40005	0004h	Model Type	Numeric Value	600 (decimal)	Read
40006	0005h	Control Card S/W Rev.	ASCII	One Character	Read

Master I/O Address (Dec)	Register Address (Hex)	Function	Data Type	Data Range	Access
40007	0006h	LCD S/W Revision	ASCII	One Character	Read
40008	0007h	Temperature	Numeric Value	8-bit, 00-FFh	Read
40009	0008h	Maximum Temperature	Numeric Value	8-bit, 00-FFh	Read
40010	0009h	Minimum Temperature	Numeric Value	8-bit, 00-FFh	Read
40011	000Ah	Accept/Reset	Numeric Value	1 or 2	Write
40012	0008h	Not Used	N/A	N/A	N/A
40015	000Eh	Not Used	N/A	N/A	N/A
40016	000Fh	Mod1 Address	Numeric Value	1-247 (1-F7h)	Read/Write
40017	0010h	Mod1 Baud Rate	Numeric Value	24, 48, 96, 192 (18h, 30h, 60h, C0h)	Read/Write
40018	0011h	Mod1 Format	Numeric Value	0, 1, 2 or 3	Read/Write
40019	0012h	Mod2 Address	Numeric Value	1-247 (decimal)	Read/Write
40020	0013h	Mod2 Baud Rate	Numeric Value	24, 48, 96, 192 (18h, 30h, 0h, C0h)	Read/Write
40021	0014h	Mod2 Format	Numeric Value	0, 1, 2 or 3	Read/Write
40022-40032	0015h-0019h	Not Used	N/A	N/A	N/A
40033	0020h	Mod1 Total Rcv Errors	Numeric Value	8-bit, 00-FFh	Read
40034	0021h	Mod1 MODBUS Address Errors	Numeric Value	8-bit, 00-FFh	Read
40035	0022h	Mod1 Function Code Errors	Numeric Value	8-bit, 00-FFh	Read
40036	0023h	Mod1 Starting Address Errors	Numeric Value	8-bit, 00-FFh	Read
40037	0024h	Mod1 No. Reg. Errors	Numeric Value	8-bit, 00-FFh	Read
40038	0025h	Mod1 RXD CRC Errors	Numeric Value	8-bit, 00-FFh	Read
40039	0026h	Mod1 Timing	Numeric Value	8-bit, 00-FFh	Read
40040	0027h	Mod1 Framing Errors	Numeric Value	8-bit, 00-FFh	Read
40041	0028h	Mod1 Parity Errors	Numeric Value	8-bit, 00-FFh	Read
40042	0029h	Mod1 Noise Errors	Numeric Value	8-bit, 00-FFh	Read
40043	002Ah	Mod1 SCI Interrupt Errors	Numeric Value	8-bit, 00-FFh	Read
40044	002Bh	Mod1 Clear Mod Errors	Numeric Value	1-bit	Write
40045-40048	002Ch-002Fh	Not Used	N/A	N/A	N/A
40049	0030h	Mod2 Total Rcv Errors	Numeric Value	8-bit, 00-FFh	Read
40050	0031h	Mod2 MODBUS Address Errors	Numeric Value	8-bit, 00-FFh	Read

Master I/O Address (Dec)	Register Address (Hex)	Function	Data Type	Data Range	Access
40051	0032h	Mod2 Function Code Errors	Numeric Value	8-bit, 00-FFh	Read
40052	0033h	Mod2 Starting Address Errors	Numeric Value	8-bit, 00-FFh	Read
40053	0034h	Mod2 No. Reg. Errors	Numeric Value	8-bit, 00-FFh	Read
40054	0035h	Mod2 RXD CRC Errors	Numeric Value	8-bit, 00-FFh	Read
40055	0036h	Mod2 Timing	Numeric Value	8-bit, 00-FFh	Read
40056	0037h	Mod2 Framing Errors	Numeric Value	8-bit, 00-FFh	Read
40057	0038h	Mod2 Parity Errors	Numeric Value	8-bit, 00-FFh	Read
40058	0039h	Mod2 Noise Errors	Numeric Value	8-bit, 00-FFh	Read
40059	003Ah	Mod2 SCI Interrupt Errors	Numeric Value	8-bit, 00-FFh	Read
40060	003Bh	Mod2 Clear Comm Errors	Numeric Value	1-bit	Write
40061-40064	003Ch-003Fh	Not Used			N/A
40065	0040h	CH1 Channel Mode	Numeric Value	8-bit, 00-0Fh	Read/Write
40066	0041h	CH1 Sensor Type	Numeric Value	8-bit, 00-22h	Read/Write
40067	0042h	CH1 Sensor Full-scale	Numeric (Scaled)	16-bit	Read
40068	0043h	CH1 Sensor Value	Numeric (Scaled)	16-bit	Read
40069	0044h	CH1 High Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40070	0045h	CH1 Low Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40071	0046h	CH1 Warn Setting	Numeric (Scaled)	16-bit	Read/Write
40072	0047h	CH1 Alarm State	Bit Map	8-bit	Read
40073	0048h	CH1 Sensor Life	Numeric Value	0-100% (00h-64h)	Read/Write
40074	0049h	CH1 Cal Point	Numeric Value	25-95% full-scale (19h-5Fh)	Read/Write
40075	004Ah	CH1 Alarm Mode	Numeric Value	8-bit	Read/Write
40076	004Bh	CH1 Alarm Delay Time	Numeric Value	8-bit	Read/Write
40077-40080	400Ch-004Fh	CH1 Not Used	N/A	N/A	N/A
40081	0050h	CH2 Channel Mode	Numeric Value	8-bit, 00-0Fh	Read/Write
40082	0051h	CH2 Sensor Type	Numeric Value	8-bit, 00-22h	Read/Write
40083	0052h	CH2 Sensor Full-scale	Numeric (Scaled)	16-bit	Read
40084	0053h	CH2 Sensor Value	Numeric (Scaled)	16-bit	Read
40085	0054h	CH2 High Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40086	0055h	CH2 Low Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40087	0056h	CH2 Warn Setting	Numeric (Scaled)	16-bit	Read/Write
40088	0057h	CH2 Alarm State	Bit Map	8-bit	Read

Master I/O Address (Dec)	Register Address (Hex)	Function	Data Type	Data Range	Access
40089	0058h	CH2 Sensor Life	Numeric Value	0-100% (00h-64h)	Read/Write
40090	0059h	CH2 Cal Point	Numeric Value	25-95% full-scale (19h-5Fh)	Read/Write
40091	005Ah	Ch2 Alarm Mode	Numeric Value	8-bit	Read/Write
40092	005Bh	CH2 Alarm Delay Time	Numeric Value	8-bit	Read/Write
40093-40096	005Ch-005Fh	Not Used	N/A	N/A	N/A
40097	0060h	CH3 Channel Mode	Numeric Value	8-bit, 00-0Fh	Read/Write
40098	0061h	CH3 Sensor Type	Numeric Value	8-bit, 00-22h	Read/Write
40099	0062h	CH3 Sensor Full-scale	Numeric (Scaled)	16-bit	Read
40100	0063h	CH3 Sensor Value	Numeric (Scaled)	16-bit	Read
40101	0064h	CH3 High Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40102	0065h	CH3 Low Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40103	0066h	CH3 Warn Setting	Numeric (Scaled)	16-bit	Read/Write
40104	0067h	CH3 Alarm State	Bit Map	8-bit	Read
40105	0068h	CH3 Sensor Life	Numeric Value	0-100% (00h-64h)	Read/Write
40106	0069h	CH3 Cal Point	Numeric Value	25-95% full-scale (19h-5Fh)	Read/Write
40107	006Ah	Ch3 Alarm Mode	Numeric Value	8-bit	Read/Write
40108	006Bh	Ch3 Alarm Delay Time	Numeric Value	8-bit	Read/Write
40109-40112	006Ch-006Fh	Not Used	N/A	N/A	N/A
40113	0070h	CH4 Channel Mode	Numeric Value	8-bit, 00-0Fh	Read/Write
40114	0071h	CH4 Sensor Type	Numeric Value	8-bit, 00-22h	Read/Write
40115	0072h	CH4 Sensor Full-scale	Numeric (Scaled)	16-bit	Read
40116	0073h	CH4 Sensor Value	Numeric (Scaled)	16-bit	Read
40117	0074h	CH4 High Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40118	0075h	CH4 Low Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40119	0076h	CH4 Warning Setting	Numeric (Scaled)	16-bit	Read/Write
40120	0077h	CH4 Alarm State	Bit Map	8-bit	Read
40121	0078h	CH4 Sensor Life	Numeric Value	0-100% (00h-64h)	Read/Write
40122	0079h	CH4 Cal Point	Numeric Value	25-95% full-scale (19h-5Fh)	Read/Write
40123	007Ah	CH4 Alarm Mode	Numeric Value	8-bit	Read/Write
40124	007Bh	CH4 Alarm Delay Time	Numeric Value	8-bit	Read/Write
40125-40128	007Ch-007Fh	CH4 Not Used	N/A	N/A	N/A
40129	0080h	CH5 Channel Mode	Numeric Value	8-bit, 00-0Fh	Read/Write

Master I/O Address (Dec)	Register Address (Hex)	Function	Data Type	Data Range	Access
40130	0081h	CH5 Sensor Type	Numeric Value	8-bit, 00-22h	Read/Write
40131	0082h	CH5 Sensor Full-scale	Numeric (Scaled)	16-bit	Read
40132	0083h	CH5 Sensor Value	Numeric (Scaled)	16-bit	Read
40133	0084h	CH5 High Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40134	0085h	CH5 Low Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40135	0086h	CH5 Warn Setting	Numeric (Scaled)	16-bit	Read/Write
40136	0087h	CH5 Alarm State	Bit Map	8-bit	Read
40137	0088h	CH5 Sensor Life	Numeric Value	0-100% (00h-64h)	Read/Write
40138	0089h	CH5 Cal Point	Numeric Value	25-95% full-scale (19h-5Fh)	Read/Write
40139	008Ah	CH5 Alarm Mode	Numeric Value	8-bit	Read/Write
40140	008Bh	CH5 Alarm Delay Time	Numeric Value	8-bit	Read/Write
40141-40144	008Bh-008Fh	CH5 Not Used	N/A	N/A	N/A
40145	0090h	CH6 Channel Mode	Numeric Value	8-bit, 00-0Fh	Read/Write
40146	0091h	CH6 Sensor Type	Numeric Value	8-bit, 00-22h	Read/Write
40147	0092h	CH6 Sensor Full-scale	Numeric (Scaled)	16-bit	Read
40148	0093h	CH6 Sensor Value	Numeric (Scaled)	16-bit	Read
40149	0094h	CH6 High Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40150	0095h	CH6 Low Alarm Setting	Numeric (Scaled)	16-bit	Read/Write
40151	0096h	CH6 Warn Setting	Numeric (Scaled)	16-bit	Read/Write
40152	0097h	CH6 Alarm State	Bit Map	8-bit	Read
40153	0098h	CH6 Sensor Life	Numeric Value	0-100% (00h-64h)	Read/Write
40154	0099h	CH6 Cal Point	Numeric Value	25-95% full-scale (19h-5Fh)	Read/Write
40155	009Ah	CH6 Alarm Mode	Numeric Value	8-bit	Read/Write
40156	009Bh	CH6 Alarm Delay Time	Numeric Value	8-bit	Read/Write
40157-40160	009Ch-009Fh	CH6 Not Used	N/A	N/A	N/A

Table 16: MC600 MODBUS Register Summary

9.3 MC600 MODBUS Register Details

9.3.1 MC600 Mode (0001h, Read-Only)

A Read returns the current MC600 unit mode. The value returned is 0 or 1 and indicates that the unit is starting up; 1 indicates that the unit is operating normally (includes fault conditions).

9.3.2 Unit Error Status (0002h, Read-Only)

This register reports on several types of status errors. A Read command to this register returns the present status, represented by the active bit(s). The following table shows the status that is determined by the first five bits in this register. With multiple error status bits set, the maximum value for the register can range from 0-0x1F. **A value of 0 indicates that there is no current status error.**

Bit	8	7	6	5	4	3	2	1
Error Status	N/A	N/A	N/A	Low Line Fault	RAM Fault	Program Checksum Fault	EEPROM Checksum Fault	LCD Communication Fault
Bit Value	80 hex 128 dec	40 hex 64 dec	20 hex 32 dec	10 hex 16 dec	8 hex 8 dec	4 hex 4 dec	2 hex 2 dec	1 hex 1 dec
Access Read-Only	Read	Read	Read	Read	Read	Read	Read	Read

Table 17: Bitmap for Unit Error Status (Lower Byte Only)

9.3.3 Calibration and Calibration Check Mode Status (0003h, Read/Write)

This register returns the status of the channel that is in Calibration mode, as indicated by the value of the lower byte in the register, from 1 to 12 decimal. The statuses indicated by the register values vary, depending on what type of sensor or 4-20mA instrument (and associated signal conditioning card) is in Calibration mode. Only the lower byte is used.

Only three of the register values are writeable, as indicated by an asterisk (*) in the table that follows; Most statuses are Read-Only. LCD messages associated with statuses are shown in the following table. Status information that does not actually appear on the channel LCD is shown in parentheses.

NOTE: Only one MC600 channel can be in Calibration mode at a particular time; a register value of 0 indicates that none of the channels is in Calibration mode.

Register Bit Value (Dec/Hex)	Catalytic HC Sensor Calibration Status	MOS H2S Sensor Calibration Status	TS420 (Oxygen) Calibration Status	4-20mA Instrument Calibration Status	TS4000-02 Calibration Status
0	No MC600 channels are in Calibration or Calibration Check Mode				
1	Sensor Life = n Zeroing	Sensor Life = n Zeroing	4-20Crd Spanning	4-20 Crd Zeroing	4-20 Crd Spanning
2	(Return to Zero)	Apply Gas	Remove Cell	4-20 Crd Span ? (waiting)	N/A
3	Apply Gas	Apply Gas	4-20 Crd Zeroing	Apply 12mA*	4-20 Crd Zeroing
4	Apply Gas	(Gas Soak)	Replace Cell	4-20 Crd Spanning	N/A
5	(Gas Soak)	(Spanning Cal Check)	(End Cal)	Remove Span	(End Cal)
6	(Spanning Cal Check)	(Spanning)	Cal Fault (Error)	(End Cal)	Cal Fault Error
7	(Spanning)	Remove Gas		Cal Fault Error	
8	Remove Gas	(End Cal)			
9	(End Cal)	Cal Fault (Error)			
10/Ah	Cal Fault (Error	(Abort*)			
11/Bh	Cal Abort (Abort*)	Cal Abort (Abort Display			
12/Ch	(Abort Display)				
* Only the three statuses shown followed by an asterisk (*) are intended for use with Write commands. The other statuses are Read Only information. Status information that does not actually appear on the channel LCD is shown in parentheses.					

Table 18: Calibration and Calibration Check Modes

9.3.4 Model Type (0004h, Read-Only)

This register returns the model type for the MC600 as 258h, which is 600 in decimal notation. Only the lower byte of the register is used.

9.3.5 Control Card Firmware Revision (0005h, Read-Only)

This register returns the ASCII character for the control card firmware revision, such as 41h for revision A. Only the lower byte of the register is used.

9.3.6 LCD Card Firmware Revision (0006h, Read-Only)

This register returns the ASCII character for the LCD card firmware revision, such as 41h for revision A. Only the lower byte of the register is used.

9.3.7 Temperature (0007h, Read-Only)

This register returns a number that yields the current MC600 temperature in degrees Centigrade offset by 55° C (decimal). For example, if 50h (80 decimal) is returned, this indicates a temperature of 25° C ($80^{\circ} \text{C} - 55^{\circ} \text{C} = 25^{\circ} \text{C}$).

9.3.8 Maximum Temperature (0008h, Read-Only)

This register returns a number that yields the maximum MC600 temperature in degrees Centigrade offset by 55° C (decimal). For example, if 60h (96 decimal) is returned, this indicates a temperature of 41° C ($96^{\circ} \text{C} - 55^{\circ} \text{C} = 41^{\circ} \text{C}$).

9.3.9 Minimum Temperature (0009h, Read-Only)

This register returns a number that yields the current MC600 temperature in degrees Centigrade offset by 55° C (decimal). For example, if 30h (48 decimal) is returned, this indicates a temperature of -7° C ($48^{\circ} \text{C} - 55^{\circ} \text{C} = -7^{\circ} \text{C}$).

9.3.10 Accept/Reset (000Ah, Write-Only)

This register duplicates the functions of the front panel, Accept/Reset buttons. Entering a value of 1 performs an Accept function. Entering a value of 2 performs a Reset function.

9.3.11 MODBUS Channel 1 Address (000Fh, Read/Write)

This register returns and can also set the address for the MC600 MODBUS Channel 1. The default setting is 1, and the range of allowable addresses is 1-247 (decimal) or 01-FBh.

NOTE: If the same port on a MODBUS device is connected to both MC600 MODBUS channels, then the addresses for MODBUS Channel 1 and MODBUS Channel 2 must be unique. If a separate port is connected to each channel, then the unit addresses for Channel 1 and Channel 2 can be the same.

9.3.12 MODBUS Channel 1 Baud Rate (0010h, Read/Write)

This register returns and can also set the baud rate for the MC600 MODBUS Channel 1. The default setting is 19,200 baud. The list of all possible settings is:

Baud Rate	Register Value (Hex and Decimal)
2400 baud	18h (24 decimal)
4800 baud	30h (48 decimal)
9600 baud	60h (96 decimal)
19200 baud	C0h (192 decimal)

Table 19: Baud Rates for MODBUS Channel 1

9.3.13 MODBUS Channel 1 Data Format (0011h, Read/Write)

This register returns and can also set the data format for the MC600 MODBUS Channel 1. The default setting is 8 data bits, no parity, 1 stop bit. The list of all possible settings is:

Data Format (Data Bits – Parity – Stop Bits)	Register Value
8-N-1	0
8-N-2	1
8-E-1	2
8-0-1	3

Table 20: Data Formats for MODBUS Channel 1

9.3.14 MODBUS Channel 2 Address (0012h, Read/Write)

This register returns and can also set the address for the MC600 MODBUS Channel 2. The default setting is 2, and the range of allowable addresses is 1-247 (decimal) or 01-FBh.

MODBUS Channel 2 Baud Rate (0013h, Read/Write)

This register returns and can also set the baud rate for the MC600 MODBUS Channel 2. The default setting is 19,200 baud. The list of all possible settings is:

Baud Rate	Register Value (Hex and Decimal)
2400 baud	18h (24 decimal)
4800 baud	30h (48 decimal)
9600 baud	60h (96 decimal)
19200 baud	C0h (192 decimal)

Table 21: Baud Rates for MODBUS Channel 2

9.3.15 MODBUS Channel 2 Data Format (0014h, Read/Write)

This register returns and can also set the data format for the MC600 MODBUS Channel 2. The default setting is 8 data bits, no parity, 1 stop bit. The list of settings is:

Data Format (Data Bits – Parity – Stop Bits)	Register Value
8-N-1	0
8-N-2	1
8-E-1	2
8-0-1	3

Table 22: Data Formats for MODBUS Channel 2

9.3.16 MODBUS Channel 1 Total Receive Errors (0020h, Read-Only)

This register returns the sum total of all receive errors for MODBUS channel 1; this combines all types of communication errors shown individually in registers 0021h to 002Ah. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

You can also reset the counters for this register and all Channel 1 communication errors by writing to register 002Bh (see Section 9.3.28)

9.3.17 MODBUS Channel 1 Address Errors (0021h, Read-Only)

This register returns the number of valid messages received by Mod1 that specify an invalid unit address (not matching the MC600 MODBUS channel 1 unit address). The maximum number of errors is 255 (FFh); after 255, the counter restarts.

NOTE: If the same port on a MODBUS device is connected to both MC600 MODBUS channels, then duplicate address errors can occur for Channel 1 and Channel 2

9.3.18 MODBUS Channel 1 Function Code Errors (0022h, Read-Only)

This register returns the number of valid messages received by Mod1 that include an unsupported function code (not equal to 03h or 06h). The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.19 MODBUS Channel 1 Starting Address Errors (0023h, Read-Only)

This register returns the number of valid messages received by Mod1 that specify invalid register addresses. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.20 MODBUS Channel 1 No. of Register Errors (0024h, Read-Only)

This register returns the number of valid Read Query messages received by Mod1 that specify an invalid number of registers. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.21 MODBUS Channel 1 RXD CRC Errors (0025h, Read-Only)

This register returns the number of valid messages received by Mod1 containing an invalid CRC (either High or Low). The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.22 MODBUS Channel 1 Byte Timing Errors (0026h, Read-Only)

This register returns the number of messages received by Mod1 that have an improper inter-byte delay, which is greater than 1½ times the character time. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.23 MODBUS Channel 1 Framing Errors (0027h, Read-Only)

This register returns the number of messages received by Mod1 that have improper composition. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.24 MODBUS Channel 1 Parity Errors (0028h, Read-Only)

This register returns the number of messages received by Mod1 that have incorrect message parity. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.25 MODBUS Channel 1 Noise Errors (0029h, Read-Only)

This register returns the number of messages received by Mod1 with noise errors. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.26 MODBUS Channel 1 SCI Interrupt Errors (002Ah, Read-Only)

This register returns the number of messages received by Mod1 with interrupt errors due to serial overrun conditions. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.27 MODBUS Channel 1 Clear MODBUS Errors (002Bh, Write-Only)

A Write command to this register will reset all of the counters for MODBUS Channel 1 communication errors and statistics to 0.

9.3.28 MODBUS Channel 2 Total Receive Errors (0030h, Read-Only)

This register returns the sum total of all receive errors for MODBUS channel 2; this combines all types of communication errors shown individually in registers 0031h to 003Ah. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

You can also reset the counters for this register and all Channel 2 communication errors by writing to register 003Bh (see Section 9.3.40).

9.3.29 MODBUS Channel 2 Address Errors (0031h, Read-Only)

This register returns the number of valid messages received by Mod2 that specify an invalid unit address (not matching the MC600 MODBUS channel 2 unit address). The maximum number of errors is 255 (FFh); after 255, the counter restarts.

NOTE: If the same port on a MODBUS device is connected to both MC600 MODBUS channels, then duplicate address errors can occur for Channel 1 and Channel 2

9.3.30 MODBUS Channel 2 Function Code Errors (0032h, Read-Only)

This register returns the number of valid messages received by Mod2 that include an unsupported function code (not equal to 03h or 06h). The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.31 MODBUS Channel 2 Starting Address Errors (0033h, Read-Only)

This register returns the number of valid messages received by Mod2 that specify invalid register addresses. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.32 MODBUS Channel 2 Number of Register Errors (0034h, Read-Only)

This register returns the number of valid Read Query messages received by Mod2 that specify an invalid number of registers. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.33 MODBUS Channel 2 RXD CRC Errors (0035h, Read-Only)

This register returns the number of valid messages received by Mod2 containing an invalid CRC (either High or Low). The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.34 MODBUS Channel 2 Byte Timing Errors (0036h, Read-Only)

This register returns the number of messages received by Mod2 that have an improper inter-byte delay, which is greater than 1½ times the character time. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.35 MODBUS Channel 2 Framing Errors (0037h, Read-Only)

This register returns the number of messages received by Mod2 that have improper composition. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.36 MODBUS Channel 2 Parity Errors (0038h, Read-Only)

This register returns the number of messages received by Mod2 that have incorrect message parity. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.37 MODBUS Channel 2 Noise Errors (0039h, Read-Only)

This register returns the number of messages received by Mod2 with noise errors. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.38 MODBUS Channel 2 SCI Interrupt Errors (003Ah, Read-Only)

This register returns the number of messages received by Mod2 with interrupt errors due to serial overrun conditions. The maximum number of errors is 255 (FFh); after 255, the counter restarts.

9.3.39 MODBUS Channel 2 Clear MODBUS Errors (003Bh, Write-Only)

A Write command to this register will reset all of the counters for Mod2 communication errors and statistics to 0.

9.3.40 Channel Mode (0040h for Channel 1, 0050h for Channel 2, etc.)

These six registers indicate the current mode for the six MC600 channels. You can also control the channel mode by sending Write commands to the channel registers.

A Read command to the register returns a value from 00-0Fh; each value is associated with a particular mode or error condition.

A Write command that writes the value 02h, 05h or 06h to one of the Channel Mode registers will cause the channel to enter Operating mode, Calibration mode or Calibration Check mode, respectively.

NOTE: Before issuing a Write command to start Calibration or Calibration Check mode, review the instructions in the sections **Calibrating Catalytic HC and MOS H₂S Sensors** in Section 4.5 and **Checking Calibration for Sensors** in Section 4.7 carefully.

The following table provides a summary of the numeric values for this register with descriptions of the meanings when the value is returned by Read commands and sent in Write commands.

Value	Read Value Description	Write Value Result
00h	HC Startup (<i>catalytic HC sensors only</i>)	N/A
01h	HC Startup in Progress (<i>catalytic HC sensors only</i>)	
02h	Normal Operation (<i>sensors and 4-20mA instruments</i>)	Returns to Operation mode, can be used to stop calibration before gas is applied.
03h	Not Operational (<i>empty channel</i>)	N/A
04h	Instrument State (<i>4-20mA instruments</i>). Shows when input current is under 4mA or above 20mA due to instrument-controlled operations, such as during instrument-controlled calibration.	
05h	Calibration Check Mode (<i>sensors only</i>). MC600-controlled calibration check. For more detailed MC600 status information, see page 85.	Starts Calibration Check mode
06h	Calibration Mode (<i>sensors and 4-20mA instruments</i>). MC600-controlled calibration. For 4-20mA instruments, this calibrates only the LCD display. For more detailed MC600 status information, see page 85.	Starts Calibration mode
07h	Sensor Error (<i>sensors only</i>)	N/A
08h	Field Device Error (<i>4-20mA instruments only</i>). This error is signal-level related and depends on instrument type. For example, the TS400 indicates a fault when output current is less than 3.5mA, the S4000 indicates a fault when output current is less than 1.5mA, etc.	
09h	Reset Channel Faults (<i>sensors and 4-20mA instruments</i>). Internal state used to reset faults occurring on a specific channel.	
0Ah	Invalid Card (<i>sensors and 4-20mA instruments</i>). Card is in slot, however it is not recognized as one of the three valid card types.	
0Bh	New Card (<i>sensors and 4-20mA instruments</i>). Card is in slot and identified, but channel is not set up.	
0Ch	Card Removed (<i>sensors and 4-20mA instruments</i>). No card in slot, but channel is set up.	

Value	Read Value Description	Write Value Result
0Dh	Calibration Required (<i>sensors only</i>).	
0Eh	Calibration Error (<i>sensors and 4-20mA instruments</i>).	
0Fh	Channel Empty (<i>sensors and 4-20mA instruments</i>). Card is not in slot and channel is not set up.	

Table 23: Channel Mode Descriptions

9.3.41 Device Type (0041h for Channel 1, 0051h for Channel 2, etc.)

These registers are Read/Write. Sending a Read command to the Sensor Type register for a selected channel returns the current sensor type that is configured for the channel. Sending a Write command to the Sensor Type register for a selected channel will configure the selected channel for a newly installed signal conditioning card and/or a new sensor device.

Once the Write command is sent, the alarm set points for the channel will be the default settings for the specified sensor (30%, 45%, and 60% of the sensor's Full-scale value for the Warning, Alarm Low, and Alarm High set points, respectively). Table 23 lists the Sensor Type register values for the four catalytic HC and MOS H₂S sensor types. Table 24 lists the register values for compatible 4-20mA instruments.

Register Value	MOS H ₂ S Sensor Type (MOS H ₂ S Card)	Catalytic HC Sensor Type (Catalytic HC Card)
00h	HC	0-100% LEL
01h	20 ppm	
02h	50 ppm	
03h	100 ppm	

Table 24: Sensor Types (Catalytic HC and MOS H₂S)

Register Value	4-20mA Instrument	Register Value	4-20mA Instrument	Register Value	4-20mA Instrument
04h	TS400 – ClO ₂ , 3 ppm	1Eh	S214, 50 ppm	36h	TS4000/H H ₂ S, 100 ppm
05h	TS400 – Cl ₂ , 10 ppm	1Fh	S214, 100 ppm	37h	TS400 H ₂ S, 100 ppm
06h	TS400 – CO, 100 ppm	20h	S216A, 20 ppm	38h	TS4000/H, H ₂ S, 20ppm
07h	TS400 – CO, 500 ppm	21h	S216A, 50 ppm	39h	TS4000/H, H ₂ S, 50ppm
08h	TS400 – HCL, 20 ppm	22h	S216A, 100 ppm	3Ah	TS4000/H, SO ₂ , 100ppm
09h	TS400 – NO, 100 ppm	23h	Reserved	3Bh	TS400 H ₂ S, 20ppm
0Ah	TS400 – NO ₂ , 20 ppm	24h	Reserved	3Ch	TS400 H ₂ S, 50ppm
0Bh	TS400 – SO ₂ , 20 ppm	25h	Reserved	3Dh	OBSERVER
0Ch	TS400 – O ₃ , 1 ppm	26h	Reserved	3Eh	SURVEYOR
0Dh	TS420 – O ₂ , 25% v/v	27h	TS4000/H–CO 100 ppm	3Fh	Reserved
0Eh	IR2100, 0-100% LEL	28h	TS4000/H–CO 500 ppm	40h	IR400, 0 - 100% LEL
0Fh	IR2100, 0-100% v/v	29h	TS4000/H– Cl ₂ , 10 ppm	41h	IR400, 0 – 100% V/V
12h	IR7000, 0-5000 ppm	2Ah	TS4000/H– Cl ₂ , 20 ppm	42h	TS4000H – H ₂ , 500 ppm
13h	S4000C/H,0-100% LEL	2Bh	TS4000/H–ClO ₂ , 3 ppm	43h	IR5500 – Methane, 5000ppm
14h	S4000T/H, 20 ppm	2Ch	TS4000/H–HCL, 20 ppm	44h	IR5500 – Methane, 5 LEL
15h	S4000T/H, 50 ppm	2Dh	TS4000/H–NO,100 ppm	45h	IR5500 – Propane, 2000ppm
16h	S4000T/H, 100 ppm	2Eh	TS4000/H–NO ₂ ,20 ppm	46h	IR5500 – Methane, 1 LEL
17h	S4100C, 0-100% LEL	2Fh	TS4000/H – O ₂ , 25% v/v	47h	IR700 – CO ₂ , 2000ppm
18h	S4100T, 20 ppm	30h	TS4000/H – O ₃ , 1 ppm	48h	IR700 – CO ₂ , 5000ppm
19h	S4100T, 50 ppm	31h	TS4000/H–SO ₂ , 20 ppm	49h	IR700 – CO ₂ , 10000ppm
1Ah	S4100T, 100 ppm	32h	IR5000 – Methane,	4Ah	IR700 – CO ₂ , 30000ppm
1Bh	S104, 0-100% LEL	33h	IR5000 – Methane, 5%	4Bh	IR700 – CO ₂ , 50000ppm
1Ch	S106A, 0-100% LEL	34h	IR5000 – Propane, 2000		
1Dh	S214, 20 ppm	35h	IR5000 – Propane, 1%		

Table 25: Instrument Types (4-20mA Instruments)

9.3.42 Sensor Full-scale (Read-Only, 0042h for Chan 1, 0052h for Chan 2, etc.)

These registers are Read-Only. Sending a Read command to one of the channel registers will return a 16-bit value (from 0000h-FFFFh). If the installed sensor type has a full-scale value less than or equal to 5000, you must convert the returned number into the actual full-scale value using the following formula:

$$\text{Actual Value} = [(Returned Scaled Value \text{ converted to decimal} - 12500)] / 10$$

(for example, a returned value of 32C8h indicates a full-scale value of 50.0)

If the installed sensor type has a full-scale value > 5000, the returned number is the actual full-scale value.

NOTE: The units for the full-scale value depend on the type of sensor or instrument installed in the channel; ppm for MOS H₂S sensors or toxic instruments, %LEL for catalytic HC sensors and instruments, or %v/v for oxygen and some HC instruments.

9.3.43 Sensor Value (Read-Only, 0043h for Chan 1, 0053h for Chan 2, etc.)

These registers are Read-Only. Sending a Read command to one of the channel registers will return a 16-bit value (from 0000h-FFFFh). If the installed sensor type has a full-scale value less than or equal to 5000, you must convert the returned number into the actual sensor value using the following formula:

$$\text{Actual Value} = [(Returned Scaled Value \text{ converted to decimal} - 12500)] / 10$$

(for example, a returned value of 32C8h indicates a sensor value of 50.0)

If the installed sensor type has a full-scale value > 5000, use the following formula:

$$\text{Actual Value} = (Returned Scaled Value \text{ converted to decimal} - 12500)$$

(for example, a returned value of 32C8h indicates a sensor value of 500)

NOTE: The units for the sensor value depend on the type of sensor or instrument installed in the channel; ppm for MOS H₂S sensors or toxic instruments, %LEL for catalytic HC sensors and instruments, or %v/v for oxygen and some HC instruments.

9.3.44 Alarm High Set point (Read/Write, 0044h for Chan 1, 0054h for Chan 2, etc.)

These registers are Read/Write. Sending a Read command to one of the channel registers will return a 16-bit value (from 0000h-FFFFh). If the installed sensor type has a full-scale value less than or equal to 5000, you must convert the returned number into the actual Alarm High set point value using the following formula:

$$\text{Actual Value} = [(\text{Returned Scaled Value converted to decimal} - 12500)] / 10$$

(for example, a returned value of 32C8h indicates a set point value of 50.0)

If the installed sensor type has a full-scale value > 5000, the returned number is the actual Alarm High set point value.

NOTE: The units for the set point value depend on the type of sensor or instrument installed in the channel; ppm for MOS H₂S sensors or toxic instruments, %LEL for catalytic HC sensors and instruments or %v/v for oxygen and some HC instruments.

You can send a Write command to change the Alarm High set point. If the installed sensor type has a full-scale value less than or equal to 5000, the value needs to be scaled. Take the desired set point value in decimal and convert it to a scaled Hex value for the Write command using the following formula:

$$[(\text{Actual Decimal Value } n.n) \times 10 + 12500] \Rightarrow \text{Hex Notation} = \text{Scaled Write Value}$$

For example, to select a set point value of 25.0 you would include the hex value 31CEh in the Write command to this register.

If the installed sensor type has a full-scale value > 5000, no conversion is needed.

9.3.45 Alarm Low Set point (Read/Write, 0045h for Chan 1, 0055h for Chan 2, etc.)

These registers are Read/Write. Sending a Read command to one of the channel registers will return a 16-bit value (from 0000h-FFFFh). If the installed sensor type has a full-scale value less than or equal to 5000, you must convert the returned number into the actual Alarm Low set point value using the following formula:

$$\text{Actual Value} = [(\text{Returned Scaled Value converted to decimal} - 12500)] / 10$$

(for example, a returned value of 32C8h indicates a set point value of 50.0)

If the installed sensor type has a full-scale value > 5000, the returned number is the actual Alarm Low set point value.

A Write command can be sent to change the Alarm Low set point. If the installed sensor type has a full-scale value less than or equal to 5000, the value needs to be scaled. Take the desired set point value in decimal and convert it to a scaled Hex value for the Write command using the following formula:

$$[(\text{Actual Decimal Value } n.n) \times 10 + 12500] \Rightarrow \text{Hex Notation} = \text{Scaled Write Value}$$

For example, to select a set point value of 25.0 you would include the hex value 31CEh in the Write command to this register.

If the installed sensor type has a full-scale value > 5000, no conversion is needed.

9.3.46 Warning Set point (Read/Write, 0046h for Chan. 1, 0056h for Chan. 2, etc.)

These registers are Read/Write. Sending a Read command to one of the channel registers will return a 16-bit value (from 0000h-FFFFh). If the installed sensor type has a full-scale value less than or equal to 5000, you must convert the returned number into the actual Warning set point value using the following formula:

$$\text{Actual Value} = [(\text{Returned Scaled Value converted to decimal} - 12500)] / 10$$

(for example, a returned value of 32C8h indicates a set point value of 50.0)

If the installed sensor type has a full-scale value > 5000, the returned number is the actual Warning set point value.

A Write command can be sent to change the Warning set point. If the installed sensor type has a full-scale value less than or equal to 5000, the value needs to be scaled. Take the desired set point value in decimal and convert it to a scaled Hex value for the Write command using the following formula:

$$[(\text{Actual Decimal Value } n.n) \times 10 + 12500] \Rightarrow \text{Hex Notation} = \text{Scaled Write Value}$$

For example, to select a set point value of 25.0 you would include the hex value 31CEh in the Write command to this register.

If the installed sensor type has a full-scale value > 5000, no conversion is needed.

For Observer and Surveyor, Alarm high set point equal Alarm low set point and also equal Warning set point. Whenever user change one of the above set point, the MC600 will automatically update the rest of the set points to the new set point

9.3.47 Alarm State (0047h for Chan 1, 0057h for Chan 2, etc.)

These registers are Read-Only. The lower byte of these registers returns a bit-map value that indicates the alarm state for the selected channel. The bit values are:

Enabled Bit	Numeric Value	Alarm Level
N/A	0	None
0	1	Warning
1	2	Alarm Low
2	4	Alarm High
3	8	Warning Accepted
4	16	Alarm Low Accepted
5	32	Alarm High Accepted

Table 26: Alarm States (Bit Map)

9.3.48 Sensor Life (0048h for Chan 1, 0058h for Chan 2, etc.)

These registers are Read/Write. The lower byte returns a numeric value that indicates the current Sensor Life value for the selected channel, from 0-100% shown in hexadecimal (00h to 64h). You can also write a value to this register; usually this is done to reset the sensor life to 100% when a new sensor is installed.

9.3.49 Calibration Point (0049h for Chan 1, 0059h for Chan 2, etc.)

These registers are Read/Write. They are only used with channels that have catalytic HC signal conditioning cards. For a catalytic HC-configured channel, the registers return the percentage of full-scale value that is used as a calibration point.

You can also send a Write command to a register for a catalytic-configured channel, to select a calibration point from 25-95% (19h to 5Fh) of full-scale for some hydrocarbon gases other than Methane.

9.3.50 Alarm Mode (004Ah for Chan 1, 005Ah for Chan 2, etc.)

These registers are Read/Write. Entering a zero to these registers sets the corresponding channel in Non-latched Alarm Mode. Entering a 1 to these registers sets the corresponding channel in Latched Alarm Mode.

9.3.51 Alarm Delay Time (004Bh for Chan 1, 005Bh for Chan 2, etc.)

These registers are Read/Write. Enter a 10, 15, 20 and 25 corresponding to 10, 15, 20 and 25 seconds delay. Time delays only apply for ultrasonic products.

10.0 MC600 Specifications

10.1 System Specifications

10.1.1 MC600 System Unit

Sensor Compatibility:	Compatible with all GM catalytic HC and MOS H ₂ S sensors, all GM combustible & H ₂ S intelligent sensor instruments, IR2100, IR400, IR700 IR5000, IR5500, IR7000, TS4000/H, TS400 (all gases), TS420, Observer, Observer-H and Surveyor, S4000CH/TH instruments. See detailed specifications for sensors in the following subsections.
Display Range:	0-100% LEL, 0-5000 ppm, 0-25% v/v, 0-100% v/v For ultrasonic products: 44dB – 104dB
Area Classification:	General use in non-hazardous and Class I Division 2 environments.
Channel Configuration:	One to six channels with any combination of catalytic HC, MOS H ₂ S or 4-20mA signal conditioning cards. The standard configuration is six analog input cards.
Front Panel Interface:	Six individual channel LCDs, each with 2-line, 8-character backlit display area. Six Navigation Buttons ([ACCEPT] , [MODE] , [▲] , [▼] , [ENTER] , and [RESET]) for use with onboard menu system. One [DISPLAY SETUP] button to configure the display. Four daylight-readable Ready, Alarm, Warn & Fault. LED indicators with adjustable brightness. Optional 95db Sounder with adjustable volume. Optional Remote Front Panel Keypad that connects to the LCD switches.
Alarms:	Alarm High, Alarm Low and Warning, per channel.

10.1.2 MC600 System Unit Continued

Relay Settings:	For each Relay, the state is Energized or De-Energized, and the mode is Latching, Non-Latching, or Timed from 1-120 minutes.
Zoning and Voting:	Programmable zoning, from 0 to 3 zones. Single or dual voting for 1-3 zones, programmable relays for 0 zones.
Tests:	Display and card tests.
Regulatory Compliance:	CSA: Class I, Division 2 Groups A, B, C, D Type 4X EMC: EN 50270, EN 61000-6-4
Warranty:	Two years

10.1.3 4-20mA GM Instrument Specifications


Following is a list of the compatible General Monitors 4-20mA instruments. Complete specifications are provided in the GM Instruction Manual for each instrument. For a list of part numbers and titles see **Related Documentation** on page vi.

- S4000C/H/S104/S106A/S4100C – catalytic HC sensor-based instruments
- S4000T/H /S214/S216A/S4100T – MOS H₂S sensor-based instruments
- IR2100 – Infrared HC point detector instrument
- IR400 – Infrared HC point detector instrument
- IR5000 – Infrared Open Path detector for HC gas
- IR5500 – Infrared Open Path detector for HC gas
- IR7000 – Carbon Dioxide
- IR700 – Carbon Dioxide
- TS400 – Multiple Toxic Gases
- TS420 – Oxygen
- TS4000/H – Multiple Toxic Gases
- OBSERVER, OBSERVER-H and SURVEYOR

10.2 Mechanical Specifications

The MC600 is housed in a glass-filled polyester, Type 4X, UV stable enclosure. It has stainless steel hinges and lockable latches.

Height:	15.5 inches (395.25 mm)
Width:	13.3 inches (339.15 mm)
Depth:	6.70 inches (170.85 mm)
Weight:	12.75 lb. standard, 14.7 lb. w/ power supply
Mounting Holes:	Four .32-inch enclosure mounting holes
Conduit Entry Holes:	Four 3/4" conduit entries (standard configuration has four holes, drilled and plugged with caps)



**Figure 52: Outline and Dimensional Drawing
(Cabinet Dimensions and Mounting Holes)**





Figure 53: Outline and Dimension Drawing, Cabinet Door and Bottom

10.3 Environmental Specifications

MC600 Operating Temperature	Without power supply option or with Division 2 approved power supply option: -4°F to 140°F (-20°C to + 60°C). With power supply for ordinary location option: -14°F to 140°F (-10°C to + 60°C).
MC600 Storage Temperature	Without power supply option or with Division 2 approved power supply option:: -40°F to +158°F (-40°C to +70°C) With non Division 2 power supply option: -4°F to +158°F (-20°C to +70°C)
MC600 Operating Humidity	Without power supply: 0-95% RH, non-condensing. With power supply option: 20-90% RH, non-condensing.
MC600 Vibration Specs	Meets the vibration requirements described in CSA standard C22.2, No. 152, <i>Combustible Gas Detection Instruments</i>
MC600 Enclosure Rating	Type 4X

10.4 Electrical Specifications

Power Supply Requirements:	24 VDC nominal, 20-36 VDC (<i>standard</i>). 115/230 VAC C, 50-60 Hz (<i>optional onboard power supply</i>).
Cable Requirements:	When connecting ultrasonic products to MC600, the Supply Voltage must not be greater than 28VDC 3 wire shielded cable. Maximum distance between MC600 and power source @ 24 VDC nominal (5 Ohm loop):

AWG	FEET	METERS
14	750	225
16	475	145
18	375	115
20	250	75

Table 27: VDC Cable Lengths

Maximum distance between the MC600 and catalytic HC sensor, with one-way resistance of 20 Ohms (40-Ohm loop):

AWG	FEET	METERS
14	7600	2320
16	4800	1460
18	3000	910
20	1900	580

Table 28: Catalytic HC Sensor Cable Lengths

Maximum distance between the MC600 and MOS H₂S sensor, with one-way resistance of 10 Ohms (20-Ohm loop):

AWG	FEET	METERS
14	3700	1125
16	2400	730
18	1500	460
20	1000	300

Table 29: MOS H₂S Sensor Cable Lengths

10.4.1 Relay Ratings

One SPDT Fault relay. Six SPDT Auxiliary relays. Contact rating for all relays is: 8A @ 120/230 VAC, or 8A @ 30 VDC resistive maximum.

10.4.2 RS-485 Output

Dual Redundant MODBUS RTU, suitable for linking up to 128 units, or up to 247 units with repeaters. Baud Rates are selectable as 2400, 4800, 9600, or 19200 bps.

10.5 Approvals

CSA, CE Marking Approved.


11.0 Sensors and Accessories

This chapter provides a description of the catalytic HC sensors, MOS H₂S sensors, sensor accessories, upgrade modules and spare parts that can be used with the Model MC600.

11.1 Catalytic Bead Hydrocarbon (HC) Sensors

General Monitors uses a low temperature catalytic bead to detect the presence of combustible gases and vapors. These gases and vapors are found in many applications. The catalytic bead converts the combustible gases and vapors to heat. This change in heat results in a change in the electrical resistance of the bead.

By taking a matched pair of catalytic beads and coating one, so that it does not respond to the presence of combustible gases and vapors, we can compare the change in resistance between the two beads. The bead that is coated is called the reference bead and the other bead is the active bead (see Figure 58).



F

Figure 54: Catalytic Bead, Combustible Gas Sensor

Environmental factors can also influence the temperature of the catalytic beads. Because the beads are matched pairs, they will respond to changes in ambient temperature, humidity and pressure equally.

By connecting one end of each catalytic bead together, a series circuit is formed. This circuit is supplied with a constant current. The voltage drop across each bead will be identical in the absence of combustible gases and vapors. As combustible material is converted to heat, the resistance across the active bead increases, causing the voltage drop across each bead to be different. This difference is proportional to the amount of combustible gas or vapor that is present at the sensing elements (catalytic beads).

11.2 Catalytic HC Sensor Spare Parts and Accessories

To order spare parts and/or accessories, please contact your nearest General Monitors Representative, or General Monitors directly and give the following information:

- Part Number of Spare Part or Accessory
- Description of Spare Part or Accessory
- Quantity of Spare Part or Accessory

11.2.1 Catalytic HC Sensor Part Numbers

General Monitors offers a variety of catalytic HC sensors with sensor bodies and flame arrestors:

10001-1	General purpose, aluminum body, CSA, FM
10001-1R	General-purpose, poison-resistant, aluminum body, CSA, FM
10014-1	General purpose, high temperature to 400°F (200°C), aluminum body, CSA
10014-1R	General purpose, poison resistant, high temperature to 400°F (200°C), aluminum body
10015-1	Aluminum, high temperature (max. 120°C) CSA approved
10022-1	Aluminum CSA approved, sintered, Group A
10058-1	General-purpose, stainless steel body, CSA, FM
10058-1R	General-purpose, poison resistant, stainless steel body, CSA, FM
10164-1	Hydrogen-specific, aluminum body, CSA
10387-4	Super poison-resistant, aluminum body
10391-1	High temperature, industrial hydrocarbons, stainless steel
11159-1	Stainless steel, CSA, ATEX, GOST approved, 120°C max., Group A
11159-2	Stainless steel, CSA, ATEX, GOST approved, 180°C max., Group A
11159-1L	Standard industrial hydrocarbon (w/lugs), stainless steel, ATEX, Group A
11159-2L	High temperature hydrocarbon (w/lugs), stainless steel, ATEX, Group A
11159-3	Super poison-resistant, sensor assembly, ATEX, Group A
11159-3L	Super poison-resistant, sensor housing (w/lugs), ATEX, Group A

11.2.2 Sensor Housing (Junction Box)

10252	CSA, FM-approved explosion-proof housing
B13-020	ATEX-approved, polyester housing
B14-020	ATEX approved, detector head assembly universal sensor

11.2.3 Sensor Accessories

10460-2	TGA-1 Remote Test Gas Applicator
10041-1	Duct Mounting Plate
10044-1	Dust Guard Kit - 1 Guard, 12 Replaceable Screens
10042-1	Replaceable Screens, Box of 12
10395-1	Splash Guard Assembly
50060-1	H ₂ S Guard Filter
50061-1	Purafil Insert Assembly
10110-1	Dust Guard Assembly
1800822	Dust Guard, Sintered SST
10066	Flow Block

11.2.4 Calibration Equipment

10543-1	3-Liter Calibration Chamber with 250 μ L Syringe
928-700	Dish for the 3-Liter Chamber
928-715	250 μ L micro liter syringe
1400150-M	Portable Purge Calibrator, Methane @ 50% LEL
1400150-H	Portable Purge Calibrator, Hydrogen @ 50% LEL
1400150-BD	Portable Purge Calibrator, Butadiene @ 50% LEL
1400150-B	Portable Purge Calibrator, Butane @ 50% LEL
1400150-E	Portable Purge Calibrator, Ethane @ 50% LEL
1400150-PR	Portable Purge Calibrator, Propane @ 50% LEL
1400150-4X	Portable Purge Calibrator, Hexane @ 50% LEL
1400155-M	Replacement Cylinder, Methane @ 50% LEL
1400155-H	Replacement Cylinder, Hydrogen @ 50% LEL
1400155-BD	Replacement Cylinder, Butadiene @ 50% LEL
1400155-B	Replacement Cylinder, Butane @ 50% LEL
1400155-E	Replacement Cylinder, Ethane @ 50% LEL
1400155-PR	Replacement Cylinder, Propane @ 50% LEL
1400155-4X	Replacement Cylinder, Hexane @ 50% LEL
922-009	Pressure Regulator Gauge
1400152-1	Small Calibration Cup
1400154	Large Calibration Cup
925-026	Tubing

Cylinder refills are available for Methane and Hydrogen only. Replacement cylinders must be ordered for the other gases.

11.3 Metal Oxide Semiconductor (MOS H₂S) Sensors

General Monitors uses a proprietary Metal Oxide Semiconductor (MOS H₂S) film on the sensor for detecting the presence of H₂S gas. The MOS H₂S film is deposited onto a substrate between two electrodes (see Figure 59).




Figure 55: MOS H₂S Gas Sensor

With no gas present, the electrical resistance between these two electrodes is very high (in mega-ohms). As H₂S adsorbs onto the film, the resistance between the electrodes decreases (to kilo-ohms). This decrease in resistance is logarithmically proportional to the concentration of H₂S that is present.

The process of H₂S adsorbing onto the MOS H₂S film is most effective at an elevated temperature. On the outer edge of the substrate is a heater ring. The temperature of this heater ring is measured with a thermistor and kept constant by a circuit located inside the body of the sensor.

As H₂S adsorbs onto the MOS H₂S film, electrons move more freely from one electrode to the other. This is represented by a decrease in resistance. The process of H₂S adsorbing onto the MOS H₂S film is completely reversible. As the concentration of H₂S decreases (as H₂S desorbs), the resistance between the electrodes will increase.




Figure 56: Movement of Electrons on MOS H₂S Film

11.4 MOS H₂S Sensor Spare Parts and Accessories

To order spare parts and/or accessories, please contact your nearest General Monitors Representative, or General Monitors directly, and give the following information:

Part Number of Spare Part or Accessory

Description of Spare Part or Accessory

Quantity of Spare Part or Accessory

11.4.1 Sensors

50445-1	0-100 ppm, aluminum body, wire screen arrestor, CSA, FM
50445-5	0-50 ppm, aluminum body, wire screen arrestor, CSA, FM
50445-9	0-20 ppm, aluminum body, wire screen arrestor, CSA, FM
50448-1	0-100 ppm, stainless steel body, wire screen arrestor, CSA, FM
50448-5	0-50 ppm, stainless steel body, wire screen arrestor, CSA, FM
50448-9	0-20 ppm, stainless steel body, wire screen arrestor, CSA, FM
51457-1	0-100 ppm, sintered screen, stainless steel body, ATEX, CSA, GOST
51457-5	0-50 ppm, sintered screen, stainless steel body, ATEX, CSA, GOST
51457-9	0-20 ppm, sintered screen, stainless steel body, ATEX, CSA, GOST

11.4.2 Sensor Housing (Junction Box)

10252 Universal Housing

11.4.3 Sensor Accessories

10041-1 Duct Mounting Plate

10044-1	Dust Guard Kit - 1 Guard, 12 Replaceable Screens
10042-1	Replaceable Screens, Box of 12
10395-1	Splash Guard Assembly
10110-1	Dust Guard Assembly
1800822	Dust Guard, Sintered SST

11.4.4 Calibration Equipment

50000	Breaker Bottle, Single
50020	Breaker Bottle, Double
50004-3	Individual Ampoules, 10 ppm (12 minimum)
50004-21	Individual Ampoules, 25 ppm (12 minimum)
50004-13	Individual Ampoules, 50 ppm (12 minimum)
50008-9	12 Ampoules at 50 ppm (0-100ppm scale)
50008-16	12 Ampoules at 25 ppm (0-50ppm scale)
50008-10	12 Ampoules at 10 ppm (0-20ppm scale)
50009-9	12 Ampoules at 50 ppm, includes breaker bottle (0-100ppm scale)
50009-16	12 Ampoules at 25 ppm, includes breaker bottle (0-50ppm scale)
50009-10	12 Ampoules at 10 ppm, includes breaker bottle (0-20ppm scale)
914-135.1	Case for Portable Purge Assembly
922-016	Replacement Regulator (0.2 L/min)
925-430.1	Replacement Hose
960-345	Hose Clamp, 5/16"
960-346	Hose Clamp, 1/4"
1400250-1	10 ppm H ₂ S Portable Purge Calibration Assembly
1400250-3	25 ppm H ₂ S Portable Purge Calibration Assembly
1400250-5	50 ppm H ₂ S Portable Purge Calibration Assembly
1400255-1	10 ppm H ₂ S Replacement Cylinder
1400255-3	25 ppm H ₂ S Replacement Cylinder
1400255-5	50 ppm H ₂ S Replacement Cylinder
1400152-1	Calibration Cup

11.5 MC600 System Upgrades and Accessories

Following are upgrade kits for expanding your MC600 system and some accessories for use with the MC600.

11.5.1 MC600 Upgrade Modules

65003-2	Power Supply Upgrade Assembly with Mounting Hardware
65003-3	Class I Division 2 Power Supply Upgrade Assembly with Mounting Hardware
65074-1	Sounder Upgrade Assembly
65101-1	4-20mA Signal Conditioning Card Upgrade Assembly
65111-1	Catalytic Signal Conditioning Card Upgrade Assembly
65121-1	MOS H ₂ S Signal Conditioning Card Upgrade Assembly

11.5.2 MC600 Accessories

65088-1	Type 4X Cable Entry Plugs
65087-1	Type 4X Type Sounder Plug Assembly

12.0 Installing Upgrades

There are three types of upgrades you can add to your MC600 system:

Power supply for the MC600 cabinet

MOS H₂S, catalytic HC, or 4-20mA signal conditioning card

Sounder for the MC600 cabinet door

Instructions for installing each type of upgrade are included in this chapter.

Please review the following warning and caution before proceeding to install upgrade modules and related cabling. For information on non-hazardous location cabling to the MC600 cabinet, see NEC article 504. For information on Class I location seals for sensors mounted in hazardous areas, see NEC articles 501-5 and 500-3d.



WARNING: Under **NO** circumstances should equipment be connected or disconnected when under power. This is contrary to hazardous area regulations and may also lead to serious damage to the equipment. Equipment damaged in this manner is not covered under warranty.



CAUTION: The MC600 Multi-Channel Controller System and field-mounted sensor devices contain components that can be damaged by static electricity. Special care must be taken when wiring the system to ensure that only the connection points are touched.

NOTE: For additional cautions, warnings and standards, see Section 3.6.1

12.1 Adding a Signal-Conditioning Card

The part numbers for the signal-conditioning cards are:

65101-1	4-20mA Signal-Conditioning Card Upgrade Assembly
65111-1	Catalytic Signal-Conditioning Card Upgrade Assembly
65121-1	MOS H ₂ S Signal-Conditioning Card Upgrade Assembly

To Add a Signal-Conditioning Card to the MC600:

1. Remove system power and then push up the locks on the left and right side of the card slot.
2. Slide the signal-conditioning card into the slot, making sure that the connector is seated in the connector slot on the MC600 backplane.
3. Once the card is seated in the slot, push down the locks on each side of the slot to lock the card in place.
4. Connect a sensor or instrument to the signal-conditioning card, following the instructions in Section 3.6
5. Once you are ready to power on the system again, you will need to set up the channel where the card is installed by selecting a model option for the attached sensor or instrument. For instructions, see Section 5.1.1.
6. After selecting a model option, you may also need to calibrate the connected device. For instructions, see **Calibrating Catalytic HC and MOS H₂S Sensors** in Section 4.5 or **Calibrating the LCD Display for 4-20mA Instruments** in Section 4.6.

12.2 Adding a Power Supply to the MC600 Chassis

The Power Supply Upgrade Assembly (Part Number 65003-2) includes five screws in a bag attached to the power supply. Only four screws are needed, the fifth is a spare for your convenience. You will need to provide cabling to connect the power supply to an AC power source.

To Install the Power Supply:

1. Carefully cut the cable tie that holds the hardware bag on the front right side of the power supply, and remove the hardware from the bag.
2. Place the power supply on the mounting plate inside of the enclosure as shown. Secure the unit in place using four of the screws provided in the bag.




Figure 57: Power Supply

3. Verify the voltage select switch is selected to the proper input voltage used for the assembly.
4. Seat the Power Supply connector in the MC600 control board J9 mating connector, and tighten the two setscrews.




Figure 58: Power Supply Connector

5. With power removed, connect cabling to AC input to the connector provided on the Power Supply assembly board.
6. To power on the MC600, follow the guidelines in Section 3.9.

12.3 Adding a Class 1 Division 2 Power Supply to MC600 Chassis

The Power Supply Upgrade Assembly (Part Number 65003-3) includes six screws. Only four screws are needed, the extra two may be considered spares. You will need to provide cabling to connect the power supply to an AC power source.




Figure 59: MC600 Class I Division 2 Power Supply

To install the power supply:

1. Carefully cut the cable tie that holds the hardware bag in the front right side of the power supply and remove the hardware from the bag.
2. Place the power supply on the mounting plate inside of the enclosure. Secure the unit in place, using four of the screws provided in the bag.
3. Seat the power supply connector in the MC600 control board J9 mating connector and tighten the two setscrews.
4. With power removed, connect cabling to AC input to the connector provided on the power supply assembly board.
5. To power on the MC600, follow the guidelines in Section 3.9.

12.4 Adding a Sounder

You can install a Sounder Upgrade Assembly (Part Number 65074-1) in the MC600 cabinet front door to add an audible indicator.

To Add a Sounder Unit:

1. Remove the plug from the sounder opening.
2. Unscrew the two halves of the sounder unit.

- Place the sounder unit with the wiring inside the cabinet door; making sure that a rubber gasket is in place at the top of the threading.




Figure 60: Sounder Unit

- Fasten the unit in place by placing the sounder's guard cap on the outside of the cabinet door, then fastening the guard to the sounder to anchor the unit in place.
- Plug the connector at the end of the sounder cabling into the connector socket at the bottom of the LCD board inside of the MC600 cabinet front door.




Figure 61: LCD Board

Index

- [ACCEPT]
 - MC600 navigation button, 29
- [ENTER]
 - MC600 navigation button, 29
- [MODE] button
 - for entering and exiting menus, 29
- [RESET]
 - MC600 navigation button, 29
- 3-liter chamber
 - ordering information, 114
- 4-20mA instrument model options, 54
- 4-20mA signal card upgrade
 - ordering information, 118
- advanced menu options
 - descriptions, 51
- Alarm Hi set point range, 42
- Alarm Lo set point range, 43
- ampoules of gas
 - ordering information, 117
- ATEX
 - rating for explosion-proof junction box, 26
- basic menu options, 30
- basic Setup menu options, 41
- breaker bottle
 - for MOS sensor calibration, 35
 - ordering information, 117
- brightness adjustment, 25
- buttons for navigating the MC600 menus, 29
- Cal Channel
 - error message, 77
- Cal Fault
 - error message, 77
- calibration
 - equipment for Catalytic sensors, 34
 - equipment for MOS sensors, 35
 - for 4-20mA channel displays, 37
 - for oxygen detection instruments, 37
 - messages for 4-20mA instruments, 37
 - messages for Catalytic and MOS sensors, 36
 - of 4-20mA instruments, 32
 - of connected sensors, 32
 - preparing for, 33
 - procedure, 35
 - required directly after startup, 25
 - stopping, 36
- calibration check
 - LCD messages, 39
- Calibration Check
 - procedure, 39
- Calibration Check Mode
 - prevents alarm relay activation, 38
- calibration checking, 38
- calibration equipment
 - 3-liter chamber, 72
 - portable purge calibrator for H₂S, 73
- calibration for maintenance, 71
- calibration point configuration
 - procedure, 47
- Card Removed
 - error message, 77
- Card Test
 - portion of self test, 68
- Card Test setup submenu, 60
- catalytic hydrocarbon sensors
 - principle of operation, 112
- catalytic sensor
 - ordering information, 113
- Catalytic sensor
 - model options, 52
 - spare parts and accessories, 113
- Catalytic sensor cable length
 - specifications, 110
- Catalytic sensors
 - operation mode display, 23
 - setpoint ranges, 43
- Catalytic signal card upgrade
 - ordering information, 118
- channels preconfigured
 - per customer order, 51
- checking calibration, 38
- cleaning the MC600, 74
- CON FAIL / COMM
 - error message, 76
- CON FAIL / EEPROM
 - error message, 76
- CON FAIL / LOW LINE
 - error message, 76
- CON FAIL / PROGRAM
 - error message, 76
- CON FAIL RAM
 - error message, 76
- configuration
 - preset for channels, 51
- CSA, 110
- CSA Class I ratings
 - for junction box housing, 26
- CSA/FM, 26
- De-energized relay setting, 49

- default settings
 - for Setup Load Defaults menu option, 65
- Display O Setup menu, 25
- display range
 - specifications, 103
- Display Test
 - portion of self test, 68
- documentation for GM products, vi
- duct mounting plate
 - ordering information, 114, 117
- dust guard assembly
 - ordering information, 114
- dust guard kit
 - ordering information, 114, 117
- Energized relay setting, 49
- error messages
 - Cal Channel, 77
 - Cal Fault, 77
 - Card Removed, 77
 - CON FAIL / COMM, 76
 - CON FAIL / EEPROM, 76
 - CON FAIL / LOW LINE, 76
 - CON FAIL / PROGRAM, 76
 - CON FAIL RAM, 76
 - Field Device Fault, 77
 - Invalid Card, 78
 - Sensor Error, 78
 - Setup Channel, 77
- EU approved applications
 - for alarm relays, 19
- Exception codes for MODBUS, 83
- Exception Response MODBUS message structure, 82
- explosion-proof sensor housings, 26
- factory configuration
 - channels setup for customer, 51
- fault relay configuration, 63
- fault relays
 - active / inactive during calibration & setup, 63
- Field Device Fault
 - error message, 78
- field upgrades
 - configuring channels, 51
- front panel diagnostics, 26
- glycol, 9
- GM product documentation, vi
- grease compounds for lubricating the MC600, 74
- H₂S, ii
- H₂S sensor cap warning, 71
- halides, 9
- heavy metals, 9
- Hydrogen Sulfide
 - Catalytic sensor poison, 9
 - hydrogen sulfide portable calibrator, 73
- Inhibit submenu
 - password, 61
- inhibiting alarms, 40
 - procedure, 40
- installation
 - connecting alarm relay devices, 18
 - connecting the MC600 to a power source, 20
 - power-up readiness steps, 20
 - startup operation and configuration tasks, 24
 - using appropriate cable termination, 13
- Invalid Card
 - error message, 78
- IR2100
 - setpoint ranges, 44
- IR7000
 - setpoint ranges, 44
- junction box
 - ordering information, 113, 116
- Latched relay setting, 49
- LCD brightness adjustment, 25
- LED brightness adjustment, 25
- legend for MC600 menus, 29
- lubricants for the MC600, 74
- main menu overview, 31
- maintenance activities
 - calibration checks, 71
 - cleaning recommendations, 74
 - storage recommendations, 75
- maintenance activities lubrication recommendations, 74
- maintenance schedules, 71
- MC600
 - maintenance schedules, 71
- MC600
 - menu legend, 29
 - menu overview, 30
 - power-on start-up process, 23
 - power-up readiness checklist, 20
- MC600 outline and dimensional drawing, 107
- mechanical specifications
 - for MC600, 106
- menu options advanced, 50
- menu overview, 30
- messages during calibration, 36
- MODBUS channel setup
 - address, 64
 - baud rate, 64
 - data format, 64
- MODBUS overview, 79
 - baud rate settings, 79
 - serial data format settings, 79

- supported function codes, 79
- MODBUS registers
 - alarm states, 101
 - baud rates for MODBUS Channels, 91
 - Catalytic and MOS sensor types, 98
 - channel mode descriptions, 96
 - data formats for MODBUS Channels, 91
 - Mode bitmap for MC600 operations, 88
 - unit error status bitmap, 88
- Mode MODBUS register
 - for MC600 operation, 88
- model selection
 - procedure, 54
- MOS sensor
 - model options, 52
 - ordering information, 116
 - spare parts and accessories, 116
- MOS sensor cable length
 - specifications, 110
- MOS sensors
 - operation mode display, 23
 - principle of operation, 115
 - setpoint ranges, 43
- MOS signal card upgrade
 - ordering information, 118
- navigation buttons
 - for MC600 menus, 29
- NEMA 4X cable entry plugs
 - ordering information, 118
- NEMA 4X sounder plug assembly
 - ordering information, 118
- Not Latched relay setting, 49
- operating humidity specifications, 109
- operating temperature for Catalytic sensors, 109
- operating temperature for MOS sensors, 109
- operating temperature specifications, 109
- operation mode displays, 23
- ordering information
 - Catalytic sensor parts and accessories, 113
 - catalytic sensors, 113
 - MOS sensor parts and accessories, 116
 - MOS sensors, 116
 - or MC600 upgrade kits and accessories, 118
- outline and dimensional drawing
 - for MC600, 107
- password
 - configuration, 61
 - procedure to define, 62
 - procedure to disable, 62
- portable purge calibration equipment
 - ordering information, 117
- portable purge calibrator
 - for Catalytic sensors, 34, 35
 - ordering information, 114
- power supply upgrade
 - ordering information, 118
- power-on start-up process, 23
- power-up readiness checklist, 20
- Preset Single Register MODBUS code, 79
- principle of operation
 - catalytic hydrocarbon sensors, 112
 - MOS sensors, 115
- ramp time
 - for card test, 60
- Read Holding Registers MODBUS code, 79
- Read Query MODBUS message structure, 80
- Read Response MODBUS message structure, 80
- readiness checklist
 - before power-on startup, 20
- relay activation timing, 49
- relay assignments to channels
 - default setting, 48
- relay assignments with no zoning, 59
- relay configuration, 47
 - procedure, 49
- relay for faults
 - setting up, 63
- relay ratings specifications, 110
- relay sharing
 - single zoning, 55
- replacement gas cylinders
 - ordering information, 114
- restoring an inhibited alarm
 - procedure steps, 41
- RS-485 specifications, 110
- S104
 - setpoint ranges, 45
- S106A
 - setpoint ranges, 45
- S214
 - setpoint ranges, 45
- S216A
 - setpoint ranges, 45
- S4000C
 - setpoint ranges, 44
- S4000T
 - setpoint ranges, 44
- S4100C
 - setpoint ranges, 45
- S4100T
 - setpoint ranges, 45
- Self Test submenu, 68
 - card test, 68
- Sensing Elements, 115

- sensor compatibility
 - specifications, 103
 - Sensor Error
 - error message, 78
 - Sensor Life nnn %
 - LCD message, 39
 - message during calibration, 35
 - set point configuration for alarms and warnings
 - procedure, 46
 - set points
 - or Alarm Hi, Alarm Lo and Warning, 42
 - Setup Card Test submenu, 60
 - Setup Channel
 - error message, 77
 - Setup Channels submenu, 42
 - Model Options for Catalytic and MOS Sensors, 52
 - Setup Channels submenu Model Options for 4-20mA Instruments, 54
 - setup Fault Relays submenu, 63
 - Setup Load Defaults submenu, 65
 - Setup menu
 - basic options, 41
 - password, 61
 - Setup menus
 - advanced menu options, 51
 - Setup MODBUS submenu, 64
 - Setup Password submenu, 61
 - Setup Relays menu option, 41
 - Setup Relays submenu, 48
 - Setup Zoning submenu, 55, 58
- silicones, 9
 - solvents for cleaning the MC600, 74
 - sounder upgrade assembly
 - ordering information, 118
 - sounder volume adjustment, 26
 - specifications
 - sensor compatibility, 103
 - specifications
 - agency approvals, 110
 - Catalytic sensor cable lengths, 110
 - Catalytic sensor operating temperature, 109
 - display range, 103
 - MC600 operating humidity, 109
 - MC600 operating temperature, 109
 - MC600 relay ratings, 110
 - MC600 storage temperature, 109
 - mechanical, 106
 - MOS sensor cable lengths, 110
 - MOS sensor operating temperature, 109
 - RS-485 output, 110
 - splash guard assembly
 - ordering information, 114, 117
 - startup operation and configuration tasks, 24
 - storage recommendations for the MC600, 75
 - storage temperature specifications, 109
 - test gas applicator, 72
 - TGA-1, 72
 - ordering information, 114
 - TS400
 - setpoint ranges, 43, 44
 - TS420
 - setpoint range, 44
 - upgrade installation
 - procedures
 - to add a power supply upgrade, 120
 - to add a signal card upgrade, 119
 - to add a sounder unit upgrade, 122
 - upgrades in field
 - require channel setup, 51
 - VDC cable length
 - specifications, 110
 - volume adjustment, 26
 - Warning set point range, 43
 - warranty information, ii
 - warranty requirements, 76
 - Write Query MODBUS message structure, 81
 - Write Response MODBUS message structure, 81
 - X/P Integrity, 26
 - zoneless relay assignment, 59
 - zoning and relay assignments summary, 57
 - zoning configuration, 55
 - zoning submenu, 58



ADDENDUM

This product may contain hazardous and/or toxic substances.

EU Member states shall dispose according to WEEE regulations. For further WEEE disposal information please visit: www.MSAafety.com

All other countries or states: please dispose of in accordance with existing federal, state and local environmental control regulations.