

Oster®

Model
TSSTTR2BDS

User Manual
2 Slice Toaster

Oster®

For product questions contact:

Sunbeam Consumer Service

USA: 1.800.334.0759

www.Oster.com



© 2020 Sunbeam Products, Inc. All rights reserved.

Distributed by Sunbeam Products, Inc., Boca Raton, Florida 33431.

Printed in China
TSSTTR2BDS_20EM1 (US)

P.N. 202287
GCDS-OST-JC

Congratulations on your purchase of an OSTER® Toaster! To learn more about OSTER® products, please visit us at www.oster.com

www.oster.com

IMPORTANT SAFEGUARDS


When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons including the following:

1. Read all instructions before using this product.
2. This appliance generates heat during use. Do not touch hot surfaces. Use handles or knobs. Always protect your hands with non-slip oven mitts or similar.
3. To protect against electric shock, do not place or immerse cord, plugs, or appliance in water or other liquid.
4. This appliance is not intended for use by children or by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge. Close supervision is necessary when any appliance is used near children. Children should be supervised to ensure that they do not play with the appliance. Keep the appliance and its cord out of reach of children.
5. Unplug from outlet when not in use, before putting on or taking off parts and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning. To disconnect, turn any control to OFF, then unplug power cord from outlet. Do not disconnect by pulling on cord. Always grasp the plug and pull to disconnect.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Do not attempt to replace or splice a damaged cord. Return appliance to the manufacturer (see warranty) for examination, repair or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors or for commercial purposes.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near wet surfaces, or heat sources such as a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids. Always protect your hands with non-slip oven mitts or similar.
12. Do not use appliance for other than intended use. Misuse can cause injuries. Intended for household countertop use only. Keep 6 inches (152 mm) clear from the wall and on all sides. Always use appliance on a dry, stable, level surface.
13. Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may involve a risk of fire or electric shock.
14. A fire may occur if toasters are covered, touching or near flammable materials, including curtains, draperies, towels, walls, and the like, when in operation. Do not place any item on top of the appliance when in operation.
15. Do not attempt to dislodge food when toaster is plugged in.
16. Do not operate this toaster unattended.

17. When heating toaster pastries, follow the instructions in the manual for toaster pastries. If no instructions are provided specific to toaster pastries, always use the lightest toast color setting.
18. To reduce the risk of fire, empty the crumb tray after each use.
19. Do not use with a programmer, timer, wireless plug adapter or outlet that allows control remotely, or connect to a circuit that is regularly switched on and off by the utility.

SAVE THESE INSTRUCTIONS

HOUSEHOLD USE ONLY



POLARIZED PLUG

This appliance has a polarized plug (one blade wider than the other). As a safety feature to reduce the risk of electrical shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature or modify the plug in any way. If the plug fits loosely into the AC outlet or if the AC outlet feels warm do not use that outlet.

POWER CORD INSTRUCTIONS:

A short power-supply cord or detachable power-supply cord is provided to reduce risks resulting from becoming entangled in or tripping over a longer cord. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use. If a long detachable power-supply cord or extension cord is used:

- a. The marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance;
- b. The cord should be arranged so that it will not drape over the counter top or table top where it can be pulled on by children or tripped over unintentionally; and
- c. If the appliance is of the grounded type, the cord set or extension cord should be a grounding type 3-wire cord.

Do not pull, twist or otherwise abuse the power cord.

NOTICES:

1. Some countertop and table surfaces are not designed to withstand the prolonged heat generated by certain appliances. Do not set the heated unit on a finished wood table. We recommend placing a hot pad or trivet under your toaster to prevent possible damage to the surface.
2. During initial use of this appliance, some slight smoke and/or odor may be detected. This is normal with many heating appliances and will not recur after a few uses.

Learning About Your Toaster



1. Bread slots
2. Toast Lift Lever
3. Bread Selector Dial
4. Browning control
5. Cancel button
6. Frozen button
7. Gluten Free button
8. Crumb tray (at rear)

BREAD SELECTOR DIAL

The Bread Selector Dial has 5 preset cycles that adjust the toasting time for greater toast results. Each preset has been calculated to optimally toast each food type. See Toasting Tips for more information on toasting different bread types.

BROWNING CONTROL

The Browning control regulates how much the bread is toasted—in other words, the color of the toast. Lower settings produce lighter toast and higher settings produce darker toast.

When setting the browning control, remember that dry or thin food will toast quicker and require a lower setting. Moist or thick food will require a higher setting.

FROZEN BREAD BUTTON

The Frozen bread button allows you to toast bread straight from the freezer. Insert the bread into your toaster and make your Bread and Browning Control Selections. Then press the toast lever down and press the Frozen button. Once pressed, the button will illuminate to indicate selection has been made. Your toaster will extend the toasting time for each Bread Selection to allow the food to defrost.

NOTE: If Waffle is chosen on Bread Selector Dial, Frozen cycle will automatically be engaged. If toasting room temperature Waffles, turn off Frozen cycle by pressing button when illuminated.

GLUTEN FREE BUTTON

The Gluten Free button extends the cycle time for each Bread Selection to accommodate for Gluten Free foods. Insert the bread into your toaster and make your Bread and Browning Control Selections. Then press the toast lever down and press the Gluten Free button. Once pressed, the button will illuminate to indicate selection has been made.

NOTE: Gluten Free can be activated with Frozen button for Gluten Free Frozen Foods.

CANCEL BUTTON

The toasting process can be stopped at any time by pressing the cancel button. The cycle will stop and the food will pop up immediately.

TOAST LIFT LEVER

The Toast Lift Lever allows the use of the loading handle to help you remove the toast. When toasting has finished, lift the loading handle upwards from its rest position to raise the toast and make it easier to remove.

BEFORE FIRST USE

▲ CAUTION! Never force bread into the toasting slots. Bread should fit easily into the toasting slots. Never toast slices of bread that have been buttered. Take extra care when toasting items that contain sugar, jam or preserves, as there is a risk of the ingredients leaking into the toaster, causing overheating. Don't use bent, damaged or broken bread in your toaster as it may cause it to jam.

Carefully remove your toaster from its box. Remove all packaging from inside the toasting slots.

Position your toaster on a stable, secure, dry and level work surface away from the edge. Bread may burn therefore do not use the appliance near or below combustible materials such as curtains. Never use the toaster below wall cupboards or shelves. Position toaster at least 3 inches away from wall or rear of counter.

Plug the cord into a 120 volt, 60 Hz AC outlet. Connect the plug to a suitable power outlet and make sure that the power cord does not overhang the work surface.

When you first use your toaster, there may be a slight odor as the heating elements warm up for the first time. This is quite normal and not a cause for concern. To remove the odor, simply operate your toaster for the first time without any bread in it.

USING YOUR TOASTER

1. Set the level of toasting using the browning control. The higher the number selected, the darker the toast will be.
 2. Place the bread into the toasting slots. Only toast single slices of bread in each slot on 2 slice toasters. Make Bread selections using the Bread Selector Dial, then press the Toast Lever down until it latches. The bread will be lowered into the toaster and toasting will begin. The toast lever will not latch if your toaster is not connected to a working outlet.
 3. When toasting has finished, the Toast Lever will rise and the toasted bread can be removed. You can lift the Toast Lever upwards beyond its rest position to help you remove the toast.
 4. If the toast is not done enough it can be toasted again. Turn the browning control to a lower setting and keep a careful eye on the toast to ensure that it doesn't burn.
 5. Toasting can be stopped at any time by pressing the cancel button.
- For fresh bread or whole wheat bread, use a higher setting than normal.
 - Bread which has a very uneven surface, such as English Muffins or Waffles, will require a higher setting.
 - Thicker cut pieces of bread (including bagel) will take longer to toast—sometimes significantly longer. This is because more moisture must be evaporated from the bread before toasting can occur. Very thick pieces of bread may require two toasting cycles.
 - When toasting raisin or other fruit breads, remove any loose raisins or fruit from the surface of the bread before putting it into your toaster. This will help prevent fruit pieces from falling into your toaster or sticking to the guard wires in the toasting slot.

TOASTING TIPS

- Toasting is a combination of drying and cooking bread. Moisture levels differ from one bread type to another so toasting times may vary. Be sure to use evenly cut slices of bread to ensure even toasting.
- For slightly dry bread, use a lower setting than normal.

NOTES:

- The Auto-Adjusting Bread Guides will automatically center the food for even browning.
- Be sure to check the Bread Selector Dial for desired setting before each use. Having the correct selection for the food toasted will yield better results.
- To use the Toast Lift, press up on the bread carriage lever to lift food out of the bread slots. It is a convenient and safe way of retrieving the smallest of toasted items.

GENERAL INFORMATION

Tip: Your toaster has been designed for optimal toast balance. Some elements on the inside of the toaster may glow more brightly than others when in use. This is part of normal toaster operation.

To remove food jammed in the bread slots: unplug the toaster and remove the food once the toaster has cooled down.

Do not place food on top of toaster while it is warming.



WARNING! Empty the Crumb Tray frequently. Crumbs will accumulate in the Crumb Tray and could catch fire if not emptied periodically.

Cleaning Your Toaster

- After use and before cleaning, unplug wall plug and wait for toaster to cool.
- Wipe the outside of toaster with a damp cloth and dry with another cloth or paper towel. Do not use abrasive cleaners.
CAUTION: Do not immerse in water or any liquid.
- To avoid damage to toaster heating elements, do not use any pointed or sharp articles for cleaning the inside of the toaster.
- **CAUTION:** Empty the crumb tray frequently. Crumbs will accumulate in the crumb tray and could catch fire if not emptied periodically. When the toaster has cooled down completely, tap the sides of the toaster lightly to dislodge any crumbs caught in the toaster chamber, remove the crumb tray and empty it. Wipe the tray clean with a damp cloth or place it in the top rack of your dishwasher for cleaning. Tap sides again to ensure proper disposal. Return crumb tray back into the toaster before using again.

This appliance has no user serviceable parts. Any servicing beyond that described in the Cleaning Section should be performed by an Authorized Service Representative only. See Warranty Section.

One Year Limited Warranty

Sunbeam Products, Inc (Sunbeam) warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. Sunbeam, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. Do NOT attempt to repair or adjust any electrical or mechanical functions on this product. Doing so will void this warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Sunbeam dealers, service centers, or retail stores selling Sunbeam products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than Sunbeam or an authorized Sunbeam service center. Further, the warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

What are the limits on Sunbeam's Liability?

Sunbeam shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty.

Sunbeam disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise.

Sunbeam shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including but not limited to: incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service

In the U.S.A.

If you have any question regarding this warranty or would like to obtain warranty service, please call 1-800-334-0759 and a convenient service center address will be provided to you.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc., located in Boca Raton, Florida 33431. If you have any other problem or claim in connection with this product, please write our Consumer Service Department.

PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.

