

The Rubbermaid logo is a red, rounded rectangular shape with a white border. Inside, the word "Rubbermaid" is written in white, bold, sans-serif font. A small registered trademark symbol (®) is located to the right of the word.

Revision B: 4/09/2021

Rubbermaid® DuraLite™ Bakeware Containers

SAFETY AND USE INSTRUCTIONS

Read these Instructions before use and save for future reference. For more information, visit www.rubbermaid.com or call Rubbermaid® Consumer Service Department at 888-895-2110.

Rubbermaid® DuraLite™ bakeware is made of a unique type of glass, fluosilicate, that is designed for high heat tolerance and durability. Glass bakeware products require the utmost care, especially when cooking foods at hot temperatures. While our product is designed for durability, glass bakeware can break or cause injury when not following these guidelines. The plastic lid is suitable for storage and microwave reheating only and cannot be used in the oven. Keep out of reach of children.

WARNING: FAILURE TO CAREFULLY FOLLOW SAFETY AND USE INSTRUCTIONS MAY CAUSE PRODUCT TO FRACTURE IMMEDIATELY OR IN THE FUTURE, WHICH COULD RESULT IN PERSONAL INJURY OR PROPERTY DAMAGE.

- **Avoid severe and sudden temperature changes:**
 - Do not take product directly from freezer to oven or microwave.
 - Always thaw food before reheating.
 - Do not add liquid to hot Rubbermaid® DuraLite™ bakeware.
 - Do not place hot bakeware on a wet or cool surface, such as a countertop, metal surface, or sink.
 - Always place hot bakeware on a dry potholder or trivet.
 - Do not handle hot bakeware with a wet potholder or towel.
 - Allow bakeware to cool before washing, refrigerating or freezing.
 - Be sure to preheat oven before inserting bakeware.

- **Use caution with direct heat sources:**
 - Bakeware can be used under a broiler or in a toaster oven for less than 10 minutes.
 - Not for stovetop or grill use.

- **Do not use scratched, cracked or chipped bakeware:**
 - Do not drop or hit against hard surfaces.
 - Do not use hard utensils that can scratch the base.

- Avoid striking product with or against hard or sharp objects.
- Do not attempt to repair any bakeware that is chipped, cracked, or scratched.

Cleaning Instructions: Wash before use. Dishwasher safe (use top rack for the lids). When washing by hand use non-abrasive cleansers. If more vigorous cleaning is necessary, soak and clean with non-scratch plastic or nylon scouring pad. Allow base and lid to dry completely before storage.

General Usage: Inspect bakeware before each use. Use for food storage and heating using conventional and microwave ovens only. Do not heat using a stovetop, toaster oven, grill or microwave with a browning element. When using in a freezer, allow space for liquids in the food to expand. Product is intended for normal household use only. Not intended for industrial use, commercial use, or camping. Do not use to microwave popcorn or as a corn bag holder in the microwave. Do not lift the bakeware by the lid or latches when the lid is installed.

Discard if chipped, cracked or scratched since this can lead to fracturing. If damage occurs, be careful when handling broken or chipped glass pieces. The container will break in large pieces making it easier to handle but broken glass should always be handled very carefully to avoid personal injury. Use protective gloves and keep children and other household members away until done cleaning.

Conventional Oven Usage Instructions: The bases are safe for use in ovens up to 550°F. Remove the plastic lid before oven use. Always handle hot bakeware with dry potholders. Oven must be preheated before placing your bakeware in it. When cooking food items that may release fats or liquids, add a small amount of liquid to the bottom of the bakeware before inserting it in the oven. Allow the bakeware to cool so it is comfortable to touch before cleaning or installing the lid.

Microwave Usage Instructions: The base is microwave safe. The plastic lid is microwave safe when used to reheat prepared foods to temperatures comfortable for eating. Follow your microwave manufacturer's instructions. Do not microwave to food temperatures over 165° F for more than 30 seconds when using the plastic lid. Do not microwave an empty nor nearly empty container. Do not install lid on securely when reheating food in the microwave. Remove lid before heating in the microwave or ensure the lid is askew on the base to allow for venting. Use caution handling the container and removing the lid as contents can be hot. Remove the lid promptly after microwave. Use minimum cooking time to heat oil and butter in a microwave.