## Installing the Filter



This filter is to be installed in the fluid return line at the power steering pump.

- 1. Loosen the clamp which holds the return hose onto the pump reservoir.
- 2. Remove the return hose from the reservoir.

  NOTE: Inspect the hose for cracks, deterioration or other defects.

  If defective, a new hose must be installed.
- **3.** Insert the filter in the hose at the reservoir. It must be installed with the large open end of the filter inserted into the hose, and the forked end to the pump.
- **4.** Reconnect the hose to the reservoir, being careful to avoid bends or kinks in the first three inches of hose at the reservoir. Such kinks or bends could damage the filter.
- **5.** Tighten the hose clamp and refill the reservoir with new specified power steering fluid.

