

MSA Cairns

4-Point Chin Strap Upgrade Kit (P/N 10172168)

For MSA Cairns 1010/1044 Fire Helmets

1. Remove the two straps from packaging. Disconnect the yellow Quick Release buckle on the chin strap.



2. Locate the loop under/behind both the yellow Quick Release buckle and Postman's slide on each side of the helmet. For chin straps without Postman's Slide, skip to step 6.

3. Slide the black clip through the chin strap loop and attach as shown.



4. Repeat step 3 for the second strap to locate the loop under/behind the Postman's Slide.



5. Feed the free end of the strap through the corresponding 4-point chin strap channel located on the rear side of the Impact Cap. Feed only the hook portion of the hook and loop attachment on the strap through the channel. Ensure the hook and loop are able to attach to each other toward the outside of the helmet, away from the wearer's neck.



6. For chinstraps without Postman's Slide, perform steps 2 – 3. Then, for the opposite side, attach the black clip of the second strap as shown approximately 2.5" down from where the chinstrap is attached to the helmet.



7. By using the hook and loop attachments, adjust the length of the straps to fit your comfort requirements.



