



#### REMOVING THE ASSEMBLED ADAPTER

**A.**

Pull the cup down to the bottom of the yolk (1). Lift the blade until the spring clicks up (2).

**B.**

Point the attachment blade away from the cup and hold firmly (1). Push the arm up and over the blade to separate (2 + 3).

#### ASSEMBLING THE REPLACEMENT ADAPTER

**C.**

Push the ear muff arm into the new adapter and make sure it clicks into place.

**D.**

Insert the ear muff blade into the helmet slot. Press firmly at the top of the arm until the adapter clicks into place.