

PremAire® Combination

Combination Airline Escape Respirator



1 Put on belt and holster assembly.



2 Put on shoulder harness with cylinder demand valve airline assembly.



3 Attach cylinder to holster assembly and adjust shoulder strap.



4 Put on facepiece, adjust harness straps and test facepiece tightness.



5 Check gauge to ensure fully pressurized cylinder. Pull on airline hose, remove protection cap and connect pigtail to airline.*



6 Attach demand valve to facepiece and inhale once forcefully.

* Only for PremAire Combination equipped with an Automatic Switch Valve (approved to EN 14593-1). Connection to airline also possible for PremAire Combination approved to EN 402 only during escape as an emergency air source.