MEDICAL RECLINER BACK INSTALLATION INSTRUCTIONS

USED ON: ALL MEDICAL RECLINER MODELS



3. SLIDE LOWER BACK BOLT DOWN UNTIL LOWER BOLT IS RESTING IN THE NOTCH AT THE BOTTOM OF THE BRACKET



LIFT QUICK RELEASE BAR UP

5. PUSH QUICK RELEASE BAR DOWN TO LOCK BACK IN PLACE.



2. SLIDE LOWER BACK BOLT DOWN THE BACK BRACKET AS SHOWN



4. ROTATE BACK SO THAT UPPER BOLT RESTS IN THE UPPER NOTCH ON THE BRACKET.



KEEP QUICK RELEASE BAR UP

2/9/2010