






IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED ON THE BOTTOM OF SEAT CUSHION.

MODEL: 16245

(1)x1	(2)x1	(3)x1
 Seat Cushion	 TU001-305/Mechanism	 Back Cushion W/ Back Support & Bellow
(4)x1	**(5)x1**	**(6)x1**
 TU305-Knob/Knob	 TU026-240/5 / Gas Lift	 TU005-240/5 / Base
(7)x1	**(8)x1**	**(9)x5**
 TU009	 TU009-EXT	 TU015 / Casters


(A)x4  **M8X22 MECHANISM SCREW**



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.







Customer Service Hotline: 1-800-593-1888 For further assembly instructions, please visit our website at www.bosschair.com

08/13