


Congratulations on the purchase of your new OFFICIENT chair!

PARTS: REMOVE ALL THE PARTS FROM THE CARTON AND VERIFY PART QUANTITIES AS INDICATED IN THIS PARTS LIST. PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY. YOU WILL NEED A PHILLIPS-HEAD SCREWDRIVER.



- INSTRUCTIONS

STEP ONE Insert the CASTERS (A) into the BASE (B).

STEP TWO Insert the GAS LIFT © into the BASE.

STEP THREE Cover the GAS LIFT with the 3-piece TELESCOPIC BELLOWS ①.

STEP FOUR Place the CHAIR SEAT © on a level, non-abrasive surface and align the pre-drilled holes in MECHANISM with the holes in the CHAIR SEAT.

STEP FIVE Insert the four 1/4"x 3/4" SCREWS (1) through the holes in the SEAT MECHANISM into the holes in the CHAIR SEAT. Tighten with a screwdriver.


IF YOU ARE ASSEMBLING A MODEL WITH OPTIONAL ADJUSTABLE ARMS, PLEASE PROCEED TO THE NEXT PAGE FOR ASSEMBLY INSTRUCTIONS.

STEP SIX Carefully place the CHAIR SEAT with the attached SEAT MECHANISM onto the GAS LIFT aligning the hole in the SEAT MECHANISM with the GAS LIFT.

Press down on the CHAIR SEAT to secure onto the BASE.

STEP SEVEN Slide the SEAT BAR (1) (the end with the pre-drilled hole) under the CHAIR SEAT and into the slot in the SEAT MECHANISM.

STEP EIGHT Place the washers (and (b) on the threaded end of the BACK DEPTH ADJUSTMENT SCREW (1) and insert into the slot in the SEAT MECHANISM and into the pre-drilled hole in the SEAT BACK BAR. Hand tighten to hold in place.



CAUTION:
DO NOT USE THIS CHAIR AS A
STEP LADDER. PERIODICALLY
CHECK FOR LOOSE SCREWS
AND TIGHTEN THEM.

