



Congratulations on the purchase of your new *Signature Series* product!

INSTRUCTIONS


STEP 1




STEP 2




STEP 3



STEP 4



STEP 5




FILL WOOD DOWEL HOLE HALF WAY WITH GLUE FOR A STRONGER CONNECTION


Congratulations on the purchase of your new *Signature Series* product!

INSTRUCTIONS


STEP 6




STEP 7




STEP 8




STEP 9



STEP 10



STEP 11



**When adjustment height is OK,
Then use screw Q to fix the hinge
in the circular hole**

Congratulations on the purchase of your new *Signature Series* product!

INSTRUCTIONS

STEP 12

