









Put (B) Leg on (A) Table frame against (A.1) Metal Sheet. Match the screw holes of (B) and (A). MAKE SURE THE ARROW ON (A.1)&(B) ARE ALIGNED. Put in one washer and one screw for each hole, then fasten them.***ADVICE: DON'T FASTEN THE SCREWS TOO TIGHT BEFORE ALL THE SCREWS ARE PLACED IN.***

NOTICE: MAKE SURE THE ARROW ON (A.1)&(B) ARE ALIGNED.

(B)

(A)

(A)

(B)

