

# 3M<sup>™</sup> Attest<sup>™</sup> Mini Auto-reader 490M System<sup>\*</sup> Quick Reference Guide

### VH2O2 BI Preparation and Use



Inspect Remove BI from pouch and reseal. Verify media ampoule is intact and indicator stripes on cap are blue.



Pouch Place BI and chemical indicator (CI) in peel pouch indicated for use in vaporized hydrogen peroxide (VH2O2) sterilization processes.



3 Process Seal pouch and place in sterilizer with white side facing up. Process load as recommended by sterilizer manufacturer.



Identify After completion of cycle, inspect and verify media ampoule is intact and indicator stripes on cap have turned towards pink. Identify the BI by writing on the label.

# **STEAM and VH2O2 BI Activation and Incubation**



1 Crush Squeeze BI in activator to close cap and crush media ampoule.



2 Flick Remove BI and flick wrist to ensure media flows to growth chamber.



3 Inspect Verify media has transferred to BI growth chamber at the vial bottom.



4 Incubate

Place activated BI in any well. Display shows remaining minutes of incubation or test results.

DO NOT REMOVE BI until the (+) or (-) symbol indicates the test is complete.

# 3M<sup>™</sup> Attest<sup>™</sup> Mini Auto-reader 490M



- NOTES:
- Activate and incubate 1295 BI within 1 hour of completion of the VH2O2 sterilization cycle.
- Gloves are recommended when activating 1295 Bl.
- Allow 1491 and 1492V BIs to cool 10 minutes prior to activation.

# Interpretation of 3M<sup>™</sup> Sterilization Assurance Core Products

STEAM Indicator	Unex	Unexposed		Acceptable Exposed		
3M <sup>™</sup> Attest <sup>™</sup> BI 1491 and 1492V	1491	1492V	1491	1492V		
		After processing, indicator on cap turns light brown or darker.				
3M <sup>™</sup> Comply <sup>™</sup> Indicator Tape 1322		111		111,		
	After processing, indicator stripes turn dark-brown/black.					
3M <sup>™</sup> Comply <sup>™</sup> Indicator Tape 1355	1 xx	1444		11		

VH2O2 Indicator	Unexposed	Acceptable Exposed Color Range				
3M <sup>™</sup> Attest <sup>™</sup> BI 1295		0		€		
		After processing, indicator stripes turn toward pink.				
3M <sup>™</sup> Comply <sup>™</sup> Indicator Tape 1228	///	///	$\left  \right $	$\left  \right $		
		After processing, indicator stripes turn toward pink.				
3M <sup>™</sup> Comply <sup>™</sup> Chemical Indicator 1248						





Health Care Help Line 1-800-228-3957

STEAM VH2O2

#### Learn more about 3M<sup>™</sup> Sterilization Assurance products at go.3M.com/sterilization

For healthcare professional use only. Registered under Act 737. MDA Reg. No. : GMD86895875518A, GMD34608856218A and GA4487520-48634