

IMPORTANT!

To prevent possible engine hesitation upon acceleration, condition pump plunger leather for maximum efficiency as follows:

1. **Soften leather** by soaking in clean gasoline for a 10 minute period.
2. **Insure a snug fit** in pump well by carefully inserting a screw driver blade under leather cup, flaring leather outward as blade is revolved around plunger body.
3. **Make certain leather cup is not stretched excessively out of shape.**
4. **Always recheck for proper fit** prior to final installation. A light to medium drag should be felt when working plunger up and down in pump well.