



INSTALLATION INSTRUCTIONS FOR MARINE IGNITION SWITCH WITH PUSH-TO-CHOKE

1. Remove (+) Cable from the battery.
2. Refer to switch diagram below for terminal identification and circuit information. Connect wires of electrical system to the proper switch terminals. Trace wiring if necessary to determine proper terminal. Connect the cable from the engine magneto to one "M" terminal and the other "M" terminal to the electrical system ground.
3. Insure switch is in "OFF" position (key removed) and install switch in control box or mounting surface. To insure proper drainage of moisture from the lock chamber, mount switch with drain hole facing down. Make certain connections are properly made and that no shorts exist.
4. Reconnect (+) cable to the battery.
5. Insert key in switch and check installation.



A - Accessory
4 position switch only
B - Battery
C - Choke (Electric)
I - Ignition
M - Magneto
S - Start



Terminal End

NOTE: This switch is intended for manual operation only and is not intended for use in conjunction with emergency ignition shut-off devices which are attached to the control box or switch housing to mechanically rotate the switch key to the "OFF" position.

SHT999629