

Rubbermaid® Freshworks™

Rubbermaid® FreshWorks™ containers feature FreshVent™ Technology to keep produce fresher longer.

FreshWorks™ containers are BPA-free and dishwasher-safe. The FreshVent™ lid naturally regulates the flow of O₂ and CO₂ to create the optimal environment to keep produce fresher longer. The FreshVent™ filter lasts the lifetime so no refills are needed. The CrispTray™ elevates produce away from moisture and promotes proper airflow to prevent spoilage.

Use & Care

To keep your containers performing at their best, please read the following:

- Remove packaging and wash container before use.
- For optimal performance, store container with produce in fridge. Do not wash or cut produce prior to storing in FreshWorks™ container. Do not store mixed produce in the same container.
- Do not remove vent cover.
- Do not use in a conventional oven, convection oven, under browning elements or on a stovetop.
- Not intended for use in the freezer or microwave.
- This item is made of materials that are safe for normal household dishwashers. Be sure that the item is secured so that it does not come in contact with the dishwasher element to avoid melting.
- Do not use utensils with sharp edges (i.e. knives) in the container, as they could scratch or scuff the container surface.
- Do not directly block or cover the vent on the lid as this could disrupt proper airflow into the container. Containers may be stacked on top of each other and airflow will not be disrupted.

