PRESERVE & MARINATE CONTAINERS QUICK START GUIDE

FoodSaver[®]

HOW TO VACUUM SEAL



STEP 1

Turn valve so the arrow points to the Vacuum/ Store position.



STEP 2

Connect Handheld Sealer or Handheld Accessory by placing on top of the valve.



STEP 3

To vacuum and remove air, press vacuum or accessory button according to the appliance instructions. Once complete, store container in the freezer, fridge, or pantry.

To Open and Release Vacuum: Turn the valve to the Marinate/Open position and use easy open tabs to open and enjoy!

HOW TO MARINATE

Note: If your appliance does not have "Marinate Mode", marinate food by following steps in "how to vacuum seal" section above. Follow steps 1 - 3, wait 12 minutes for food to marinate, then release vacuum.



STEP 1

Turn valve so the arrow points to the Marinate /Open position.



STEP 2

Remove liquid reservoir and connect built-in Handheld Sealer.



STEP 3

Press 'Marinate' button on appliance to start marinating cycle to infuse flavor in 12 Minutes!

GUARANTEE

1-Year Limited Warranty

Sunbeam Products, Inc. warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. Sunbeam Products, Inc., as its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. This warranty is valid for the original retail purchase from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Sunbeam Products, Inc.'s dealers, service centers, or retail stores selling Sunbeam Products, Inc. products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This limited warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than Sunbeam Products, Inc. or an authorized Sunbeam Products, Inc. service center or use of this product with non-FoodSaver® branded bags and/or rolls. Further, this limited warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

What are the limits on Sunbeam Products, Inc.'s Liability?

Sunbeam Products, Inc. shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Sunbeam Products, Inc. disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise.

Sunbeam Products, Inc. shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party. Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service

In the U.S.A. If you have any question regarding this warranty or would like to obtain warranty service, please call 1.877.777.8042 and a convenient service center address will be provided to you.

In the USA, this warranty is offered by Sunbeam Products, Inc. 2381 NW Executive Center Dr. Boca Raton, FL 33431. If you have any other problem or claim in connection with this product, please write our Consumer Service Department.

PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.

For inquiries regarding recycling and proper disposal of this product, please contact your local waste management facility.

Important: For tips and types of foods that are compatible with vacuum preservation, reference the instruction booklet from your FoodSaver Vacuum Sealer or visit FoodSaver.com, 1-877-777-8042

> Wash Before Use Microwave safe – reheat only. Please remove lid prior to reheating.

Before each use, examine container and lid for damage. Discontinue use if damaged or cracked