

PACKAGING SPEC

THIS DRAWING IS A CONFIDENTIAL DISCLOSURE. THE SUBJECT MATTER OF WHICH IS THE PROPERTY OF IGNITE USA © 2014 ALL RIGHTS RESERVED CONFIDENTIAL & PROPRIETARY IMAGES FOR REFERENCE ONLY ***NOT TO SCALE***		ignite 180 N. LaSalle Street, Suite 700 Chicago, IL 60601		
MARKETING: SHARRATT		REV 000	DATE 05.09.16	PAGE 1
DESIGN: CHURCHILL		NOTE: All measurements in millimeters. Dimensions are for reference only.		

REVISION NOTES:

PRODUCT MANAGER: ☐

MARKETING COORDINATOR: ☐

INDUSTRIAL DESIGN: ☐

Inks:

L:

A:

B:

BLACK

PLACEMENT IMAGE

*must include dimensions and tolerances

contigo®

SNAPSEAL™

TRAVEL TUMBLER

Care and Use Instructions

⚠CAUTION

Careful. The beverage you are about to enjoy may be very hot. For best results always use caution.

Keep out of reach of children when filled with hot liquids.

To properly use your SNAPSEAL™ mug:

Snap up to drink with mug in upright position.

Snap down to seal.

Prior to drinking, make sure the lid is properly threaded to the body and screwed down completely.

If filling with boiling liquid, allow liquid to cool down WITH THE LID OFF for at least 3 minutes before attaching the lid.

When attaching lid, make sure the drink seal is in the open position.

DO NOT overfill. Fill liquids to just below the fill line in the body as shown.

DO NOT microwave or freeze.

DO NOT use cleaners containing bleach, chlorine, abrasives, and/or other harsh chemicals.

DO NOT continue to use product if damaged.

DO NOT carry bottles containing liquid in bags to help prevent accidental opening.

Fill line

USAGE RECOMMENDATIONS

Suitable for hot or cold beverages.

The SNAPSEAL™ lid that came with your new purchase is designed to fit only your new mug. Not for use with other products.

To attach the lid, apply slight downward pressure and rotate counter-clockwise until you hear a click and lid falls into place. Tighten completely.

PLEASE SEE REVERSE SIDE FOR CLEANING INSTRUCTIONS.

225mm

115mm

CLEANING INSTRUCTIONS

Wash thoroughly before first use.

Snap open the drink seal before rinsing or washing.

RINSE LID IMMEDIATELY AFTER EACH USE with warm water.

Lid is top-rack dishwasher safe. HAND-WASH ONLY any PAINTED stainless steel body.

10 min.

• ALWAYS STORE MUG WITH LID REMOVED to allow parts to dry completely.

ADDITIONAL CLEANING TIPS

For additional product cleaning tips, please visit www.GoContigo.com/cleaning.

LIFETIME GUARANTEE

For complete warranty information, see GoContigo.com

www.GoContigo.com

©2016 Ignite USA. All Rights Reserved.

Should you have any questions about your purchase, please contact us at 1-888-262-0622 or GoContigo.com.

034883-07

Material Specifications:

95 GSM uncoated

Additional Assembly Instructions:

Place one insert sheet in each mug.