


ASSEMBLY INSTRUCTIONS




aspenhome[®]

Distributed by Furniture Values International, LLC



ITEM NO: I24-318 74" Credenza Desk

HARDWARE PACK				COMPONENT LIST	
A		Bolt (Ø1/4*1-1/4")	4 PCS	Mounting Plate	1 Pc
B		Lock Washer	4 PCS		
C		Flat Washer	4 PCS		
D		Allen Wrench	1 PC		




MADE IN VIETNAM



aspenhome®


Distributed by Furniture Values International, LLC



ITEM NO:I24-318 74" Credenza Desk

You may use Typical Swivel Keyboard instead of the pencil drawer, please follow the procedure below.

1. Take the pencil drawer off. Remove 4 bolts from drawer frame to the desk top, and remove 4 bolts from drawer frame to the pedestals. Move the drawer frame down and take it off.



2. Attach Typical Swivel Keyboard to Mounting Plate by using 4 bolts, lock washers, flat washers and nuts. Use hex wrench to tighten all these bolts. (These hardware attached with Keyboard)
3. Attach the mounting Plate to the desk top by using 4 bolts, lock washers and flat washers. See detail 4.

