

MODEL 580A DUAL CHANNEL COMBUSTIBLE GAS CONTROLLER



580A- 1 - 1 - 0 0 - 0

CONTROLLER:

(Std) CONTROLLER

A. POWER:

- 1- (Std) 110 VAC/24 VDC
2- 220 VAC/24 VDC

B. RELAY-STATE:

- 1- (Std) LATCH ALARM/NON-LATCH WARN DE-ENERGIZED
2- LATCH ALARM/NON-LATCH WARN ENERGIZED
3- LATCH ALARM/LATCH WARN DE-ENERGIZED
4- LATCH ALARM/LATCH WARN ENERGIZED
5- NON-LATCH ALARM/NON-LATCH WARN DE-ENERGIZED
6- NON-LATCH ALARM/NON-LATCH WARN ENERGIZED
7- NON-LATCH ALARM/LATCH WARN DE-ENERGIZED
8- NON-LATCH ALARM/LATCH WARN ENERGIZED

C. COMBUSTIBLE-SENSOR: (price per active channel)*

- 00- (Std) NONE

D. ACTIVE CHANNELS*:

- 0- CONTROLLER ONLY

Note

* If requiring less than 2 sensors be sure to include sensor simulator (p/n 10102-1) for the remaining inactive channel.