## Removing the Twin Cartridge Adapter from the Advantage<sup>®</sup> 4000 Facepiece Using Tool P/N 10094780

## **Removing the Twin Cartridge Adapter**

1. Place the tool over the rotating locking ring.



Note: Ensure the corner of the locking button contacts the flat bottom of the diameter on the removal tool.



2. While holding the locking button down, rotate the removal tool clockwise to turn the locking ring.



3. Remove the tool and reposition counter-clockwise to engage the next pair of indentations to continue turning the locking ring.



Note: Approximately two short turns will rotate the locking ring 90 degrees, allowing disengagement of the twin cartridge adapter from the facepiece.

Note: The tool can be used to reinstall the twin cartridge adapter into the facepiece by turning the locking ring counterclockwise.

For More Information, call 1-800-MSA-2222 or Visit Our Website at www.MSAnet.com



MINE SAFETY APPLIANCES COMPANY CRANBERRY TWP., PENNSYLVANIA, U.S.A. 16066

MSA 113 (L) Rev. 1

© MSA 2011