Product Information News

December 6, 2006

REMOVING THE ICM[®] UNIT FROM THE QUICK-FILL[®] SYSTEM ADAPTER BLOCK

MSA recommends using two wrenches or a wrench and vise to remove the ICM Unit from the Quick-Fill System Adapter Block. Holding the case can damage the ICM Unit.

For convenience, place a copy of this PIN Article in the CARE Manual Binder.

Removing the ICM Unit from the Quick-Fill System Adapter Block

- 1. Place the Quick-Fill System Adapter Block
- in a vise using protective sleeves to prevent damage to the block (preferred) or use a 3/4" wrench to hold the Quick-Fill System Adapter Block.



2. Slide a wrench over the iam nut and loosen by turning the wrench counter-clockwise.



- 3. Unthread the ICM Unit from the Quick-Fill System Adapter Block.
- 4. Remove and discard the jam nut.

DO NOT reuse the jam nut. Dispose of it immediately. Failure to follow this warning can result in serious personal injury or death.



TAL 6012 (L) Rev. 0

For More Information, call 1-800-MSA-2222 or Visit Our Website at www.MSAnet.com

MINE SAFETY APPLIANCES COMPANY PITTSBURGH, PENNSYLVANIA, U.S.A. 15230

© MSA 2006

Print Spec. 10000005196 (A) Mat. 10073996 Doc. 10073996