


GASGARD[®] XL

MULTI-CHANNEL WALL MOUNT CONTROLLER

Please review the manual for complete product information.



CHANNEL STATUS INFO LEDs DETAIL

CHANNEL STATUS INFO LEDs


GRAPHIC DISPLAY



ALARM RESET

CONTROL PUSH BUTTONS

ALARM ACKNOWLEDGEMENT



COMMON LEDs DETAIL


UP BUTTON:
CHANGE VALUES OR
SCROLL THROUGH
MENU OPTIONS

LEFT
BUTTON:
ESCAPE
OR BACK


RIGHT
BUTTON:
ENTER
OR MODIFY
MENU OPTIONS

DOWN/
PAGE DOWN
BUTTON:
CURSOR


CONTROL PUSH
BUTTONS DETAIL




ETHERNET PORT DETAIL




USB PORT DETAIL




EXTENSION SENSOR CONNECTIONS




ALARMS/HORNS/
FAULTS RELAY




CHANNEL RELAY BOARD



SENSOR CONNECTIONS




MAIN AND BATTERY CONNECTIONS




Battery is shipped disconnected. Connect during installation of the GasGard XL. In order to function properly, the battery back-up mode must be turned on internally in the unit.



10.91" (277mm)



CABLE ENTRIES
0.75" (20mm)



LEFT BUTTON: 	UP BUTTON: 	RIGHT BUTTON: 	DOWN/ PAGE DOWN BUTTON:
ESCAPE OR BACK	CHANGE VALUES OR SCROLL THROUGH MENU OPTIONS	ENTER OR MODIFY MENU OPTIONS	CURSOR OR SCROLL THROUGH MENU OPTIONS

