

MODEL TL105 TL105 TEST LAMP

TL105

A	B

MODEL TL105 TEST LAMP

(Std) TEST LAMP

A LAMP-SETTINGS

- 0- (Std) = FL4000H, FL500, FL4000 SENSITIVITY
- 1- = FL3100H, FL3100, FL3110, FL3000 SENSITIVITY
- 2- = FL3101H, FL3101, FL3111, FL3001 SENSITIVITY
- 3- = FL3102, FL3112, FL3002 SENSITIVITY
- 4- = TYPE V, VI SENSITIVITY

B BATTERY-CHARGER

- 1- = NO CHARGER
- 2- (Std) = 71676-1 CHARGER ASSEMBLY - TL105

