

TransAire™ 5 & 10

Part no.
5 min. 10008292
10 min. 10008293
10 min. 10083327
5 min less air 10066739
10 min less air 10066740

**5 & 10 minute escape
apparatus
(aparato para escaparse
de 5 y 10 minutos)**

**Parts List
(Lista de Partes)**

For More Information, call 1-800-MSA-2222 or Visit Our Website at www.MSAnet.com




**MINE SAFETY APPLIANCES COMPANY
PITTSBURGH, PENNSYLVANIA, U.S.A. 15230**

TransAire™

484351 Hood and Inlet Assembly/Montaje de Entrada y Capucha


(Does Not Include Hose/No Incluye la Manga)

(Not Saleable/No Tenemos en Existencia — Order Hood and Inlet Assembly Separately/
Mande Separadamente la Capucha Y el Montaje de Entrada)




TransAire™ 5

10008298 Cylinder and Valve Assembly/Montaje de Cilindro y Válvula 5 Minute Unit/Unidad de 5 Minutos




TransAire™ 10

10008299 Cylinder and Valve Assembly/Montaje de Cilindro y Válvula 10 Minute Unit/Unidad de 10 Minutos



TransAire™ 10

10083327 Cylinder and Valve Assembly/Montaje de Cilindro y Válvula 10 Minute Unit/Unidad de 10 Minutos



For More Information, call 1-800-MSA-2222 or Visit Our Website at www.MSAnet.com



MINE SAFETY APPLIANCES COMPANY
PITTSBURGH, PENNSYLVANIA, U.S.A. 15230