





AUTOSEAL® Stainless Steel Water Bottle



AWARNING

Hot contents can create internal pressure resulting in discharge of hot liquids that can cause injury. DO NOT use this product with hot liquids.

ACAUTION

- Not for use with carbonated or pulpy beverages.
- · Prior to drinking, make sure the lid is properly threaded to the body and screwed on completely.
- Avoid accidental depressing of the AUTOSEAL* button by keeping the button free and clear of other objects.
- DO NOT overfill. Fill liquids to just below the threading in the body.
- DO NOT microwave or freeze.
- DO NOT use cleaners containing bleach, chlorine, abrasives and/or other harsh chemicals.
- DO NOT continue to use product if damaged.
- DO NOT carry bottles containing liquid in bags to help prevent accidental opening.

USAGE RECOMMENDATIONS:

PRESS BUTTON

to sip

TIP to drink RELEASE BUTTON

to Automatically Seal









- · Wash thoroughly before first use.
- RINSE IMMEDIATELY AFTER EACH USE with warm water, pressing the AUTOSEAL* button so water flows through Drink Spout and Vent Hole.
- · Lid is top-rack dishwasher safe.
- Hand-wash stainless steel body.



- If washing by hand, soak lid for 10 minutes in hot, soapy water. Hand wash body with warm water and a mild detergent. Rinse both lid and body thoroughly before use.
- For best cleaning results, use a Contigo bottle + spout brush, www.GoContigo.com.



OR





• ALWAYS STORE BOTTLE WITH LID REMOVED to allow parts to dry completely.



©2016 Ignite USA, LLC. All Rights Reserved.

Should you have any questions about your purchase, please contact us at 1-888-262-0622 or GoContigo.com
*Warranty only applicable in US & Canada. See GoContigo.com for details.