


# contigo®



## Glacier Stainless Steel Water Bottle Care and Use Instructions



### ⚠ WARNING

Hot contents can create internal pressure resulting in discharge of hot liquids that can cause injury. **DO NOT** use this product with hot liquids.

### ⚠ CAUTION

- Not for use with carbonated or pulpy beverages.
- Prior to drinking, make sure the lid is properly threaded to the body and screwed on completely.
- Avoid accidental depressing of the button by keeping the button free and clear of other objects.
- DO NOT overfill. Fill liquids to just below the threading in the body.
- DO NOT microwave or freeze.
- DO NOT use cleaners containing bleach, chlorine, abrasives and/or other harsh chemicals.
- DO NOT continue to use product if damaged.
- DO NOT carry bottles containing liquid in bags to help prevent accidental opening.

### USAGE RECOMMENDATIONS:

TO OPEN



TO CLOSE



TO LOCK




### CLEANING INSTRUCTIONS


- Wash thoroughly before first use.
- RINSE IMMEDIATELY AFTER EACH USE with warm water.
- Lid is top-rack dishwasher safe.
- Hand-wash stainless steel body.



- If washing by hand, soak lid for 10 minutes in hot, soapy water. Hand wash body with warm water and a mild detergent. Rinse both lid and body thoroughly before use.
- For best cleaning results, use a Contigo® bottle + spout brush, [www.GoContigo.com](http://www.GoContigo.com).



OR



- ALWAYS STORE BOTTLE WITH LID REMOVED to allow parts to dry completely.



©2014 Ignite USA. All Rights Reserved.

Should you have any questions about your purchase, please contact us at 1-888-262-0622 or [GoContigo.com](http://GoContigo.com)

\*Warranty only applicable in US & Canada. See [GoContigo.com](http://GoContigo.com) for details.

035920-11