

contigo®

Purity Water Bottle Care and Use Instructions

⚠ CAUTION


- Product is NOT designed for hot liquids. Use only with cold liquids.
- Prior to drinking, make sure the lid is properly threaded to the body and screwed on completely.
- DO NOT microwave or freeze.
- DO NOT use cleaners containing bleach, chlorine, abrasives and/or other harsh chemicals.
- DO NOT continue to use product if damaged.
- DO NOT carry bottles containing liquid in bags to help prevent accidental opening.

USAGE RECOMMENDATIONS:





CLEANING INSTRUCTIONS

- Wash thoroughly before first use.
- It is NOT necessary to remove the silicone sleeve from the bottle for washing.
- RINSE IMMEDIATELY AFTER EACH USE.
- Attached lid and glass body with silicone sleeve are top-rack dishwasher safe.



- If washing by hand, wash glass body and attached lid with warm water and a mild detergent. Rinse both lid and body thoroughly before use.
- For best cleaning results, use a Contigo® bottle brush, www.GoContigo.com.
- ALWAYS STORE BOTTLE WITH LID REMOVED to allow parts to dry completely.



for complete warranty information, see GoContigo.com.

www.GoContigo.com

©2016 Ignite USA, LLC. All Rights Reserved.

Should you have any questions about your purchase,
please contact us at 1-888-262-0622 or GoContigo.com.