

contigo®




AUTOSPOUT® Squeeze Kids' Bottle

⚠ CAUTION

- Not for use with hot, carbonated, pulpy or perishable beverages.
- Not intended for children under 3 years of age.
- DO NOT microwave or freeze.
- DO NOT use cleaners containing bleach, chlorine, abrasives and/or other harsh chemicals.
- DO NOT continue to use if damaged
- DO NOT carry bottles containing liquid in bags to help prevent accidental opening.

USAGE RECOMMENDATIONS



TO OPEN




TO CLOSE



SQUEEZE TO DRINK




RELEASE TO SEAL



CLEANING INSTRUCTIONS


- Wash thoroughly before first use.
- **RINSE LID IMMEDIATELY AFTER EACH USE** with warm water, with spout in open position.
- Lids and body are top-rack dishwasher safe.
- If washing by hand, soak lid for 10 minutes in hot, soapy tap water. Hand wash body with warm water and a mild detergent. Rinse both lid and body thoroughly before use.
- For best results, use a Contigo® bottle brush, www.GoContigo.com.



OR



10 min.



ALWAYS STORE BOTTLE WITH LID REMOVED and spout in open position to allow parts to dry completely.

ADDITIONAL CLEANING TIPS

For additional product cleaning tips visit www.GoContigo.com

contigo®

LIFETIME
GUARANTEE

For complete warranty information, see GoContigo.com.

©2014 Ignite USA. All Rights Reserved.

Should you have any questions about your purchase, please contact us at 1-888-262-0622 or GoContigo.com.

033956-07