

# contigo®

AUTOSEAL®  
TECHNOLOGY

## AUTOSEAL® Kids' Bottle Care and Use Instructions

### ⚠ WARNING

CHOKING HAZARD - small parts.  
Not for children under 3 yrs.

### ⚠ CAUTION


- Not for use with hot, carbonated, pulpy or perishable beverages.
- Not intended for children under 3 years of age.
- DO NOT microwave or freeze.
- DO NOT use cleaners containing bleach, chlorine, abrasives, and/or other harsh chemicals.
- DO NOT continue to use product if damaged.
- DO NOT carry bottles containing liquid in bags to help prevent accidental opening.

## USAGE RECOMMENDATIONS

**PRESS BUTTON**  
to drink



**TIP**  
to drink



**RELEASE BUTTON**  
to Automatically Seal



- Use the bottle's lock feature to avoid unintended depressing of the AUTOSEAL® button.



## CLEANING INSTRUCTIONS

- Wash thoroughly before first use.
- Flip open the lid interior before rinsing or washing.


To Open




To Close



- RINSE LID IMMEDIATELY AFTER EACH USE with warm water, pressing the AUTOSEAL® button so water flows through the Drink Spout and Vent Hole.
- Lid and plastic body are top-rack dishwasher safe.
- If washing by hand, soak the lid for 10 minutes in hot, soapy tap water. Hand-wash body with warm water and a mild detergent. Rinse both the lid and body thoroughly before use.
- For best results, use a Contigo® bottle brush, [www.GoContigo.com](http://www.GoContigo.com).



OR



- ALWAYS STORE BOTTLE WITH LID REMOVED to allow parts to dry completely.

## ADDITIONAL CLEANING TIPS

For additional product cleaning tips visit [GoContigo.com](http://GoContigo.com).



For complete warranty information, see [GoContigo.com](http://GoContigo.com).

[www.GoContigo.com](http://www.GoContigo.com)

©2014 Ignite USA. All Rights Reserved.

Should you have any questions about your purchase,  
please contact us at 1-888-262-0622 or [GoContigo.com](http://GoContigo.com).

035141-09