




Pro-Line ProGrid® Ergonomic High-Back Mesh Office Chair with Arms

FEATURES & OPERATING INSTRUCTIONS



• PNEUMATIC SEAT HEIGHT ADJUSTMENT

To raise seat remove pressure from seat and pull lever (3) up. To lower seat height sit on chair and pull lever (3) up.

• SEAT ANGLE ADJUSTMENT

To adjust seat angle, lift lever (5). Leave lever up for free float or push lever (5) down to lock.

• BACKREST ANGLE ADJUSTMENT

To adjust back angle lift lever (6). Leave lever (6) up for free float or push lever (6) down to lock at any angle.

• SEAT SLIDER ADJUSTMENT

To slide seat forward or backward, pull handle bar (4) out. Release handle bar (4) to lock desired seat position.


• TILT TENSION ADJUSTMENT

To adjust tilt tension, Turn knob (1) clockwise to increase tension and counter-clockwise to decrease or ease the tension.

NOTE: Be careful not to completely loosen knob (1).




• SEAT/BACK ANGLE ADJUSTMENT & FORWARD TILT

To adjust Seat/Back angle, lift lever (5) leave lever up for free float or push lever down to lock. For forward tilt lean back with lever (5) in the down position and push lever (2) forward. Lift lever (5) and the seat will tilt forward for keyboard intensive activities.



RATCHET BACK HEIGHT ADJUSTMENT

To adjust the height of the backrest lift upward. Once backrest reaches its highest position it returns to the bottom to be moved upward again.



ARM HEIGHT ADJUSTMENT

To adjust arm height, push button in to allow the arms to move up or down freely. Release button once the desired height is reached.

ARM WIDTH ADJUSTMENT

To adjust width, loosen knob, move arm to desired position then fully tighten knob.

WARNING

- 1) Use this product only one person at a time.
- 2) Do not use this product unless all bolts, screws and knobs are securely tightened.
- 3) Check that all bolts, screws and knobs are tight every three months or as needed.
- 4) Do not overturn back tilt knob when decreasing tension.
- 5) Dispose of packing material properly. Do not use plastic cover as head covering as it may cause suffocation.
- 6) Do not use this product as a stepladder.
- 7) Use this product for its intended purpose only.
- 8) Use mild detergent only for cleaning.

CUSTOMER SERVICE HOTLINE: 800-558-1010







WWW.NBF.COM

ASSEMBLY INSTRUCTIONS

Remove all the parts from carton, separate them into part numbers indicated on the list and make sure part quantities are correct.

- STEP 1** Insert five Casters (2) into Base (1), push hard until you hear or feel Caster (2) snap into place. Insert Cylinder (3) into Base (1) and slip Bellows (4) over Cylinder (3).
- STEP 2** Attach Mechanism (5) to Seat (6) using six Screws (11).
- STEP 3A** Attach Arms (9L & 9R) to Seat (6) using one Knob w/ washers (12) for each Arm (9). **NOTE:** Activate seat slider adjustment to expose hole in rear of Mechanism (5).
- STEP 3B** Insert Post (8) into Back Assembly (7) with nut facing inward, and secure using four Screws (10).
- STEP 3C** Insert Post (8) into rear of Mechanism (6) and secure using Screw w/ washers (13). Secure Back Support Cover (16) over Back Support (15) using two Back Cover Screws (17).
- STEP 4A** Attach Plastic cover (16) to Backrest (7) using two Screws (15).
- STEP 4B** Place assembled seat on top of Cylinder (3) and apply pressure.

ATTENTION: MAKE SURE ALL SCREWS AND KNOBS ARE FULLY TIGHTENED BEFORE USING CHAIR.

PARTS		STEP 1	STEP 2
 (1) Base QTY 1  (2) Caster QTY 5	 (3) Cylinder QTY 1  (4) Bellows QTY 1	 (5) Mechanism QTY 1  (6) Backrest QTY 1	 (7) Seat QTY 2  (8L & 8R) Arms QTY 2
 (9) Knob QTY 6  (10) Flat Washer QTY 2	 (11) Lock Washer QTY 1  (12) Screw QTY 6	 (13) Screw QTY 1  (14) Screw QTY 4	 (15) Back Support QTY 1  (16) Plastic cover QTY 1
 (17) Screws QTY 2  (18) Allen Wrench QTY 1			
			
			
Phillips screwdriver also needed for assembly (not provided)			

CUSTOMER SERVICE HOTLINE: 800-558-1010

WWW.NBF.COM