



Congratulations on the purchase of your new *Signature Series* product!

COMPONENTS


(A) TOP-1pc




(B) Left side panel-1pc




(C) Right side panel-1pc



(D) Modesty panel-1pc



(E) Modesty panel-1pc



HARDWARE & TOOLS

(F) Wood dowel - 4pcs



(G) Cam bolt - 12pcs



(H) Cam lock - 12pcs



(I) Adhesive cover- 12pcs



Tools Required for Assembly




Philips Screw Driver


(J) Allen Key- 1pc




(K) Screw M6*12 - 4pcs



(L) Caster With Lock- 4pcs



(M) Screw M4*22- 4pcs



(N) Power unit -1pc









(O) Nut-4pcs



INSTRUCTIONS


STEP 1




Congratulations on the purchase of your new *Signature Series* product!

INSTRUCTIONS


STEP 2




STEP 3



STEP 4



STEP 5



STEP 6

