





SETUP INSTRUCTIONS IMTR647 CREDENZA

No	Parts List	Qty
A	 IMTR647 Credenza	1
B	 Leg (Short)	4

No	HardwareList	Qty
1	Bolt M8 x 68 mm w/ Washer	8
2	Allen Key 5 mm	1
3	Anti-Tip Restraint Hardware	1

Note:


- Locate the Hardware Pack.
- Once all items are removed from the carton, inspect carton for any parts that may have come loose during shipment.
- Please read through the instructions before you attempt to assemble.
- It is recommended to use two people during the assembly process.
- Tool required: Phillips Screwdriver (not provided)

1

Turn the Credenza (A) upside down on a smooth and clean surface, take special care so that the drawers do not fall and become damaged.

Adjust the levelers as required.

1




2

Using the Bolts (1) and Allen Key (2), screw all the Legs (B) to the bottom of the Credenza (A)

Turn the Credenza (A) upright and adjust the levelers as required.

Please secure the cabinet to the wall using the Anti-Tip Restraint hardware (3)


2



3

3

The Handles are installed inside the drawers for packing. Unscrew the Handles and re-screw them outside the drawers and doors



CARING FOR YOUR FURNITURE

- Use a soft, clean cloth that will not scratch the surface when dusting.
- Use of furniture polishes are not necessary. Should you choose to use polishes, test in an inconspicuous area first.
- Using solvents of any kind on your furniture may damage your furniture finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Always use coasters under beverage glasses and flowerpots.
- Liquid spills should be removed immediately. Use a soft, clean cloth, blot the spill gently. Avoid rubbing.
- Direct sunlight may damage wood finishes.
- Extreme temperature and humidity changes can cause warping, shrinking and splitting of wood furniture. It is best to keep furniture in a climate controlled room.
- Always use protective pads under hot dishes and plates. Heat can cause chemical changes that may create spotting within the furniture finish.
- In the event that your furniture is stained or otherwise damaged during use, we recommend that you call a professional to repair your furniture.