



IMTR387RT PARTS LIST

No	Parts List	Qty	Part No.
A	IMTR387RT Removal Top 1	1	IMTR387RT-RT1
B	IMTR387RT Removal Top 2	1	IMTR387RT-RT2
C	Lift Base (Separate Box)	1	-
D	Power Center	1	IM-PC
E	Grommet	2	IM-GM
F	Drawer Handle	4	IMTR-DH
G	16" Drawer Slide (inside)	2	IM-16DS
H	14" Drawer Slide (inside)	2	IM-14DS
I	Level Adjuster (Separate Box)	6	-
J	Lift Controller (Separate Box)	1	-
K	Hardware Pack	1	IMTR387T-HP

No	Hardware Pack	Qty	Part No.
1	M6 x 30 mm Bolt	6	IM-M6-30
2	Instruction Sheet	1	IMTR387RT-AI

