



COMPONENTS




HARDWARE & TOOLS




INSTRUCTIONS - We don't recommend using power tools when installing Cam Posts.

STEP 1




INSTRUCTIONS - We don't recommend using power tools when installing Cam Posts.

STEP 2




STEP 3




INSTRUCTIONS - We don't recommend using power tools when installing Cam Posts.

STEP 4




STEP 5




INSTRUCTIONS - We don't recommend using power tools when installing Cam Posts.

COMPLETED




COMPONENTS

Ⓔ Starter Base-2pcs



INSTRUCTIONS



ICT72T
ICT96T

OR

ICT60HT
ICT72HT
ICT84HT
ICT96HT

