





COMPONENTS


(A) Top Panel-1pc




(B) Back Panel-1pc




(C) Right Side Panel-1pc




(D) Left Side Panel-1pc




(E) Bottom Panel-1pc




(F) Adjustable Shelf-1pc



(G) Toe Kick-1pc



(H) Door Panel-2pcs



HARDWARE & TOOLS

(J) Cam Post-24pcs



(K) Wood Dowel
Ø8*30mm-8pcs



(L) Cam Lock-24pcs



(M) Cam Sticker-28pcs



Tools Required for Assembly



(N) Shelf Support -5pcs



(O) Allen Leveler-4pcs



(P) Allen Wrench
4mm-1pc



(Q) Screw Ø4X
16mm-17pcs



Philips Screw Driver for

(J) Cam Post (L) Cam Lock

(Q) Screw Ø4X16mm

(S) Screw Ø3.5 x 16mm White

(R) Door Stop -1pc




(S) Screw Ø3.5 x 16mm
Silver - 3pcs




INSTRUCTIONS -We don't recommend using power tools when installing Cam Posts.

STEP 1




STEP 2






INSTRUCTIONS - We don't recommend using power tools when installing Cam Posts.


STEP 3




STEP 4



STEP 5




STEP 6







INSTRUCTIONS - We don't recommend using power tools when installing Cam Posts.


STEP 7




STEP 8



ADJUSTMENT HEIGHT



ADJUSTMENT DEPTH



ADJUSTMENT GAP

COMPLETED

