












**IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED
ON THE BOTTOM OF SEAT CUSHION.**

MODEL : B9331 B9336

(1)x1	(2)x1	(3)x1 (L)x1 (R)
		
Back Cushion	Seat Cushion	Left & Right-Arm
(4)x1	(5)x1	(6)x1
		
Gas Lift W/ Cover	Base	Mechanism
(7)x5		
		
Caster		
(A)x8		M6*25 ARM SCREW
(B)x4		M8*22 MECHANISM SCREW
(C)x8		ARM CAPS



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

