

















**IMPORTANT NOTICE:**  
**HARDWARE PACKAGE IS ATTACHED**  
**ON THE BOTTOM OF SEAT CUSHION.**  
MODEL : B248

 <p>knee cushion</p>										
 <p>seat cushion</p>	 <p>caster</p>									
<table><tr><td>(A)*4</td><td></td><td>M6*18 Seat Cushion Screws (found in seat)</td></tr><tr><td>(B)*1</td><td></td><td>M6*16 Frame Screws</td></tr><tr><td>(C)*1</td><td></td><td>Long Frame screw ( B &amp; C found in frame Remove before Step 3 )</td></tr></table>		(A)*4		M6*18 Seat Cushion Screws (found in seat)	(B)*1		M6*16 Frame Screws	(C)*1		Long Frame screw ( B & C found in frame Remove before Step 3 )
(A)*4		M6*18 Seat Cushion Screws (found in seat)								
(B)*1		M6*16 Frame Screws								
(C)*1		Long Frame screw ( B & C found in frame Remove before Step 3 )								

<p>Step 1</p>  <p>Flip Over</p>	<p>Step 2</p> 
<p>Step 3</p> 	<p>Step 4</p> 

Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using.  
This chair is only intended for sitting. Any other use will void the warranty.

