













**Please unscrew mechanism and L-bar hardware from cushion before assembly.**

**Por favor de destornillar todos los tornillos del cojín antes de ensamblar la silla.**

**MODEL : B8771/B8776**

(1)x1	(2)x1	(3)x1 (L)x1 (R)
		
Back Cushion	Seat Cushion	Left & Right-Arm
(4)x1	(5)x1	(6)x1
		
Gas Lift W/ Cover	Base	Mechanism
(7)x5		
		
Caster		
(A)x4		M8*22 MECHANISM SCREW
(B)x4		M8*50 ARM SCREW
(C)x4		M8*25 L-BAR SCREW
(D)x4		ARM CAPS



**Note: Please tighten all arm screws using allen key before step 6**

Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

