

How to adjust the back pivot on your Nex Nesting Chair:

Armless Nesting Chair



Remove cap.




Locate nut.



Use Size 10 socket wrench to adjust pivot: tighten to have less recline; loosen to have more recline.

Nesting Chair with Arms



Locate nut.



Use Size 10 socket wrench to adjust pivot: tighten to have less recline; loosen to have more recline.