

Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required. The product of Hillsdale Furniture, LLC is designed for residential use only. Customer Service Phone Number: 502-562-0000


HARDWARE LIST

- A (4) Allen Bolts
- B (4) Spring Washers
- C (4) Metal Washers
- D (1) Allen Wrench

PARTS LIST

- E (1) Top Section
- F (1) Bottom Section

TOOLS REQUIRED FOR ASSEMBLY: ALLEN
WRENCH (INCLUDED)



***** ASSEMBLY *****

Attach Top Section (E) to Bottom Section (F), using 4 Allen Bolts (A), 4 Spring Washers (B) & 4 Metal Washers (C) to hold tight in place. Please tighten all bolts using Allen Wrench (D) provided to prevent stripping of wood.

The illustration shown above, is a generic drawing of assembly of the original item you purchased.