












**Congratulations on the purchase of your new *Signature Series* product!**

(A) Top -1pc      (B) Left side panel -1pc      (C) Right side panel - 1pc      (D) Bottom -1pc      (E) Back panel - 1pc



(J) Cam bolt - 18pcs      (K) Cam Lock - 18pcs      (L) Wood dowel - 24pcs      (M) Screw M4\*16 - 16pcs



22

**Philips Screw Driver**


(M) Screw M4\*16

Q Screw M4\*16


**Congratulations on the purchase of your new *Signature Series* product!**

## INSTRUCTIONS


### STEP 1




### STEP 2




### STEP 3



### STEP 4




### STEP 5




**Congratulations on the purchase of your new *Signature Series* product!**

## INSTRUCTIONS


### STEP 6



### STEP 7



### STEP 8



### STEP 9

