




# Models 66122, 66152, 66182 Mesa Series Flip/Nesting Table

## Parts Listing



## Assembly Instructions



**Tools Needed: Allen Wrench (Not Included)**  
**Please read all instructions before assembly.**

**Step 1:** Place Table Top (A) upside down on a clean, flat surface. Press the flip lever *down*, while lifting the leg mount bracket, locking it into the vertical position.




**Step 2:** Attach Legs (B) to the leg mount bracket on Table Top (A). Align the holes on each Leg (B) to the leg mount bracket (as shown) and insert two Allen Bolts (C). Hand tighten bolts until both Legs (B) are attached. Use Allen Wrench to tighten all four Allen Bolts.

**Note:** Each Leg (B) should attach to the leg mount bracket with the rounded bent tubing to the *outside* of the table and the square tubing to the *inside* of the table. The square tubing will attach directly to the leg mount bracket.

**Step 3:** Flip the table right side up using at least two people.

## To nest tables together:

Pull the flip lever up, flip the table top up, and roll the tables in line.



**WEIGHT CAPACITY: 125 lbs.**

### Assembly Notes:

During assembly, hand tighten bolts only. When all bolts are in place, you may then tighten all bolts completely.

### CAUTION:

1. Do not use this table as a step ladder.
2. Check for loose screws and tighten them every 6 months.

**ofm**  
Furniture For The Real Office™

161 Tradition Trail, Holly Springs, NC, 27540  
800-520-7471 (voice) 919-362-4765 (fax)  
919-303-6389 (voice) www.ofminc.com  
support@ofminc.com