



800-558-1010 | www.NBF.com

Assembly Instructions For Symphony Glass Tables

Tools required: Allen wrench. (Included in hardware pack)

Note: These instructions are intended for various models and configurations. Your products may not look exactly as those shown in the diagrams.

Important: The assembly process requires that some hardware be kept loose until later in the sequence. Follow these instructions closely to ensure correct assembly.

Recommendation: Retighten all bolts on a seasonal basis to ensure your product remains strong and stable for many years of use.

Parts List

Tabletop Leg Frame, Upper Leg Frame, Lower


Hardware Pack

3/4" Allen Bolts, 4 pcs. Allen Wrench



- Place glass tabletop with the silver disks facing up on a clean, carpeted or otherwise protected surface to avoid scratching.
- Attach Upper Leg Frame to tabletop using 3/4" Allen bolts, as shown in figure 1. Upper Leg Frame has slot in cross tube that faces up. Keep bolts slightly loose for now.
- 4. Align slot in Lower Leg Frame with slot in Upper Leg Frame and attach to tabletop using 3/4" Allen bolts, as shown in figure 2. Tighten all 4 bolts securely.
- 5. Carefully return table to the upright position.
- Your table is now assembled and ready to use.

Note: The floor glides are threaded and can be adjusted in length to accomodate floors that are not quite level.



Thank you for purchasing this NBF product.

Need assistance with assembly? Call our customer service at 800.558.1010 or visit us online at www.nbf.com