


COMPONENTS

- (A) Top Panel-2pcs (B) Modesty Panel-4pcs (C) Left Base Leg-1pc (D) Right Base Leg-1pc (K) Middle Base Leg-1pc



HARDWARE & TOOLS

- (E) Cam Post-41pcs (F) Wood Dowel Ø8*30mm-17pcs (G) Cam Lock-41pcs (H) Cam Sticker-41pcs
(I) Mntg Plate 260*100*3mm-2pcs (J) Phillips Screw M6X15mm-17pcs

Tools Required for Assembly




NOTE:
Hardware is packed
with carton **DCT144T**.


Philips Screw Driver for
(E) Cam Post (G) Cam Lock
(J) Screw M6X15mm

INSTRUCTIONS - Do not use power tools to assemble


STEP 1




STEP 2



STEP 3




STEP 4




INSTRUCTIONS

STEP 5



STEP 6



COMPLETED

