Conference Table Base ASSEMBLY INSTRUCTIONS

COMPONENTS (\widehat{C}) Left Base Leg-1pc (D) Right Base Leg-1pc NOTE: Hardware is packed with carton DCT96/DCT120T/DCT144T. INSTRUCTIONS - Do not use power tools to assemble DCT96 OR **DCT120T** OR DCT144T