


COMPONENTS

- Ⓐ Top Panel-1pc Ⓑ Back Panel-1pc Ⓒ Left Side Panel-1pc Ⓓ Right Side Panel-1pc Ⓔ Bottom Panel-1pc Ⓕ Shelf Panel-1pc



HARDWARE & TOOLS

- Ⓖ Cam Post-19pcs Ⓗ Wood Dowel Ø8*30mm-13pcs Ⓘ Cam Lock-19pcs ⓵ Cam Sticker-19pcs



- Ⓚ Shelf Support -5pcs Ⓛ M8 Leveler-4pcs




Tools Required for Assembly




Philips Screw Driver for
Ⓖ Cam Post Ⓘ Cam Lock

INSTRUCTIONS - Do not use power tools to assemble


STEP 1




STEP 2



STEP 3




STEP 4




INSTRUCTIONS


STEP 5





STEP 6




STEP 7




OR



ADJUSTMENT HEIGHT



ADJUSTMENT DEPTH



ADJUSTMENT GAP