

## 2-DRAWER WRITING DESK

H08799 ESPRESSO FINISHING

H08800 WHITE FINISHING


H08801 BLACK FINISHING

Assembly Instructions



For assistance with assembly contact:  
Southern Enterprises Inc.  
Customer Service 1-800-633-5096  
[service@seidal.com](mailto:service@seidal.com)  
[www.seidal.com](http://www.seidal.com)

PO :12388



# 2-DRAWER WRITING DESK

## Parts List


Please review all parts and hardware before disposing of any packaging.

Call Customer Service if missing hardware. Do not return to store/retailer.

Using hardware that is too long will cause damage.

Before beginning assembly, separate each type of hardware. Carefully study the hardware diagrams below. You may receive extra hardware with your unit.


1



Top Frame


Quantity  
Of 1

2



Quantity  
Of 4

A




Quantity  
Of 8

B




Quantity  
Of 8

C



Quantity  
Of 8

D



Quantity  
Of 1


### Care and Cleaning Instructions:

Before using, wipe with a clean, dry cloth. Periodically apply furniture wax to renew the finish. Avoid rubbing or scratching the surface with rough or abrasive objects.

For replacement parts or questions, please call Customer Service at 1-800-633-5096. Do not return product to store. Please call manufacturer for assistance, questions or parts.

# 2-DRAWER WRITING DESK

## Assembly Instruction



### Assembly Instructions:

Wood may scratch easily. Be careful when assembling. Do not scratch.

**Step 1.** Unpack and lay parts on clean, padded surface like carpet or blanket. Check that you have all parts indicated on the front page.

**Step 2.** Put Top Frame (1) upside down on a soft working surface.

**Step 3.** Put the Flat Washers(A) and Spring Washers (B) into Allen Bolts(C), attach the Legs(2) Into corner block with Allen Bolts (C) by Allen Key (D).


**Step 4.** Fasten the Allen Bolt (B).

(A)  Quantity Of 8

(B)  Quantity Of 8

(C)  Quantity Of 8

(D)  Quantity Of 1



**Step 1.** Turn the assembly right side up

**Max loading weight:40LB**

## Parts Replacement Form

### Customer Information

Name \_\_\_\_\_

Address \_\_\_\_\_

City/State/Zip Code \_\_\_\_\_

Phone Number \_\_\_\_\_

Please indicate where you purchased this item: Store/Website/Catalog

\_\_\_\_\_

Please indicate color/size/style number:

\_\_\_\_\_

Style No	Parts Letter	Parts Description	Quantity Needed
----------	--------------	-------------------	-----------------

_____	_____	_____	_____
-------	-------	-------	-------

_____	_____	_____	_____
-------	-------	-------	-------

_____	_____	_____	_____
-------	-------	-------	-------

Please immediately examine this product carefully. Any request for missing parts or damage replacement must be received within 90 days of your receipt of the product. Replacement, if available, will be honored within this time frame. Parts will not be available for items arriving fully assembled. We do not recommend modifying product(s) and we are not responsible for any damages due to product modification(s). If damages or missing parts are not reported within 90 days of your receipt, we are under no obligation to provide parts or replacement merchandise. Please contact Southern Enterprises at 800-633-5096 or in Dallas 972-869-0111/ 9am – 4pm Mon-Fri Central time if you have product issues or email us at [service@seidal.com](mailto:service@seidal.com). Please ask for customer service representative for issues involving damages or replacement parts. Please ask for technical assistance representative for any issues with product and assembly/construction.

Please contact the retailer that you purchased from for returns.



Customer Service 1-800-633-5096

[service@seidal.com](mailto:service@seidal.com)

Southern Enterprises, Inc.

600 Freeport Parkway, Suite 200

Coppell, Texas 75019