



# INVISACOOK® INDUCTION UNIT **DESIGN & INSTALLATION GUIDE**


# PANORAMIC PORCELAIN SURFACES BASIC REQUIREMENTS








### INVISACOOK™ INDUCTION SYSTEM BASIC CONCEPTS




#### INVISACOOK INDUCTION UNIT

Depending on the requirements, there are three validated models of Invisacook® invisible induction system for use with Panoramic Porcelain Surfaces:


#### **1 BURNER UNIT**



#### **2 BURNERS UNIT**



The Invisacook ware with raisers are not allowed.




Every induction unit will include a control pad, depending on the type

As no cut-outs are allowed in the countertop area where the induction unit is placed, the control pads will always be placed frontally (on the




Outdoor use.

### **3 BURNERS UNIT**



#### 4 BURNERS UNIT








# DESIGN, INSTALLATION & USE REQUIREMENTS

#### MINIMUM DISTANCES TO EDGES


The minimum distance (D) set will be a minimum in Panoramic 20mm (2cm) of 250mm [10"], and for Panoramic 12mm of 300mm [11.8"], from the centre axis of each induction burner to any of the edges/joints (front, rear, and sides).

This way, and depending on the type of induction unit chosen, we have:


#### **1BURNER UNIT**




#### **2 BURNER UNIT**



#### 3 BURNER UNIT




#### 4 BURNER UNIT



#### **PANORAMIC CONFIGURATION & DISTANCES**


The minimum distance between units, for any Combination (1+1,1+2,2+2,etc.), will be determined by the space occupied by the installation elements (clips) of the system. Please refer to the manufacturer's documentation for further details.



#### **INSTALLATION PROCESS**

Install the units by following the manufacturer's instructions. The only valid installation procedure is by using its Epoxy adhesive + Sink Clips + Z Clips.

Other types of installation (e.g. as Drill + Insert + Screw) are NOT allowed under any circumstances.



Epoxy + Sink Clip + Z Clip

Drill + Insert + Screw



- MANDATORY use of Invisamat (silicone rising mat).
- 4 and 5 burners are for island use only due to minimum specification requirements.
- Never heat empty cookware, as it can reach very high temperatures and damage both Invisamat and the Panoramic Porcelain Surfaces.
- Follow the appliance manufacturer's recommendations for proper ventilation under the countertop.
- Find further information on this induction system at <u>www.invisacook.com</u>.
- Daltile warranty does not cover possible damages caused by improper use.








# FOR ISLAND USE ONLY DUE TO MINIMUM SPECIFICATION REQUIREMENTS

#### 4 BURNER UNIT



#### 5 BURNER UNIT

